

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DALTON](#) /

› [DALTON KS10Pro Portable Karaoke Machine User Manual](#)

DALTON KS10Pro

DALTON KS10Pro Portable Karaoke Machine User Manual

Model: KS10Pro

Introduction	What's in the Box	Setup	Operating Instructions	Maintenance	Troubleshooting
			Warranty & Support		

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your DALTON KS10Pro Portable Karaoke Machine. Please read this manual thoroughly before using the product and retain it for future reference. The DALTON KS10Pro is an all-in-one portable karaoke system designed for versatile audio entertainment. It features Bluetooth connectivity, dual wireless microphones, and various input options for music playback and vocal performance.

2. WHAT'S IN THE Box

Upon unpacking, please ensure all items listed below are present and in good condition:

- 2 UHF Wireless Microphones
- 4 AA Batteries (for microphones)
- 1 Power Cable
- 1 Storage Box (for microphones)
- 1 Instruction Manual (this document)





Image: The complete package contents of the DALTON KS10Pro Portable Karaoke Machine, showing the main speaker unit, two wireless microphones, power cable, AA batteries, and a storage case.

3. SETUP GUIDE

3.1 Initial Charging

Before first use, fully charge the karaoke machine. Connect the provided power cable to the AC120V/60Hz input on the rear panel of the speaker and plug it into a power outlet. The 'CHARGE' indicator light will illuminate. Charging is complete when the 'CHARGE' light turns off or changes color (refer to specific model indicators if different).

Your browser does not support the video tag.

Video: A demonstration of the DALTON KS10Pro Portable Bluetooth Speaker, highlighting its features and portability. This video shows the speaker being moved and its control panel.

3.2 Microphone Setup

- Insert the 4 AA batteries into the wireless microphones.
- Turn on each microphone using its power switch. The microphones should automatically pair with the speaker.
- Place the non-roll rings on the microphones for added protection and stability.

3.3 Connecting to a Music Source

The KS10Pro offers multiple connectivity options:

- **Bluetooth:**
 1. Turn on the karaoke machine.
 2. Activate Bluetooth on your smartphone, tablet, or other device.
 3. Search for "Dalton BT03" (or similar, refer to your device's Bluetooth list) and pair.
 4. Once connected, you can play music wirelessly from your device.
- **USB:** Insert a USB drive containing MP3 files into the USB port on the control panel. The speaker will automatically detect and play the music.
- **AUX IN:** Connect an external audio device (e.g., TV, MP3 player) using an AUX cable to the AUX IN ports on the rear panel.



Image: The DALTON KS10Pro Portable Karaoke Machine highlighting its connectivity options: Bluetooth, AUX, and USB, indicating versatile music playback.

Your browser does not support the video tag.

Video: A demonstration of a karaoke machine playing songs from YouTube, showing the screen interface and song selection. This video illustrates how to select and play music for karaoke.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

Locate the 'POWER' switch on the control panel. Flip it to 'ON' to power on the device. Flip it to 'OFF' to power off.

4.2 Adjusting Volume and Effects

The control panel features various knobs for fine-tuning your audio experience:

- **MUSIC VOL:** Adjusts the overall music volume.
- **MUSIC TREBLE/BASS:** Controls the treble and bass levels of the music.
- **MIC VOL:** Adjusts the microphone volume.
- **MIC TREBLE/BASS:** Controls the treble and bass levels of the microphones.
- **ECHO:** Adds an echo effect to the microphone vocals.
- **DELAY:** Adjusts the delay of the echo effect.




Image: A detailed view of the DALTON KS10Pro control panel, showing all knobs and inputs for adjusting music and microphone settings, including volume, treble, bass, echo, and delay.

4.3 Portable Use

The KS10Pro is designed for portability with 360-degree wheels and a sturdy handle, allowing you to easily move it to any location for indoor or outdoor events.

Portable Karaoke Speaker

Sturdy & modern design



Alloy steel &
rubber handle



33.9 lbs



Wooden
cabinet



Image: A woman demonstrating the portability of the DALTON KS10Pro karaoke speaker, easily moving it across a floor using its built-in wheels and handle.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker and microphones. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, fully charge the unit before long periods of storage and recharge it every 3 months.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted; Power cable not connected.	Charge the unit; Ensure power cable is securely connected.
No sound from speaker	Volume too low; Incorrect input mode selected; Device not paired (Bluetooth).	Increase MUSIC VOL; Select correct input mode (Bluetooth/USB/AUX); Re-pair Bluetooth device.
No sound from microphone	Microphone off; Batteries depleted; MIC VOL too low.	Turn on microphone; Replace batteries; Increase MIC VOL.
Poor sound quality	Interference; Incorrect TREBLE/BASS settings.	Move away from other electronic devices; Adjust MUSIC/MIC TREBLE/BASS knobs.

Your browser does not support the video tag.

Video: Instructions on how to connect a karaoke machine to a TV using an optical cable. This video demonstrates the process of setting up audio output from a TV to an external speaker.

7. SPECIFICATIONS

Feature	Detail
Brand	DALTON
Model Number	KS10Pro
Output Wattage	300 Watts
Woofer Size	10-inch
Tweeter Size	1-inch
Connectivity Technology	AUX, Bluetooth, USB
Power Source	Battery Powered
Item Weight	33.9 pounds
Product Dimensions	21.3 x 12.6 x 17.6 inches
Material	Steel, Wooden Cabinet
Number of Channels	2
Compatible Devices	TV, Guitar, USB, AUX IN, Wireless Microphone

ULTIMATE AUDIO EXPERIENCE



300W



10-inch Woofer



1-inch Tweeter




Image: An exploded diagram of the DALTON KS10Pro speaker, illustrating its internal components including the 300W power output, 10-inch woofer, and 1-inch tweeter for harmonizing sounds.

8. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official DALTON website. Keep your purchase receipt as proof of purchase for warranty claims.

Protection plans are available for purchase separately:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect: One plan covers all eligible past and future purchases