



Manuals.plus /

› JEEOHEY /

› JEEOHEY Oversized Corduroy Chaise Lounge Chair with Ottoman User Manual

JEEOHEY B0CTMPT5D9

JEEOHEY Oversized Corduroy Chaise Lounge Chair with Ottoman User Manual

Model: B0CTMPT5D9

1. INTRODUCTION

Thank you for choosing the JEEOHEY Oversized Corduroy Chaise Lounge Chair with Ottoman. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: The JEEOEHEY Oversized Corduroy Chaise Lounge Chair with Ottoman.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 350 lbs (158 kg).
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid standing on the chaise lounge or ottoman.
- Place the furniture on a level surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Chaise Lounge Base (1)
- Ottoman (1)
- Backrest Cushion (1)
- Throw Pillows (2)
- Assembly Hardware (e.g., screws, bolts, Allen wrench)
- Instruction Manual (this document)

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two people assemble the chaise lounge to ensure stability and ease of installation. Please follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Legs:** Securely attach the legs to the bottom of the chaise lounge base and the ottoman using the provided hardware. Ensure they are tightened firmly.
3. **Install Backrest:** Align the backrest cushion with the brackets on the chaise lounge base. Gently push down until it locks into place. Ensure it is stable and does not wobble.
4. **Position Pillows:** Place the back pillow and two throw pillows on the chaise lounge for added comfort and support.
5. **Final Check:** Verify that all connections are secure and the furniture is stable before use.

DIMENSIONS DATA



Weight Capacity

Image 4.1: Product dimensions for planning placement.

REMOVABLE OTTOMAN

The **movable ottoman** can be combined with the sofa chair in any combination. You can take naps, watch TV, read and enjoy leisure time with your family and friends on this chaise lounge. ✨ ✨



X1



Suitable for many scenarios



Living Room



Bedroom



Apartment



Office

Image 4.2: The removable ottoman can be positioned as desired.

5. USAGE

The JEEOHEY Chaise Lounge Chair and Ottoman are designed for comfortable indoor use. Its versatile design allows for various configurations:

- **Chaise Lounge:** Combine the ottoman with the main chair to create an extended lounging surface for relaxation, reading, or napping.
- **Armchair with Footrest:** Use the ottoman separately as a footrest for the armchair, providing support for your legs.
- **Additional Seating:** The ottoman can serve as an extra seat when entertaining guests.
- **Side Table:** With a tray, the ottoman can function as a temporary side table.



Image 5.1: The chaise lounge provides ample space for relaxation.



Image 5.2: The ottoman can be used independently or with the chaise.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your chaise lounge.

- **Cleaning:** Wipe clean with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the corduroy fabric.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.
- **Vacuuming:** Regularly vacuum the fabric using a soft brush attachment to remove dust and debris.
- **Pillow Care:** Fluff pillows regularly to maintain their shape and comfort.



Image 6.1: The corduroy fabric and high-density foam require gentle care.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chaise feels wobbly after assembly.	Loose connections or uneven placement.	Ensure all bolts and screws are tightened. Place on a flat, level surface.
Backrest does not feel secure.	Backrest not fully engaged with brackets.	Re-align the backrest and push down firmly until it clicks into place.
Fabric appears flattened or creased.	Prolonged pressure or packaging.	Fluff cushions and allow time for fabric to recover. Gentle steaming may help with creases.

8. SPECIFICATIONS

Feature	Detail
Brand	JEEOHEY
Model Number	B0CTMPT5D9
Overall Dimensions (D x W x H)	55.1"D x 43.3"W x 30.7"H (Chaise Lounge with Ottoman)
Ottoman Dimensions (D x W x H)	21"D x 43.3"W x 18"H
Seat Depth	42 inches
Seat Height	18 Inches
Weight Capacity	350 Pounds
Upholstery Material	Corduroy Fabric
Frame Material	Solid Wood
Assembly Required	Yes (Recommended 2 people)
Included Components	Chaise Lounge, Ottoman, 1 Back Pillow, 2 Throw Pillows

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

For additional assistance, you may visit the JEEOHEY store on Amazon:[JEEOHEY Store](#)

