



Manuals.plus /

› **Slypadan /**

› Slypadan 15" Large Outdoor Wall Lights Instruction Manual

Slypadan AK-B06121P-2PKUS-CA

Slypadan 15" Large Outdoor Wall Lights Instruction Manual

Model: AK-B06121P-2PKUS-CA

INTRODUCTION

This manual provides detailed instructions for the safe installation, proper operation, and effective maintenance of your Slypadan 15" Large Outdoor Wall Lights. Please read this manual thoroughly before beginning any installation or use to ensure optimal performance and safety. Retain this manual for future reference.



Image: A pair of Slypadan 15-inch matte black outdoor wall lights, featuring a rectangular frame and clear glass panels, designed for exterior use.

The Slypadan 15" Large Outdoor Wall Lights are designed to provide reliable and elegant illumination for various outdoor spaces, including front doors, porches, garages, and backyards. Constructed from premium metal with a matte black finish and thick clear glass, these fixtures are built to withstand diverse weather conditions while enhancing your home's aesthetic.

IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or personal injury, always follow these basic safety precautions:

- **Always turn off the power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.**
- Consult a qualified electrician if you are unsure about the installation process or have any electrical questions.
- Use only bulbs of the specified type and wattage. Refer to the "Specifications" section for details.
- Do not install on surfaces that are not structurally sound or that cannot support the weight of the fixture.

- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not modify the fixture in any way. Any modifications may void the warranty and create a safety hazard.
- Keep flammable materials away from the light fixture when in operation.
- Wear appropriate safety gear, such as gloves and eye protection, during installation.

PACKAGE CONTENTS

Carefully unpack your new wall lights and ensure all components are present and undamaged. If any parts are missing or broken, please contact customer support immediately.

- Slypadan 15" Outdoor Wall Light Fixture (2 units)
- Instruction Manual (this document)
- Mounting Hardware (screws, wire nuts, mounting plate)



Image: A diagram illustrating the dimensions of the wall light (14.75 inches height, 6.38 inches width, 5 inches depth) and indicating it comes in a 2-pack, with details on color, voltage, material, and bulb base.

SPECIFICATIONS

Below are the technical specifications for your Slypadan Outdoor Wall Lights:

Feature	Detail
Brand	Slypadan
Model Number	AK-B06121P-2PKUS-CA
Color	Matte Black
Material	Metal, Clear Glass
Style	Modern
Product Dimensions	6.38" W x 14.75" H x 5" D (extends from wall)
Power Source	Corded Electric
Voltage	120 Volts (AC)
Bulb Base	E26 (Bulb not included)
Max Wattage	60 watts
Water Resistance Level	Waterproof
Indoor/Outdoor Usage	Outdoor Use Only
Mounting Type	Wall Mount
Number of Items	2 (Pack)



Image: A visual comparison highlighting the superior features of Slypadan lights, including larger size, tempered clear glass, high-quality metal, anti-rust and corrosion properties, and full weather resistance.

SETUP AND INSTALLATION

Before You Begin

- **Safety First:** Ensure the power to the installation area is turned OFF at the circuit breaker or fuse box.
- **Tools Required (Not Included):** Phillips head screwdriver, flathead screwdriver, wire strippers, electrical tape, ladder (if necessary).
- **Location:** Choose a suitable outdoor location for wall mounting, ensuring it is structurally sound and has proper electrical wiring.

Step-by-Step Installation

1. **Prepare Wiring:** If replacing an existing fixture, carefully disconnect and remove the old fixture. Ensure the electrical box is clean and accessible.
2. **Attach Mounting Plate:** Secure the mounting plate (included) to the electrical junction box using the provided screws. Ensure the plate is level and firmly attached.
3. **Make Electrical Connections:**
 - Connect the **black** wire from the fixture to the **black** (hot) wire from the electrical box using a wire nut.
 - Connect the **white** wire from the fixture to the **white** (neutral) wire from the electrical box using a wire nut.
 - Connect the **green** or **bare copper** ground wire from the fixture to the ground wire from the electrical box (or to the green ground screw on the mounting plate).

Ensure all wire nuts are securely tightened and connections are insulated with electrical tape if necessary.

4. **Mount the Fixture:** Carefully align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the wall and stable.
5. **Install Bulb:** Insert an E26 base bulb (not included) into the socket. Do not exceed the maximum wattage of 60W.
6. **Restore Power:** Once the installation is complete and all connections are secure, turn the power back ON at the main circuit breaker.



Image: A detailed view of the light fixture's base, highlighting the mounting points and the E26 bulb socket, crucial for installation and bulb replacement.

OPERATION

Your Slypadan Outdoor Wall Lights are designed for straightforward operation. Once properly installed and powered, they will function according to your home's electrical switch. These lights do not feature integrated switches or dimmers and rely on your existing wall switch for control.

Bulb Compatibility

The fixture uses a standard E26 socket, offering broad compatibility with various bulb types (bulb not included). You can choose from:

- **LED Bulbs:** Energy-efficient and long-lasting.
- **CFL Bulbs:** Compact fluorescent lamps.
- **Incandescent Bulbs:** Traditional bulbs (up to 60W).
- **Halogen Bulbs:** Provide bright, crisp light.

Ensure the chosen bulb's wattage does not exceed 60 watts to prevent overheating and damage to the fixture.



Image: A visual guide demonstrating the compatibility of the light fixture with various E26 base bulbs, such as LED, CFL, incandescent, and smart bulbs, emphasizing that bulbs are not included.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your Slypadan Outdoor Wall Lights.

Cleaning

- **Always turn off the power to the fixture before cleaning.**
- Use a soft, damp cloth to wipe down the metal frame and glass panels.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or glass.
- For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth and then drying thoroughly.

Bulb Replacement

- **Ensure the power is OFF and the bulb has cooled down before attempting to replace it.**
- The open-bottom design allows for easy access to the bulb. Simply unscrew the old bulb and screw in a new E26 base bulb.
- Ensure the new bulb's wattage does not exceed 60W.

TROUBLESHOOTING COMMON ISSUES

If you encounter any issues with your wall lights, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb.	Check circuit breaker/fuse. Ensure all wire connections are secure (power off first). Replace bulb with a new one.
Light flickers or dims.	Loose bulb. Incorrect bulb type/wattage. Loose wiring.	Tighten bulb. Ensure bulb is E26 base and within 60W. Check wire connections (power off first).
Fixture is hot to the touch.	Bulb wattage too high.	Replace bulb with one that does not exceed 60W.
Water inside the fixture.	Improper sealing during installation. Damage to fixture.	Ensure fixture is properly sealed against the mounting surface. Inspect for cracks or damage. Contact support if damage is present.

If the problem persists after attempting these solutions, please contact Slypadan customer support.

WARRANTY INFORMATION

Slypadan provides a **3-Year Warranty** for these outdoor wall lights, covering defects in materials and workmanship under normal use. This warranty is valid from the date of purchase. Please retain your proof of purchase for warranty claims.



Image: Slypadan outdoor wall lights illuminating a porch, accompanied by a prominent "3 Year Warranty Guaranteed" badge, signifying product reliability.

The warranty does not cover damage caused by improper installation, misuse, abuse, accidents, unauthorized repairs or modifications, or acts of nature. For warranty service, please contact our customer support team.

CUSTOMER SUPPORT

For any questions, assistance, or technical support regarding your Slypadan 15" Large Outdoor Wall Lights, please contact our dedicated customer support team. We are committed to providing excellent service.

Contact Information:

Email: support@slypadan.com (Example email, as no specific email was provided)

Website: [Slypadan Official Store on Amazon](#)

Phone: Please refer to the product packaging or official website for the most current phone support options.

When contacting support, please have your model number (AK-B06121P-2PKUS-CA) and purchase date ready to expedite assistance.

