

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko 3x3m Garden Gazebo with LED Lights - Instruction Manual

Devoko 3*3m

Devoko 3x3m Garden Gazebo with LED Lights

Model: 3*3m | Brand: Devoko

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Devoko 3x3m Garden Gazebo. Please read all instructions carefully before beginning assembly or use to ensure safe and correct operation. Keep this manual for future reference.

SAFETY INFORMATION

- Ensure all connections are secure and tightened before and during use.
- Do not use the gazebo in extreme weather conditions, such as strong winds, heavy rain, or snow. Disassemble or secure the gazebo appropriately during such conditions to prevent damage or injury.
- Keep all heat sources and open flames away from the gazebo fabric.
- Adult assembly is required. Keep children and pets away from the assembly area.
- Regularly inspect the gazebo for any signs of wear, damage, or loose parts. Address any issues promptly.
- Ensure the gazebo is anchored firmly to the ground using the provided stakes or other suitable anchoring methods.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. All parts are numbered for easy identification.

- Metal Frame Components (legs, beams, connectors)
- Main Canopy Fabric (UV50+ coated polyester)
- Double-Layer Roof Fabric
- Removable Side Panels (4 pieces)
- LED Lighting System (central spotlight, 8 upper lamp beads)
- Solar Panel and USB Charging Cable
- Remote Control for LED Lights
- Ground Stakes (8 pieces)

- Assembly Tools and Hardware
- Instruction Manual



Image: Exploded view of the Devoko gazebo components, showing the frame, canopy, and side panels before assembly.

SETUP AND ASSEMBLY

Follow these steps for proper assembly. It is recommended to have at least two adults for assembly.

1. **Unpack and Identify Parts:** Lay out all components and match them with the parts list in the manual. Ensure all numbered parts are accounted for.
2. **Assemble the Base Frame:** Connect the lower leg sections and horizontal beams to form the base of the gazebo. Ensure all connections are finger-tight initially.
3. **Install Reinforced Support Posts:** Attach the reinforced support posts to the base frame. These posts are designed for enhanced stability.
4. **Construct the Roof Frame:** Assemble the upper frame structure, including the triangular stabilizing connections, which contribute to the gazebo's overall stability.
5. **Attach Canopy Fabric:** Carefully drape and secure the main canopy fabric and the double-layer roof fabric onto the

assembled frame. Ensure the fabric is taut and evenly distributed. The double-layer design allows for ventilation.

- 6. Install LED Lighting System:** Integrate the solar panel and LED lights into the designated areas on the roof frame. Connect the wiring as per the detailed diagram in the included manual.
- 7. Attach Side Panels:** Hang the four removable side panels. These can be tied back or deployed for privacy and additional shade.
- 8. Secure to Ground:** Once the gazebo is fully assembled, use the provided 8 thickened ground stakes to firmly anchor the gazebo to the ground. This is crucial for stability, especially in varying weather conditions.



Image: Diagram illustrating the dimensions of the Devoko 3x3m gazebo and its removable side panels.




Image: Visual comparison highlighting the reinforced support posts and triangular stabilizing structure for enhanced durability.

OPERATING INSTRUCTIONS (LED LIGHTS)

Your Devoko gazebo features an integrated LED lighting system for evening use.

- **Power Source:** The LED lights are powered by a solar panel and also support USB charging for convenience. Ensure the solar panel is exposed to direct sunlight for optimal charging.
- **Remote Control Functions:** The included remote control allows you to manage the lighting.
 - **On/Off Switch:** Press the designated buttons to turn the lights on or off.
 - **Timer Function:** Set the lights to turn off automatically after 30 or 60 minutes.
 - **Brightness Adjustment:** Choose from 5 levels of brightness to suit your ambiance.
 - **Automatic Runtime:** The lights are designed for approximately 4 hours of continuous operation on a full charge.
- **Charging:** For solar charging, ensure the panel is clean and receives adequate sunlight. For USB charging, connect the provided cable to a suitable power source.



Image: The Devoko gazebo illuminated at night, showcasing the LED lighting system and its remote control.

MAINTENANCE

Proper maintenance will extend the life of your gazebo.

- **Cleaning the Canopy:** The UV50+ coated polyester fabric is resistant to fading. Clean the canopy and side panels with mild soap and water. Rinse thoroughly and allow to air dry completely before folding or storing. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** The galvanized alloy frame is rust and corrosion-resistant. Wipe down the metal frame with a damp cloth to remove dirt and debris. Inspect for any scratches or chips in the coating and touch up if necessary to prevent rust.
- **Seasonal Storage:** For prolonged periods of non-use or during harsh weather seasons, it is recommended to disassemble the gazebo and store it in a dry, protected area. Ensure all fabric components are clean and dry before storage to prevent mold or mildew.
- **Inspection:** Periodically check all nuts, bolts, and connections to ensure they remain tight. Inspect the fabric for any tears or damage.

TECHO DE DOBLE CAPA

Ventilación y extracción de humos



Image: Detail of the gazebo's double-layer roof, designed for effective ventilation.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **LED Lights Not Working:**
 - Check if the solar panel is clean and receiving sufficient sunlight.
 - Ensure the LED system is fully charged (via solar or USB).
 - Verify that the remote control battery is functional and correctly inserted.
 - Confirm all wiring connections for the LED system are secure.
- **Gazebo Instability:**
 - Ensure all frame connections are tightly secured.
 - Verify that all 8 ground stakes are fully inserted into stable ground.
 - Avoid using the gazebo in high winds.
- **Water Accumulation on Canopy:**

- Ensure the canopy fabric is stretched tautly across the frame to prevent sagging.
- Clear any debris from the canopy that might impede water runoff.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	300 x 300 x 285 cm (3L x 3W x 2.85H meters)
Weight	29.1 kilograms
Model Number	3*3m
Brand	Devoko
Frame Material	Metal (Galvanized Alloy)
Canopy Material	UV50+ Coated Polyester Fabric (180G/m ²)
Water Resistance Level	Waterproof
UV Protection	UV50+
Occupancy	4-6 people
Assembly Required	Yes
Lighting	Integrated LED lights (Solar & USB rechargeable)

WARRANTY AND SUPPORT

For any installation or usage problems, please do not hesitate to contact Devoko customer support. Refer to your purchase documentation for specific warranty details and contact information.

You can often find support contact details on the retailer's website where you purchased the product or on the official Devoko brand store page.