

[manuals.plus](#) /› [Jada](#) /› [Jada Toys Wednesday Addams Thing RC Instruction Manual](#)**Jada 35132**

Jada Toys Wednesday Addams Thing RC Instruction Manual

Brand: Jada | Model: 35132

INTRODUCTION

Step into the eerie, enchanting world of Wednesday Addams with the Jada Toys "Thing" R/C – a life-size, remote-controlled replica of the iconic disembodied hand. Straight from the mysterious halls of Nevermore, this mischievous accomplice is ready to join you on all your thrilling adventures. Designed with a soft plastic texture and realistic paintwork, the "Thing" R/C looks and feels just like the real deal. The fine stitching details add to its authenticity, making it a perfect companion for fans of the Addams Family. The simple-to-use toggle remote lets you guide Thing forward, backward, and turn with ease, ensuring that no mystery is left unsolved. Powered by a convenient USB rechargeable battery, your new partner in crime is always ready for the next adventure. Whether you're creeping around the house or putting it on display, the "Thing" R/C is a fun, eerie, and intriguing addition to your collection.

WHAT'S IN THE BOX

- Jada Toys Wednesday Addams Thing RC Unit
- Remote Control
- USB Charging Cable (integrated into the Thing unit)

SETUP

1. Charging the Thing RC Unit

The Thing RC unit is powered by a USB rechargeable battery. To charge:

1. Locate the USB charging cable integrated into the base of the Thing unit.
2. Plug the USB cable into any standard USB power adapter (not included) or a computer's USB port.
3. The indicator light on the Thing unit will illuminate during charging and turn off when fully charged.
4. A full charge typically takes approximately 60-90 minutes.



Image: The Thing RC unit with its integrated USB charging cable and an illustration of the remote requiring 2x AAA batteries.

2. Installing Batteries in the Remote Control

The remote control requires 2x AAA batteries (not included). To install:

1. Open the battery compartment on the back of the remote control.
2. Insert 2x AAA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment securely.

OPERATING INSTRUCTIONS

1. Powering On

- Ensure the Thing RC unit is fully charged.
- Turn on the Thing RC unit using the power switch located on its base.
- Turn on the remote control. The indicator light on the remote will show it's active.



Image: The Jada Toys Wednesday Addams Thing RC unit and its unique bat-shaped remote control.

2. Remote Control Functions

The remote control features a simple toggle switch designed to mimic a hand, allowing intuitive control of the Thing RC unit.

- **Forward Movement:** Push the toggle switch forward to make Thing crawl forward.
- **Backward Movement:** Pull the toggle switch backward to make Thing crawl backward.
- **Turning:** Push the toggle switch left or right to make Thing turn in the corresponding direction.



Image: A close-up of the remote control, highlighting its unique hand-shaped toggle for intuitive movement.

3. Dynamic Movement

The Thing RC unit is designed to mimic the crawling motion of the character from the show, providing a realistic and engaging play experience.



Image: The Thing RC unit demonstrating its dynamic movement, capable of crawling and turning.

4. Official Product Video

Video: An official product video from Jada Toys showcasing the Wednesday Addams Thing RC unit in action, demonstrating its

MAINTENANCE

- Cleaning:** Wipe the Thing RC unit and remote control with a soft, damp cloth. Do not submerge in water.
- Storage:** Store the unit in a cool, dry place away from direct sunlight when not in use.
- Battery Care:** For prolonged storage, remove batteries from the remote control. Ensure the Thing RC unit is fully charged before storing for extended periods.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------------|--|---|
| Thing RC unit does not move. | Low battery in Thing unit or remote. | Charge the Thing RC unit. Replace batteries in the remote control. |
| Remote control not responding. | Batteries in remote are dead or incorrectly installed. | Check battery polarity or replace with new AAA batteries. |
| Limited range or erratic movement. | Interference or low battery. | Ensure no obstacles between remote and Thing. Charge Thing unit. Move closer to the unit. |

SPECIFICATIONS

| Feature | Detail |
|------------------------------|--|
| Product Dimensions | 5.5 x 4 x 6.25 inches (13.97 x 10.16 x 15.88 cm) |
| Item Weight | 1.3 pounds |
| Item Model Number | 35132 |
| Manufacturer Recommended Age | 8 years and up |
| Power Source (Thing Unit) | USB Rechargeable Battery |
| Power Source (Remote) | 2x AAA Batteries (not included) |
| Country of Origin | China |




Image: The Thing RC unit displaying its approximate dimensions.

WARRANTY AND SUPPORT

For warranty information or product support, please contact Jada Toys customer service directly. Refer to the product packaging or the official Jada Toys website for the most up-to-date contact details and warranty policies. *Please retain your purchase receipt as proof of purchase for any warranty claims.*

Related Documents - 35132

| | |
|--|--|
|  | <p>Jada FF19 7.5" RC Car Instruction Manual</p> <p>This document provides instructions for operating and maintaining the Jada FF19 7.5" RC Car, including features like the vapor function and turbo boost. It covers battery installation, troubleshooting, and safety precautions.</p> |
|  | <p>Jada 1/16" RC Vehicle: User Manual and Operation Guide</p> <p>Get detailed instructions for your Jada 1/16" remote control vehicle. This guide covers setup, charging, playing, troubleshooting, safety, and regulatory information for model F84228-KMAR-1SH-EN01A.</p> |

| | |
|--|---|
|  | <p><u>Jada Toys Back to the Future Time Machine R/C 1:16 Scale - User Manual</u></p> <p>Comprehensive user manual and safety guide for the Jada Toys Back to the Future Time Machine R/C 1:16 scale remote control vehicle. Learn how to charge, operate, troubleshoot, and maintain your RC car, along with important safety information and warranty details.</p> |
|  | <p><u>Jada Toys RC Buggy Woody Toy Story Edition Instruction Manual</u></p> <p>Official instruction manual for the Jada Toys RC Buggy Woody, featuring Toy Story branding. Includes setup, operation, battery installation, safety warnings, and customer support information.</p> |
|  | <p><u>Wednesday Thing RC 4L Remote Control Toy - Instruction Manual</u></p> <p>Official instruction manual for the Jada Toys Wednesday Thing RC 4L remote control toy. Learn how to play, charge, troubleshoot, and find important safety information.</p> |
|  | <p><u>Jurassic World Jeep RC 1:16 - Jada Toys Instruction Sheet</u></p> <p>This instruction sheet provides essential guidance for operating the Jada Toys Jurassic World Jeep RC 1:16. Learn about battery installation, vehicle pairing, turbo boost features, and troubleshooting tips for safe and enjoyable play.</p> |