

Retro Fighters Hunter

Retro Fighters Hunter XBOX Wireless Controller User Manual

Brand: Retro Fighters | Model: Hunter

INTRODUCTION

The Retro Fighters Hunter Wireless Controller is designed to provide a modern gaming experience for classic consoles and platforms. Featuring 2.4 GHz wireless technology, it offers low latency and drift-free gameplay. This controller is compatible with the original Xbox, Nintendo Switch, and PC, bringing contemporary ergonomic design and advanced features to your favorite games.

KEY FEATURES

- **2.4 GHz Wireless Technology:** Ensures low latency and a stable connection for responsive gameplay.
- **Multi-Platform Compatibility:** Works seamlessly with original Xbox, Nintendo Switch, and PC.
- **Hall Effect Analog Sticks:** Engineered for precision and durability, eliminating stick drift.
- **Pressure Sensitive Buttons:** Provides varied input based on press intensity, supporting original Xbox game mechanics.
- **Next-Gen Ergonomic Design:** Offers a comfortable and familiar feel for extended gaming sessions.

SETUP GUIDE

To begin using your Retro Fighters Hunter Wireless Controller, follow these steps:

1. **For Original Xbox:** Insert the included Xbox-specific dongle into an available controller port on your original Xbox console.
2. **For Nintendo Switch/PC:** Insert the included USB dongle into an available USB port on your Nintendo Switch dock or PC.
3. **Power On Controller:** Press the central Xbox button on the controller to power it on.
4. **Pairing:** Locate the small sync button on the back of the controller, just below the 'Hunter' label. Press and hold this button until the controller's indicator lights begin to flash rapidly. Simultaneously, press the sync

button on the dongle. The lights on both the controller and dongle will become solid once successfully paired.

5. **Reconnection:** After initial pairing, you can typically reconnect by simply pressing the central Xbox button on the controller.



Figure 1: Top view of the Retro Fighters Hunter Wireless Controller, showing its ergonomic design and button layout.

OPERATING INSTRUCTIONS

The Hunter controller is designed for intuitive use, mirroring modern controller layouts while retaining classic functionality.

- **Analog Sticks:** Utilize the Hall Effect analog sticks for precise movement and aiming. These sticks are designed to prevent drift over time.
- **Pressure Sensitive Buttons:** The face buttons (A, B, X, Y) and triggers offer pressure sensitivity, allowing for nuanced control in games that support this feature on the original Xbox.
- **D-Pad:** The directional pad provides tactile feedback for accurate directional input. While improved over some original designs, some users may find the surrounding lip slightly high.
- **Rumble Motors:** Experience immersive feedback with built-in rumble motors that respond to in-game actions.



Figure 2: Detailed views of the Hall Effect analog stick and responsive trigger button.

MAINTENANCE

To ensure the longevity and optimal performance of your controller, please observe the following maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the controller. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no moisture enters the ports or crevices.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** The controller uses a Lithium Ion battery. Avoid fully discharging the battery frequently. If storing for extended periods, charge the battery to about 50% to prolong its lifespan.

TROUBLESHOOTING

If you encounter issues with your Retro Fighters Hunter Wireless Controller, consider the following:

- **Controller Not Connecting:** Ensure the correct dongle (Xbox or USB) is securely inserted into the console/PC. Re-attempt the pairing process as described in the Setup Guide. Verify the controller battery is charged.
- **Input Lag/Latency:** Ensure the controller and dongle are within close proximity and there are no significant obstructions. Interference from other wireless devices can sometimes affect performance.
- **D-Pad Feel:** While the D-pad is designed for improved performance, its physical design may feel different from other controllers. This is generally a characteristic of the design and not a defect.
- **No Wired Connection:** The USB-C port on the controller is primarily for charging and firmware updates. It does not support a direct wired connection for gameplay. All gameplay is wireless via the included dongles.

SPECIFICATIONS




ASIN	B0CTP8TH4F
Release Date	January 31, 2024
Package Dimensions	6.85 x 4.8 x 2.95 inches
Item Weight	5.6 ounces
Batteries	1 Lithium Ion batteries required (included)
Manufacturer	Retro Fighters

WARRANTY AND SUPPORT

For warranty information, technical support, or further inquiries, please refer to the official Retro Fighters website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

© 2025 Retro Fighters. All rights reserved.

Related Documents - Hunter

	<p>Retro Fighters Hunter Wireless Gamepad Quick Start Guide - Xbox, Switch, PC</p> <p>Get started with your Retro Fighters Hunter Wireless Gamepad for Xbox, Nintendo Switch, and PC. This quick start manual covers pairing, features, FAQs, and troubleshooting.</p>
	<p>Retro Fighters StrikerDC Wireless Gamepad for Sega Dreamcast - Quick Start Guide</p> <p>Get started with your Retro Fighters StrikerDC wireless gamepad for Sega Dreamcast. This quick start manual provides pairing instructions, button mapping, LED indicators, and firmware update information.</p>
	<p>Retro Fighters Brawler64 Wireless Edition Gamepad - User Guide</p> <p>Instructions and information for setting up and using the Retro Fighters Brawler64 Wireless Edition gamepad for Nintendo 64. Includes pairing, charging, and troubleshooting.</p>
	<p>Brawler64 Bluetooth NSO Edition Firmware Update Instructions</p> <p>Step-by-step guide to updating the firmware for the Retro Fighters Brawler64 Bluetooth NSO Edition controller for Nintendo Switch.</p>
	<p>Retro Fighters D6 Dreamcast Controller Firmware Update Guide</p> <p>Instructions for updating the firmware on the Retro Fighters D6 Dreamcast Wireless 6-Button Controller for Dreamcast, Switch, and PC.</p>

USB DONGLE Firmware Update Instructions

1. Download the USB Dongle Firmware Update Instructions PDF.
2. Extract the USB Dongle Firmware Update Instructions PDF.
3. Run the USB Dongle Firmware Update Instructions PDF.
4. Follow the instructions in the PDF to update the USB Dongle.

For more information, please visit www.retrofighters.com

000000000000

[Retro Fighters BattlerGC/BladeGC USB Dongle Firmware Update Instructions](#)

Step-by-step guide for updating the firmware on the Retro Fighters BattlerGC and BladeGC USB dongle. Learn how to download, extract, and run the update program for your wireless GameCube controller.