

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY Modern Accent Armchair (Model DY-6871) Instruction Manual

COLAMY DY-6871

COLAMY Modern Accent Armchair (Model DY-6871) Instruction Manual

Your guide to assembly, use, and care.

INTRODUCTION

Thank you for choosing the COLAMY Modern Accent Armchair, Model DY-6871. This manual provides detailed instructions for the assembly, safe operation, and maintenance of your new chair. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The COLAMY Modern Accent Armchair, Model DY-6871, shown in a light grey fabric, positioned in a dining area next to a wooden table.

SAFETY INFORMATION

Important Safety Precautions:

- The maximum weight capacity for this chair is **275 pounds (125 kg)**. Do not exceed this limit to prevent injury or damage to the chair.
- Ensure all components are securely fastened during assembly. Periodically check and tighten all bolts to maintain stability.
- This chair is designed for indoor use only. Avoid exposure to direct sunlight, extreme temperatures, or moisture.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Do not stand on the chair or use it as a step stool.

WHAT'S IN THE BOX

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: An exploded diagram illustrating the chair components and hardware included in the package, labeled as "WHAT'S IN THE BOX".

- **A:** Seat Part (x1)
- **B:** Front Leg (x2)
- **C:** Back Leg (x2)
- **D:** M8*70mm Bolts (x8)
- **E:** Spring Washer (x8)
- **F:** Flat Washer (x8)
- **G:** Allen Wrench (x1)
- **H:** Adjustable Foot Nails (pre-installed on front legs)

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your COLAMY Modern Accent Armchair.

Step 1: Attach the Legs

1. Before assembly, place the seat part (A) on its side, with the bottom facing upwards. Locate the accessories, including the front legs (B), back legs (C), and the hardware bag.
2. Insert the front legs (B) and back legs (C) into the corresponding slots at the bottom of the seat part (A).
3. Secure each leg using two M8*70mm bolts (D), one spring washer (E), and one flat washer (F).
4. Tighten all eight bolts firmly with the provided Allen wrench (G). Do not overtighten.



Image: Detailed diagram showing the attachment of front and back legs to the chair's seat base using bolts and washers.

Step 2: Adjust Stability

5. Once all legs are securely attached, carefully turn the chair upright.
6. The front legs of the chair are equipped with adjustable foot nails. If the chair wobbles, gently turn the foot nails on the front legs to adjust the height until the chair is stable on your floor surface.



Image: Diagram showing how to adjust the foot nails on the front legs to ensure the chair's stability.

Your chair is now successfully installed.

OPERATING INSTRUCTIONS

The COLAMY Modern Accent Armchair is designed for comfortable seating in various indoor environments. Once assembled and stable, the chair is ready for use.

- **Placement:** Position the chair on a flat, stable surface. Ensure there is adequate space around the chair for comfortable movement.
- **Seating:** Sit gently on the chair. Avoid sudden impacts or excessive force when sitting down.
- **Versatility:** This chair is suitable for dining, living room accent seating, reading nooks, or as an additional seat for guests.

// MULTI-PURPOSE //



Image: A multi-panel image demonstrating the chair's versatility in different settings, including dining, living room, and event spaces.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your armchair.

- **Cleaning:** The fabric cover is resistant to spills and stains. For general cleaning, **spot clean only** with a mild detergent and a damp cloth. Blot the area gently; do not rub vigorously. Allow to air dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong chemical solvents, as these can damage the fabric and finish.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Inspection:** Periodically inspect all bolts and connections to ensure they remain tight. Tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.

TROUBLESHOOTING

If you encounter any issues with your COLAMY Modern Accent Armchair, refer to the following common solutions:

- **Chair Wobbles:**
 - Ensure all leg bolts are securely tightened.
 - Adjust the foot nails on the front legs by turning them clockwise or counter-clockwise until the chair is stable on an even surface.
- **Difficulty Assembling Legs:**
 - Verify that you are using the correct bolts and washers for each connection.
 - Ensure the legs are oriented correctly before inserting them into the slots.
 - Do not force components. If a part does not fit, re-check the instructions and component identification.
- **Stains on Fabric:**
 - Refer to the "Maintenance and Care" section for spot cleaning instructions. Act quickly on spills.

If these steps do not resolve your issue, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	COLAMY
Model Name	DY-6871
Color	Light Grey
Product Dimensions (D x W x H)	25.79"D x 25.2"W x 33.86"H
Item Weight	21.2 pounds (9.6 kg)
Maximum Weight Recommendation	275 Pounds (125 kg)
Material	Upholstered (Foam Fill), Rubberwood Frame
Back Style	Solid Back, Barrel Accent
Arm Style	Upholstered
Product Care Instructions	Spot Clean Only
Indoor/Outdoor Usage	Indoor

PRODUCT SIZE



Weight Capacity
275BS




Image: Detailed product dimensions including height, width, and depth, along with weight capacity.

WARRANTY AND SUPPORT

COLAMY stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official COLAMY website. If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact COLAMY customer support.

Customer Support: Please refer to the contact information provided on the product packaging or the official COLAMY website for the most up-to-date support channels.

Online Resources: For additional product information and FAQs, visit the [COLAMY Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question