

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Braun](#) /
- > [Braun Series 7 Electric Shaver User Manual](#)

Braun 72-C1500s

Braun Series 7 Electric Shaver User Manual

Model: 72-C1500s

Brand: Braun

PRODUCT OVERVIEW

The Braun Series 7 Electric Shaver is designed to provide a quick and close shave, even on busy mornings. This advanced shaver features an evolved close-contact system, ensuring a smooth finish with no stubble. It incorporates innovative technologies to optimize shaving performance and user comfort. Key features include:

Key features include:

- New Turbo Mode for faster shaving.
- 360° close-contact system for ultimate closeness.
- Selectable shaving modes (Turbo, Standard, Gentle) to optimize power.
- Artificial Intelligence Technology for automatic power adjustment.
- 100% waterproof design for wet and dry use, and easy cleaning.
- High-performance Lithium-ion battery with quick charge capability.
- German-engineered durability for long-lasting performance.

KEY FEATURES IN DETAIL

新ターボモードで
さらに早剃り

ターボモード	+28.5% 振動数UP vs. ジェントルモード
スタンダードモード	最適化されたパワー 毎日のシェービングに
ジェントルモード	+18% バッテリー長持ち vs. ターボモード

NEW

選べるシェービングモードで
パワーを最適化

Selectable Shaving Modes

The Braun Series 7 offers three distinct shaving modes: Turbo, Standard, and Gentle. You can easily switch between these modes by pressing the button below the power button. This allows you to optimize the shaver's power and speed according to your specific needs and beard density. Turbo mode increases rotation speed by up to 28.5% for a faster, deeper shave, ideal for busy mornings. Gentle mode reduces rotation speed for a milder shave, suitable for sensitive skin or lighter beard growth, and also extends battery life.



360° Close-Contact System

This shaver is equipped with an advanced 360° close-contact system. It features three floating blades, front-to-back head pivoting, and added side-to-side movement. This comprehensive flexibility ensures ultimate closeness, allowing the shaver to adapt to the contours of your face, even in difficult areas like under the chin or below the nose, for a completely stubble-free result.



100% Waterproof Design

The Braun Series 7 shaver is designed to be 100% waterproof. This allows for convenient use in the shower or bath and enables easy, thorough cleaning under running water. The robust waterproof construction ensures reliability and longevity.



High-Performance Battery & Quick Charge

Equipped with a high-performance lithium-ion battery, the shaver provides up to 50 minutes of continuous cordless operation on a single full charge. Additionally, a quick 5-minute charge is sufficient for one full shave, perfect for those unexpected busy mornings when you've forgotten to charge your device.

	72-C7500cc	62-B7200cc	52-M1200s
BRAUN 比較表			
密着性	究極の密着性 360°密着システム + 3連密着ブレード	スイング 密着システム + 3連密着ブレード	3連密着ブレード
シェービングモード	3つのモード ターボ スタンダード ジェントル	ターボ ジェントル	ターボ スタンダード
早剃り	新ターボモード 搭載	新ターボモード 搭載	新ターボモード 搭載
水洗い / お風呂ぞり	○	○	○
充電 / 連続稼働	1時間 / 最大50分	1時間 / 最大50分	1時間 / 最大50分

Artificial Intelligence Technology

The shaver features Artificial Intelligence Technology that automatically adjusts power based on your beard density. This ensures optimal shaving performance and comfort, adapting to various beard types for an efficient and gentle shave.

SETUP

Before first use, ensure the shaver is fully charged. Connect the charging cord to the shaver and plug it into a power outlet. The battery indicator on the shaver will show the charging status. A full charge typically takes about 1 hour, providing up to 50 minutes of shaving time. For quick use, a 5-minute charge provides enough power for one shave.

If your model includes a cleaning station, refer to its separate instructions for setup and initial use.

OPERATING INSTRUCTIONS

- Power On/Off:** Press the power button to turn the shaver on or off.
- Selecting Shaving Mode:** Below the power button, there is a switch to select your preferred shaving mode:
 - **Turbo Mode:** For a faster, more powerful shave, ideal for dense beards or when time is limited.

- **Standard Mode:** Optimized power for daily shaving.
 - **Gentle Mode:** For a milder shave, suitable for sensitive skin or lighter beard growth, and to extend battery life.
3. **Shaving Technique:** For best results, hold the shaver at a right angle (90°) to your skin and shave against the direction of beard growth. Stretch your skin with your free hand to ensure a close shave, especially in difficult areas like the neck and jawline.
 4. **Wet & Dry Use:** The shaver can be used dry, with foam, gel, or in the shower. For a refreshing shave, apply shaving foam or gel before use.

MAINTENANCE

Regular cleaning and maintenance are crucial for optimal performance and longevity of your Braun Series 7 shaver.

- **Daily Cleaning:** After each use, turn off the shaver and rinse the shaver head under warm running water. You can also use a small amount of liquid soap. For a more thorough clean, remove the shaver head and rinse both the head and the underlying cutting elements.
- **Deep Cleaning (with Cleaning Station):** If your model includes a cleaning station, place the shaver in the station after each shave. The cleaning station will automatically clean, lubricate, dry, and charge your shaver, ensuring hygienic and peak performance.
- **Lubrication:** Periodically, apply a drop of light machine oil (e.g., Braun shaver oil) to the shaver head to maintain smooth operation of the cutting elements.
- **Replacing Shaver Parts:** The shaver foil and cutter block are precision parts that wear out over time. For optimal performance, it is recommended to replace them every 18 months. Replacement parts are available from authorized Braun retailers.

TROUBLESHOOTING

If you encounter any issues with your Braun Series 7 shaver, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes for a quick shave, or fully charge for up to 50 minutes of use.
Poor shaving performance.	Shaver head/cutter block is worn or dirty.	Clean the shaver head thoroughly. If performance does not improve, replace the shaver foil and cutter block.
Shaver makes unusual noise.	Shaver head is not properly attached or is damaged.	Ensure the shaver head is securely attached. If damaged, replace it.
Battery life is shorter than expected.	Frequent use of Turbo mode or aging battery.	Try using Gentle mode more often. If the issue persists after several full charge cycles, the battery may be nearing the end of its lifespan.

If the problem persists after trying these solutions, please contact Braun customer support.

SPECIFICATIONS

Feature	Detail
Model Name	72-C1500s
Brand	Braun
Power Source	Battery Powered
Battery Type	Lithium-ion
Battery Life	Up to 50 minutes (continuous operation)
Quick Charge	5 minutes for one shave
Number of Blades	3
Blade Material	Titanium
Waterproof	100% waterproof (wet & dry use, washable)
Recommended Uses	Beard, Moustache, Face
Product Weight	0.51 kg
Package Dimensions	25.2 x 13.8 x 6.8 cm

SAFETY INFORMATION

WARNING:

- Keep out of reach of children.
- When consulting a doctor, bring the product container or label.
- Keep away from heat, sparks, open flames, and hot objects that are easily ignitable.
- If wearing contact lenses, remove them as much as possible before cleaning the shaver.
- If cleaning solution (if applicable to your model's cleaning station) spills, wipe it up immediately.
- In case of eye contact with cleaning solution: Rinse thoroughly with water for several minutes.
- Do not smoke nearby when handling cleaning solutions or charging the device.

Always read the full instruction manual provided with your product for complete safety guidelines.

WARRANTY AND SUPPORT

Braun products are manufactured to the highest quality standards. This product comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage.

For customer support, service, or to purchase replacement parts, please visit the official Braun website or contact your local Braun service center. You can find contact information on the Braun website or in your product's packaging.

Online resources and FAQs may also be available on the Braun official website: www.braun.com

