

[manuals.plus](#) /

› [MoKo](#) /

› [MoKo Case for Samsung Galaxy Tab A9+ 11" 2023 - Instruction Manual](#)

MoKo P840401414033

MoKo Case for Samsung Galaxy Tab A9+ 11" 2023 - Instruction Manual

Model: P840401414033

1. INTRODUCTION

This instruction manual provides detailed information on the features, setup, operation, and maintenance of your MoKo Slim Hard Back Shell Protective Cover Case for the Samsung Galaxy Tab A9+ 11-inch 2023 Release (Models: SM-X210/SM-X216/SM-X218). This case is designed to offer robust protection and enhanced functionality for your tablet. Key features include a durable PU leather exterior, soft lining, hard PC back for drop protection, multiple viewing angles, and an auto wake/sleep function.

2. COMPATIBILITY AND SETUP

This case is specifically designed for the **Samsung Galaxy Tab A9 Plus 11-Inch 2023 Release**. Please verify your tablet's model number to ensure compatibility. Compatible models are: **SM-X210, SM-X216, SM-X218**. This case is not compatible with other tablet models, including Galaxy Tab S9 or Galaxy Tab S9 FE.



Compatible with

Galaxy Tab A9+ 11" 2023



Galaxy Tab A9+ 11" 2023

SM-X210

SM-X216

SM-X218



Galaxy Tab S9 11" 2023

SM-X710 (Wi-Fi)

SM-X716B (5G Global)

SM-X718U (5G US)



Galaxy Tab S9 FE 10.9" 2023

SM-X510

SM-X516

SM-X518



Image: Compatibility chart for MoKo case with Samsung Galaxy Tab A9+ 11" 2023 models.

2.1 How to Find Your Tablet Model Number

1. Go to your tablet's "Settings".
2. Click on "About tablet".
3. Click "Model number" to view your device's specific model.

Keep Up with Modern Trends



Image: Steps to locate your tablet's model number.

2.2 Case Installation

1. Gently align your Samsung Galaxy Tab A9+ with the case's hard PC back shell.
2. Press the tablet firmly into the case, ensuring all corners are securely seated.
3. Verify that all ports, buttons, and the camera are aligned with the case's precise cutouts.



Image: MoKo case in pink, demonstrating its form factor and stand capability.

3. OPERATING INSTRUCTIONS

3.1 Viewing Stand Functionality

The MoKo case features two non-slip grooves that allow you to prop up your tablet at different viewing angles. This is ideal for watching videos, typing, or browsing the web hands-free.

1. Fold the front cover back to form a triangular stand.
2. Place the edge of your tablet into one of the two non-slip grooves on the inside of the cover to achieve your desired viewing angle.

Stand Your Way

Enjoy hands-free viewing
in comfort



2 Angles



Non-slip
Grooves



Image: The case configured for two different viewing angles.




Image: User interacting with the tablet in stand mode.

3.2 Auto Wake/Sleep Function

The case features a strong magnetic strip that supports the auto wake/sleep function of your tablet. This helps conserve battery life.

- Opening the cover will automatically wake your tablet.
- Closing the cover will automatically put your tablet to sleep.



Precise Cutouts



Smooth Charging



Unimpeded Operation

Auto Wake / Sleep

Save energy and prolong standby time.



Image: Demonstration of the auto wake/sleep feature.

3.3 Access to Ports and Buttons

The case is designed with precise cutouts to ensure full and unimpeded access to all buttons, ports, sensors, speakers, and cameras of your Samsung Galaxy Tab A9+.

Video: This video demonstrates the precise cutouts for buttons and ports, and the auto wake/sleep function of the MoKo case for Galaxy

4. MAINTENANCE

To ensure the longevity and appearance of your MoKo case, follow these simple maintenance guidelines:

- Cleaning:** Wipe the exterior PU leather with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- Storage:** Store the case in a cool, dry place away from direct sunlight when not in use for extended periods.
- Handling:** While the case offers protection, avoid unnecessary drops or impacts to maximize its lifespan and protect your device.

Image: Detailed view of the case's construction materials.

5. TROUBLESHOOTING

If you encounter any issues with your MoKo case, please refer to the following common solutions:

- Case does not fit:** Double-check your tablet's model number (SM-X210/SM-X216/SM-X218) against the compatibility information in Section 2. Ensure the tablet is correctly aligned and gently pressed into the case.
- Auto Wake/Sleep not working:** Ensure the tablet is fully seated in the case and the magnetic strip on the cover is making proper contact with the tablet's sensor. Some tablet settings may also affect this feature; check your tablet's display settings for "Smart Cover" or "Magnetic Cover" options.
- Difficulty accessing ports/buttons:** Confirm the tablet is correctly installed and aligned within the case. The precise cutouts should allow full access. If not, re-seat the tablet.

6. SPECIFICATIONS

Feature	Detail
Brand	MoKo
Model Number	P840401414033
Compatibility	Samsung Galaxy Tab A9+ 11-inch 2023 (SM-X210/SM-X216/SM-X218)
Material	Premium PU Leather Exterior, Soft Lining, Hard PC Back
Color	Pink
Product Dimensions	10.31 x 6.93 x 0.47 inches
Item Weight	11.1 ounces
Features	Viewing Stand (2 angles), Auto Wake/Sleep, Precise Cutouts, Drop Protection

7. WARRANTY AND SUPPORT

MoKo stands behind the quality of its products. For specific warranty information, please refer to the packaging or visit the official MoKo website. For any product-related inquiries, technical support, or assistance, please contact MoKo customer service.



Image: MoKo customer service is available for support.

You can also visit the [MoKo Store on Amazon](#) for more products and information.

© 2023 MoKo. All rights reserved.