

Hespéride 3560232952975

Hespéride Melhia Rectangular Offset Parasol 4x3m Instruction Manual

Model: 3560232952975

Brand: Hespéride

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Hespéride Melhia Rectangular Offset Parasol. Please read all instructions carefully before use to ensure safe and optimal performance.

SAFETY INFORMATION

- Always ensure the parasol base is adequately weighted with suitable paving slabs (sold separately) to prevent tipping.
- Fold and secure the parasol in windy conditions to prevent damage or injury.
- Do not use the parasol during storms, heavy rain, or strong winds.
- Keep children and pets away from the parasol during opening and closing operations.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x Parasol canopy
- 1 x Parasol frame (pole, arms)
- 1 x Cross base
- Assembly hardware (screws, bolts, tools if included)
- Instruction manual

SETUP AND ASSEMBLY

Assembly instructions are provided with the product. Follow these steps carefully.

1. Unpack all components and lay them out on a clean, flat surface.
2. Assemble the cross base. Ensure all connections are secure.
3. Attach the main pole to the assembled cross base. Tighten all fasteners.
4. Securely place appropriate weighting slabs onto the cross base (not included). This is crucial for stability.
5. Carefully attach the parasol canopy and arm assembly to the main pole.
6. Ensure all locking mechanisms are engaged before attempting to open the parasol.



The cross base provides stability and must be weighted with suitable paving slabs (sold separately) before use.



This image shows the crank handle used for opening and closing the parasol, and the lever for adjusting the tilt.

OPERATING INSTRUCTIONS

Opening the Parasol

To open the parasol, locate the crank handle on the main pole. Turn the handle clockwise until the canopy is fully extended. Do not force the crank once the canopy is fully open.

Closing the Parasol

To close the parasol, turn the crank handle counter-clockwise until the canopy is fully retracted. Secure any ties or straps to keep the canopy neatly folded.


360° Rotation

The parasol features a 360° rotating base. To rotate, loosen the locking mechanism at the base of the pole, adjust

the parasol to the desired position, and then re-tighten the locking mechanism to secure it.

Tilt Function

To tilt the parasol canopy, use the tilt lever or button located on the main pole (refer to the crank mechanism image). Adjust the angle to block the sun as it moves throughout the day. Ensure the tilt mechanism is securely locked after adjustment.



This view from underneath the canopy shows the robust frame structure that supports the Olefin fabric.



A top-down perspective of the rectangular canopy, illustrating its multi-fabric design which aids in air circulation and wind resistance.

MAINTENANCE

- **Cleaning:** Wipe the aluminum frame with a damp cloth. For the Olefin canopy, clean with mild soap and water, then rinse thoroughly and allow to air dry completely before folding.
- **Storage:** During winter months or extended periods of non-use, it is recommended to fold the parasol and protect it with a compatible cover. Store in a dry, sheltered location.
- **Inspection:** Periodically check all screws, bolts, and moving parts for tightness and proper function. Lubricate moving parts if necessary.

TROUBLESHOOTING

Parasol is unstable:


- Ensure the base is adequately weighted with paving slabs.
- Check that all assembly fasteners are securely tightened.
- Fold the parasol in windy conditions.

Canopy does not open/close smoothly:

- Check for any obstructions in the mechanism or canopy fabric.
- Ensure the crank handle is not jammed.
- Lubricate moving parts if resistance is felt.

SPECIFICATIONS

Feature	Detail
Model	3560232952975
Dimensions (L x W x H)	400 x 300 x 272 cm (4 x 3 x 2.72 meters)
Weight	25 kg
Frame Material	Aluminum with epoxy treatment
Canopy Material	Olefin fabric
Color	Beige Lin
Rotation	360°
Tilt Function	Yes
Assembly Required	Yes
Special Features	Multi-fabric design for air circulation, wind-resistant



A detailed diagram illustrating the key dimensions of the parasol, including its length, width, and overall height.

WARRANTY AND SUPPORT

Specific warranty information is not provided in this manual. Please refer to your purchase documentation or contact Hespéride customer service for details regarding warranty coverage and support.

For further assistance, please visit the official Hespéride website or contact your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question