

Logitech MK950

Logitech MK950 Signature Slim Wireless Keyboard and Mouse Combo User Manual

Model: MK950 | Part Number: 920-012488

1. INTRODUCTION

The Logitech MK950 Signature Slim Wireless Keyboard and Mouse Combo provides a versatile and efficient input solution for multiple devices. Designed for quiet operation and extended battery life, this combo enhances productivity across various operating systems.



Image: The Logitech MK950 Signature Slim Wireless Keyboard and Mouse Combo, showcasing both the keyboard and mouse in Graphite Grey.

2. SETUP

2.1 Unpacking and Initial Power-Up

Upon unboxing, ensure all components are present: the wireless keyboard, wireless mouse, and Logi Bolt USB receiver. The keyboard and mouse come with pre-installed AAA batteries. Remove any protective tabs from the battery compartments to activate them.




Image: A hand opening the battery compartment of the Logitech MK950 keyboard, revealing the pre-installed batteries and a storage slot for the Logi Bolt USB receiver.

2.2 Connectivity Options

The MK950 combo offers two primary connection methods:

1. **Logi Bolt USB Receiver:** Plug the Logi Bolt USB receiver into an available USB port on your computer. The keyboard and mouse are pre-paired with the receiver for immediate use.
2. **Bluetooth:** For devices without a USB port or to free up a port, connect via Bluetooth. Activate Bluetooth on your device and follow the pairing instructions in your device's settings. The keyboard and mouse feature Easy-Switch buttons to manage connections across up to three devices.

3. OPERATING INSTRUCTIONS

3.1 Keyboard Operation

The K950 Signature Slim keyboard provides a familiar typing experience similar to a laptop. It includes a full numeric keypad and dedicated media keys for convenience.

3.2 Mouse Operation

The M750 Signature Plus wireless mouse features SilentTouch technology, reducing click sounds by 90% for a quieter work environment. The SmartWheel allows for precise line-by-line scrolling or fast scrolling through long documents and web pages.




Image: The Logitech M750 Signature Plus wireless mouse, highlighting its ergonomic design and scroll wheel.

3.3 Multi-Device Switching

Both the keyboard and mouse are equipped with Easy-Switch buttons, allowing you to seamlessly switch between up to three connected devices (e.g., laptop, tablet, smartphone) with a single tap.



Image: A hand demonstrating the multi-device switching function on the Logitech MK950 keyboard, with numbered keys indicating different device connections.

4. CUSTOMIZATION

Enhance your workflow by customizing keys, buttons, and shortcuts using the Logi Options+ App. This application is available for Windows and macOS, providing extended possibilities for personalized control over your wireless mouse and keyboard.

5. BATTERY LIFE AND MAINTENANCE

The keyboard offers up to 36 months of battery life, while the mouse provides up to 24 months, ensuring long periods of uninterrupted use. Both devices use standard AAA alkaline batteries. Replace batteries when the low battery indicator illuminates.

5.1 Replacing Batteries

To replace batteries, open the designated battery compartment on the underside of the device. Insert new AAA batteries, ensuring correct polarity, and close the compartment securely.

5.2 Cleaning

To clean the keyboard and mouse, use a soft, damp cloth. Avoid harsh chemicals or abrasive materials that could damage the surfaces.

6. COMPATIBILITY

The Logitech MK950 Signature Slim combo is compatible with a wide range of operating systems, including:

- Windows 10, 11 or later
- macOS 11 or later
- Chrome OS
- Linux
- iPadOS and iOS 14 or later
- Android 9.0 or later

7. SPECIFICATIONS

Feature	Detail
Brand	Logitech
Model Number	920-012488
Connectivity Technology	Bluetooth, Logi Bolt USB Receiver
Keyboard Description	Membrane
Movement Detection Technology	Optical
Hand Orientation	Ambidextrous

Special Features	Connect up to three devices, Noiseless Clicks, Programmable Buttons, Shortcuts & Media Buttons, Smartwheel
Power Source Type	Battery Powered (2 AAA batteries included)
Material	Plastic parts include certified recycled consumer plastic (minimum 48% for keyboard, 25% for mouse)

8. TROUBLESHOOTING

8.1 Connection Issues

- **Ensure Power:** Check that the keyboard and mouse are powered on and have sufficient battery life.
- **Receiver Check:** If using the Logi Bolt receiver, ensure it is securely plugged into a working USB port. Try a different USB port if necessary.
- **Bluetooth Pairing:** For Bluetooth connections, verify that Bluetooth is enabled on your device and the keyboard/mouse are in pairing mode. Re-initiate the pairing process if connection is lost.
- **Easy-Switch:** Confirm that the correct Easy-Switch channel (1, 2, or 3) is selected on both the keyboard and mouse for the device you intend to use.

8.2 Unresponsive Keys/Clicks

- **Battery Replacement:** Replace batteries in both devices, even if the indicator light is not yet active.
- **Interference:** Move the devices closer to the receiver or Bluetooth-enabled computer to minimize potential wireless interference.
- **Software Update:** Ensure the Logi Options+ App and your operating system are up to date.

9. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Logitech website or contact Logitech customer service. Product registration may be required to activate your warranty.
