

EasyKeys EB079

Lori EB079 Office Furniture Replacement Key

User Manual

PRODUCT OVERVIEW

This manual provides essential information for the proper identification and use of your Lori EB079 series replacement key. This key is designed for specific office furniture locks, including cabinet and drawer locks, often associated with LORI (GCODE/FRAMON) or EAGLE systems.



Figure 1: A representative image of a Lori EB series key. The image displays an 'EB001' key, illustrating the typical appearance and the location of the stamped code, which is crucial for identifying your specific EB079 replacement key.

SETUP AND KEY IDENTIFICATION

Before attempting to use your new key, it is critical to ensure you have the correct key for your specific lock. The Lori EB079 key series is part of a larger range (EB001-EB240), and each key is unique to its corresponding lock code.

Identifying the Correct Key:

- 1. Locate the Lock Code:** The lock code is the primary identifier for your key. This code is typically stamped on one of the following locations:
 - Your original key (if available).

- The face of the lock cylinder itself.

Example: If your lock or original key has "EB079" stamped on it, then the EB079 replacement key is the correct one.

2. **Verify Key Blank:** This replacement key is cut on an O1014S key blank, which is compatible with LORI (GCODE/FRAMON) and EAGLE cabinet/drawer locks.
3. **Match the Code:** Ensure the code on your new replacement key precisely matches the code found on your lock or original key. Using an incorrect key can damage the lock mechanism.

OPERATING INSTRUCTIONS

Once you have confirmed you have the correct key, operating your lock is straightforward.

1. **Insert the Key:** Gently insert the key into the keyway of the lock cylinder. Do not force the key. It should slide in smoothly if it is the correct key and the lock is not obstructed.
2. **Turn the Key:** Once fully inserted, turn the key clockwise or counter-clockwise (depending on the lock mechanism) to engage or disengage the lock. You should feel a distinct click or resistance as the lock mechanism operates.
3. **Remove the Key:** After the lock has been operated, return the key to its original insertion position (usually vertical) and gently pull it out.

Note: If the key does not turn easily, do not force it. Refer to the Troubleshooting section.

MAINTENANCE

Proper care of your key and lock can extend their lifespan and ensure smooth operation.

- **Keep Clean:** Periodically wipe the key with a soft, dry cloth to remove any dirt or debris. Avoid using abrasive cleaners or solvents.
- **Avoid Bending:** Store the key in a way that prevents it from bending or being damaged. A bent key may not fit into the lock or could damage the lock mechanism.
- **Lubrication (Lock):** If the lock mechanism becomes stiff, a small amount of graphite lubricant (specifically designed for locks) can be applied to the keyway. Avoid oil-based lubricants as they can attract dust and gum up the mechanism.
- **Proper Storage:** Store spare keys in a secure, dry location to prevent loss or corrosion.

TROUBLESHOOTING

If you encounter issues with your replacement key, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Key does not insert fully.	Incorrect key; debris in keyway; bent key.	Verify lock code match. Check keyway for obstructions. Inspect key for damage.
Key inserts but does not turn.	Incorrect key; lock mechanism jammed; internal lock damage.	Confirm key code. Apply lock lubricant. If issue persists, the lock may require professional service or replacement.
Key is difficult to remove.	Lock mechanism not fully disengaged; key slightly bent.	Ensure lock is fully operated. Gently wiggle key while pulling. Do not force.

SPECIFICATIONS

- **Model:** EB079
- **Key Series:** Lori EB001-EB240
- **Manufacturer:** Lori
- **Brand:** EasyKeys
- **ASIN:** B0CTQR45MN
- **Item Weight:** 0.247 ounces (approx. 7 grams)
- **Date First Available:** February 1, 2024

SUPPORT

For further assistance or inquiries regarding your Lori EB079 replacement key, please contact the seller, EasyKeys Inc., through the platform where the purchase was made. Provide your order details and the specific lock code for efficient support.

You can visit the [EasyKeys Store on Amazon](#) for more information on their products.

© 2024 EasyKeys. All rights reserved.