


## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Retevis](#) /
- › [Retevis RE3120 C-Type 2-Pin Walkie Talkie Earphone Instruction Manual](#)

## Retevis EUJ9118A



## INTRODUCTION

This manual provides detailed instructions for the Retevis RE3120 C-Type 2-Pin Walkie Talkie Earphone. This earphone is designed to enhance communication privacy and clarity when used with compatible two-way radios. It features a comfortable C-type design, a Push-to-Talk (PTT) button for easy operation, and a rotatable earhook for versatile wear.

## PRODUCT OVERVIEW

### Key Features

- C-Type Earphone Design:** Adapts comfortably to your ear, ensuring private and clear communication.
- Push-to-Talk (PTT) Button:** Enables one-click calls, allowing for hands-free operation.
- 360° Rotatable Earhook:** Can be worn on either the left or right ear for maximum comfort and flexibility.
- Integrated Cable Clip:** Allows the earphone cable to be securely attached to clothing.
- Wide Compatibility:** Compatible with 2-pin radios such as Retevis RT24, RT27, RT28, RT22, RT617, RT618, RT619, Baofeng BF-888S, BF-88E, and Kenwood models.

### Components

The Retevis RE3120 earphone consists of the following main components:

- 2-Pin K-Type Connector:** For connecting to compatible two-way radios.
- Push-to-Talk (PTT) Button:** Activates the microphone for transmission.
- Microphone (MIC):** Captures your voice for transmission.
- C-Type Earhook:** Holds the earphone securely on your ear.
- Earbud:** Delivers audio to your ear.
- Cable Clip:** For securing the cable to clothing.



Figure 1: Retevis RE3120 Earphone Components

## SETUP

1. **Connect to Radio:** Insert the 2-pin K-type connector firmly into the earphone jack of your compatible two-way radio. Ensure a secure connection.

Compatible Most Walkie Talkies with K Head Plug,such as:

Retevis RT24 RT27 RT22 RT28 RT46 RT15 RT21

Baofeng BF-888S BF-88E

Kenwood etc.



Figure 2: Connecting the Earphone to a Radio

2. **Position the Earhook:** Place the C-type earhook over your ear. The earhook is designed to rotate 360 degrees, allowing you to adjust it for a comfortable fit on either your left or right ear. Adjust the earhook up or down as needed.



Left Ear



Right Ear



360 ° rotatable earhook

Adjustable earhook up and down

Figure 3: Earhook Adjustment



## 360° Revolvable Ear Hook

This C type walkie talkie earpiece is ergonomically designed to fit the auricle. The ear hook can rotate 360 degrees, fits right and left ears.

Figure 4: Earphone Worn on Ear

3. **Secure the Cable:** Use the integrated clip on the cable to attach it to your clothing (e.g., collar, pocket) to prevent tangling and ensure stability during movement.

Featured with a plastic clip, you can clip it on your clothes.



Figure 5: Using the Cable Clip

## OPERATING INSTRUCTIONS

- Receiving Audio:** Once connected, audio from your radio will be transmitted directly to the earphone. Adjust the radio's volume for comfortable listening.
- Transmitting (Push-to-Talk):** To speak, press and hold the PTT button located on the cable. Speak clearly into the microphone. Release the PTT button when you have finished speaking to return to receive mode.

## MAINTENANCE

- Cleaning:** Gently wipe the earphone and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Store the earphone in a clean, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tangling the cable.
- Water Resistance:** This earphone is **not water resistant**. Avoid exposure to water or excessive moisture.

## TROUBLESHOOTING

### No Audio from Earphone:

- Ensure the 2-pin connector is fully inserted into the radio's jack.
- Check the radio's volume level.
- Test the earphone with another compatible radio if possible to rule out a radio issue.

### Unclear or Distorted Audio:

- Verify the connection to the radio is secure.
- Adjust the radio's squelch level if applicable.
- Ensure the earbud is clean and free of debris.

### PTT Button Not Functioning:

- Confirm the earphone is correctly connected to the radio.
- Ensure the radio is powered on and in an active channel.

## SPECIFICATIONS

<b>Model Number</b>	EUJ9118A
<b>Brand</b>	Retevis
<b>Material</b>	Plastic, Silicone, Foam
<b>Connectivity Technology</b>	Wired
<b>Connector Type</b>	2-Pin K-Type, 3.5 mm Audio Jack
<b>Control Method</b>	Push Button (PTT)
<b>Water Resistance Level</b>	Not Water Resistant
<b>Product Weight</b>	45 g
<b>Package Dimensions</b>	15 x 12 x 1.7 cm
<b>Compatible Devices</b>	Retevis RT24, RT27, RT28, RT22, RT617, RT618, RT619, Baofeng BF-888S, BF-88E, Kenwood (2-pin models)

## Long and durable cable

Diameter: 2cm

20cm

Diameter: 3cm

89cm



Figure 6: Earphone Cable Dimensions

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the

official Retevis website. You can also visit the [Retevis Brand Store on Amazon](#) for additional product information and support resources.

© 2024 Retevis. All rights reserved.