

sweeek ICHICSOFACRVVGY

sweeek 2-Seater Corduroy Convertible Sofa Bed Instruction Manual

Model: ICHICSOFACRVVGY

1. INTRODUCTION

Thank you for choosing the sweeek 2-Seater Corduroy Convertible Sofa Bed. This versatile furniture piece is designed to offer comfort and functionality, transforming effortlessly between a sofa, a banquette, and a bed. This manual provides essential information for safe assembly, operation, and maintenance to ensure long-lasting enjoyment of your product.

2. SAFETY INSTRUCTIONS

- Keep away from open flames or high heat sources.
- Do not tumble dry or use bleach on the fabric.
- Supervise children and pets to prevent entrapment risks when using the convertible function and retractable legs.
- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight limit of 110 kg.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Convertible Sofa Frame
- Seat Cushions
- Back Cushions (2 rectangular cushions included)
- Retractable Legs (pre-installed or separate)
- Assembly Hardware (screws, Allen key)



Image: The sweeck 2-Seater Corduroy Convertible Sofa Bed in its standard sofa configuration, showcasing its corduroy fabric and included cushions.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended that two people assemble the sofa bed. A screwdriver is the recommended tool.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Securely attach the furniture legs to the base of the sofa sections. Ensure they are tightened properly.
3. **Connect Sofa Sections:** Align the main sofa sections and connect them using the provided hardware. Ensure a snug fit.
4. **Install Retractable Mechanism:** If not pre-installed, attach the retractable bed mechanism according to the diagrams. Ensure smooth operation.
5. **Place Cushions:** Position the seat and back cushions onto the sofa frame.



Image: Detail of the retractable mechanism that allows the sofa to convert into a bed.

5. OPERATING INSTRUCTIONS

Your sweeek convertible sofa bed offers three positions: sofa, banquette, and bed.

5.1. Converting to Bed Position

1. Remove all cushions from the sofa.
2. Locate the pull-out handles or straps at the front of the sofa base.
3. Gently pull the base outwards. The retractable legs behind the backrest will extend automatically as the bed mechanism unfolds.
4. Ensure the bed is fully extended and stable before use.



Image: The sofa in a transitional state, with the bed mechanism partially extended.



Image: The sweeek sofa fully transformed into a comfortable bed.

5.2. Converting to Banquette Position

The banquette position typically involves adjusting the backrest to a reclined angle, often achieved by pushing the backrest slightly forward and then reclining it to the desired position until it locks.

5.3. Returning to Sofa Position

1. Ensure the bed is clear of any obstructions.
2. Lift the front section of the bed slightly and push it inwards towards the sofa base. The retractable legs will fold back into place.
3. Push until the mechanism is fully retracted and the sofa base is flush.
4. Replace the cushions.

6. MAINTENANCE AND CARE

- **Cleaning:** Do not wash. Do not use bleach. Do not tumble dry. Iron at high temperature. Professional dry cleaning (moderate process with restrictions) is recommended.
- **Fabric Care:** The corduroy velvet fabric has a soft, velvety texture with vertical ribs. Regularly vacuum with a soft brush attachment to remove dust and debris.

- **Frame Care:** Periodically check all screws and connections to ensure they remain tight.
- **Cushion Care:** Fluff cushions regularly to maintain their shape and comfort.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sofa bed mechanism is stiff or difficult to operate.	Mechanism may need lubrication or is misaligned.	Ensure no obstructions. Apply a silicone-based lubricant to moving parts. Check for proper alignment during conversion.
Sofa feels unstable.	Loose legs or connecting hardware.	Check and tighten all leg and frame connection screws.
Cushions losing shape.	Normal wear and tear; lack of fluffing.	Regularly fluff and rotate cushions to maintain their form.

8. SPECIFICATIONS

Brand:	sweeek
Model Number:	ICHICSOFACRVVGY
Type:	Convertible Sofa Bed
Seating Capacity:	2 people (3 positions: sofa, banquette, bed)
Color:	Grey
Upholstery Material:	Corduroy Velvet
Frame Material:	Metal
Seat Filling Material:	Foam (6.2cm recycled foam (50kg/m ³) + 1cm new foam (16kg/m ³))
Backrest Filling Material:	Foam (6.2cm recycled foam (50kg/m ³) + 1cm new foam (16kg/m ³))
Armrest Filling Material:	New foam (16kg and 22kg/m ³)
Cushion Filling Material:	100% Polyester
Product Dimensions (Sofa):	L 172.5 x D 91.5 x H 88.5 cm
Sleeping Dimensions (Bed):	L 180 x W 138 cm (Thickness: 17 cm)
Seat Depth:	50 cm
Seat Height:	44 cm
Net Weight:	65 kg
Weight Limit:	110 kg
Assembly Required:	Yes (Recommended 2 people)
Recommended Tools:	Screwdriver



Image: Detailed dimensions of the sofa bed in its sofa configuration.




Image: Detailed dimensions of the sofa bed when fully converted into a bed.

9. WARRANTY AND SUPPORT

This product comes with a limited warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or contact sweeek customer support.

For any questions, missing parts, or assistance with assembly or operation, please contact sweeek customer support. Contact information can typically be found on the product packaging or the official sweeek website.

