

[Manuals.plus](#) /

> [FORLIGHT](#) /

> FORLIGHT Nere Ceiling Fan with LED Light and Temperature Selector User Manual

FORLIGHT Nere

FORLIGHT Nere Ceiling Fan User Manual

Model: Nere

1. INTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your FORLIGHT Nere Ceiling Fan. Please read these instructions thoroughly before installation and retain them for future reference.

Ventilador de techo Nere

Diseñado
para cuidar
tu bienestar



Image 1.1: The FORLIGHT Nere Ceiling Fan, designed for comfort and well-being.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the main power supply is disconnected before installation, maintenance, or cleaning.
- Installation must be performed by a qualified electrician in accordance with local electrical codes.
- The mounting structure must be capable of supporting the fan's weight (approximately 6.2 kg).
- Do not insert objects into the fan blades while the fan is operating.

- Keep children and pets away from the fan during operation.
- Ensure all connections are secure and properly insulated.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Unit with Integrated LED Light
- 3 FSC Certified Wooden Blades
- Remote Control
- Mounting Bracket
- Downrods (12.5 cm and 25 cm for adjustable height)
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

4. PRODUCT OVERVIEW

The FORLIGHT Nere Ceiling Fan combines efficient air circulation with integrated LED lighting, designed for modern living spaces. It features a silent DC motor and natural wooden blades.



Image 4.1: Front view of the FORLIGHT Nere Ceiling Fan with its three natural wooden blades.

Multifunciones



Un aliado todo en uno para tu **comodidad durante todo el año**. Un ventilador que no solo refresca, simplifica tu día a día con sus **múltiples prestaciones**.

Motor DC



Ultra silencioso



Image 4.2: Key features including the ultra-silent DC motor and integrated LED light.

Con luz LED integrada



Con intensidad y temperatura de color regulables



Image 4.3: The integrated LED light offers adjustable intensity and color temperature (3000K, 4200K, 6200K).

5. SETUP AND INSTALLATION

Follow these general steps for installation. Refer to the detailed diagrams in the included printed manual for specific instructions.

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting location is structurally sound.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling junction box using appropriate hardware.
3. **Assemble Downrod:** Choose the desired downrod length (12.5 cm or 25 cm) and attach it to the motor unit.
4. **Wire Connections:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the printed manual. Ensure all connections are secure.
5. **Mount Fan:** Carefully lift the fan assembly and hang it on the mounting bracket.
6. **Attach Blades:** Securely attach the three wooden blades to the motor unit.
7. **Final Checks:** Ensure all screws are tightened and the fan is stable. Restore power.



Image 5.1: The fan includes two downrod lengths (12.5 cm and 25 cm) for customizable height. Blades are made from FSC certified natural wood.

6. OPERATING INSTRUCTIONS

The FORLIGHT Nere Ceiling Fan is controlled via the included remote control.



Image 6.1: The FORLIGHT Nere Ceiling Fan and its remote control.



Image 6.2: Remote control showing 6 speed settings and programmable timer options.

Remote Control Functions:

- **Power Button:** Turns the fan and light ON/OFF.
- **Fan Speed (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **Light ON/OFF:** Toggles the LED light on or off independently.
- **Light Color Temperature:** Cycles through 3 color temperatures: Warm White (3000K), Neutral White (4200K), Cool White (6200K).
- **Timer (1H, 2H, 4H, 8H):** Sets the fan to automatically turn off after 1, 2, 4, or 8 hours.
- **Reverse Mode (Winter/Summer):** Changes the direction of blade rotation.

Seasonal Operation:




Image 6.3: Illustration of airflow in summer and winter modes.

- **Summer Mode (Downward Airflow):** Blades rotate counter-clockwise, creating a downward breeze that provides a cooling effect. This can reduce perceived temperature by up to 6°C.
- **Winter Mode (Upward Airflow):** Blades rotate clockwise, drawing cool air up and pushing warm air (which rises) down along the walls. This redistributes heated air, optimizing heating efficiency and potentially reducing energy consumption.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the fan is turned off and power is disconnected before cleaning.
- **Blade Inspection:** Check the blades for any signs of damage or warping. Replace damaged blades immediately.
- **Tighten Screws:** Periodically check and tighten all screws on the fan assembly and mounting bracket to prevent wobbling or noise.
- **No Lubrication Needed:** The DC motor is permanently lubricated and does not require additional oiling.

8. TROUBLESHOOTING

If you encounter issues with your FORLIGHT Nere Ceiling Fan, refer to the following common problems and solutions:

- **Fan Does Not Start:**
 - Check if the power supply is connected and the circuit breaker is ON.
 - Ensure the remote control batteries are not depleted and are inserted correctly.
 - Verify all wire connections are secure.
- **Fan Wobbles:**
 - Ensure all blade screws are tightened.
 - Check that the mounting bracket is securely fastened to the ceiling.
 - Verify that the downrod is properly seated and secured.
- **Light Does Not Work:**
 - Check the light connection wires.
 - Ensure the light function on the remote control is activated.
 - The LED light is integrated and not user-replaceable. If it fails, contact customer support.
- **Remote Control Not Responding:**
 - Replace the batteries in the remote control.
 - Ensure there are no obstructions between the remote and the fan receiver.

If problems persist after attempting these solutions, contact FORLIGHT customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	FORLIGHT
Model Name	Nere
Color	White
Design	Ceiling Fan
Number of Blades	3

Feature	Specification
Blade Material	FSC Certified Wood
Motor Type	DC Motor
Integrated Light	LED (3000K, 4200K, 6200K)
Number of Speeds	6
Control Method	Remote Control
Timer Function	1, 2, 4, 8 hours
Reverse Mode	Yes (Summer/Winter)
Voltage	230V (AC)
Product Weight	6.2 kg
Dimensions (approx.)	132 x 132 cm (diameter)

10. WARRANTY AND SUPPORT

FORLIGHT products are manufactured to high-quality standards and are covered by a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official FORLIGHT website.

For technical support, replacement parts, or any inquiries regarding your FORLIGHT Nere Ceiling Fan, please contact FORLIGHT customer service through their official channels. When contacting support, please have your product model (Nere) and purchase information readily available.