

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Xbox](#) /
- › [Xbox Wireless Controller - Nocturnal Vapor Special Edition User Manual](#)

Xbox QAU-00103

Xbox Wireless Controller - Nocturnal Vapor Special Edition User Manual

Model: QAU-00103

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Xbox Wireless Controller - Nocturnal Vapor Special Edition. This controller is designed for use with Xbox Series X|S, Xbox One, and Windows devices, offering a unique aesthetic with its light and dark green color swirl. It features advanced connectivity, customizable controls, and enhanced grip for an optimal gaming experience.



Figure 1: Front view of the Xbox Wireless Controller - Nocturnal Vapor Special Edition.

2. PRODUCT FEATURES

The Xbox Wireless Controller - Nocturnal Vapor Special Edition includes several key features designed to enhance your gaming:

- **Dynamic Color Swirl:** Each controller features a unique light and dark green color swirl pattern.
- **Enhanced Grip:** Rubberized, green diamond-pattern grips on the back-case, along with textured grip on triggers, bumpers, and side caps, ensure secure handling.
- **Hybrid D-pad:** Provides precise input for directional control.
- **Dedicated Share Button:** Easily capture and share screenshots, game clips, and more.
- **Wireless and Bluetooth Technology:** Seamlessly connect to Xbox consoles, Windows PCs, mobile phones, and tablets.
- **Custom Button Mapping:** Personalize your controller settings using the Xbox Accessories app.
- **3.5mm Audio Jack:** Connect any compatible headset for immersive audio.
- **USB-C Port:** For direct plug-and-play connection to console or PC.
- **AA Battery Support:** Operates on two AA batteries, providing up to 40 hours of battery life.



Customize button mapping

Figure 2: Rubberized diamond-pattern grips for enhanced handling.



Plug in any compatible headset

Figure 3: The hybrid D-pad for precise control.



Rubberized, green diamond-pattern grips

Figure 4: 3.5mm audio jack for headset connection.

3. SETUP

3.1 Powering the Controller

The controller operates on two AA batteries (included). To install or replace batteries:

1. Remove the battery cover on the back of the controller.
2. Insert two AA batteries, ensuring correct polarity (+/-).
3. Replace the battery cover.

Alternatively, you can use a rechargeable battery pack (sold separately) or connect the controller directly via the USB-C port for power and wired play.



Figure 5: Battery compartment on the back of the controller.

3.2 Connecting to Devices

The controller supports both Xbox Wireless and Bluetooth technology for versatile connectivity.

3.2.1 Connecting to Xbox Console

1. Turn on your Xbox console.
2. Press and hold the Xbox button on your controller to turn it on.
3. Press the Pair button on your Xbox console (usually a small circular button near the USB ports).
4. Press and hold the Pair button on the top edge of your controller until the Xbox button flashes rapidly.
5. Once the Xbox button on the controller glows solid, it is connected.

3.2.2 Connecting to PC or Mobile Device (Bluetooth)

1. Ensure your PC or mobile device has Bluetooth enabled.
2. Press and hold the Xbox button on your controller to turn it on.
3. Press and hold the Pair button on the top edge of your controller until the Xbox button flashes rapidly.
4. On your PC or mobile device, go to Bluetooth settings and select the Xbox Wireless Controller from the list of available devices.

5. Once connected, the Xbox button on the controller will glow solid.



Xbox Wireless and Bluetooth technology

Figure 6: Xbox Wireless and Bluetooth connectivity.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls

The controller features standard Xbox button layouts, including A, B, X, Y buttons, a hybrid D-pad, left and right analog sticks, triggers (LT, RT), and bumpers (LB, RB).

4.2 Share Button

The dedicated Share button, located in the center of the controller, allows for quick capture and sharing of content:

- Press the Share button once to take a screenshot.

- Press and hold the Share button to record the last 30 seconds of gameplay.



Up to 40 hours of battery life*

Figure 7: The dedicated Share button for quick content capture.

4.3 Custom Button Mapping

Customize your controller's button assignments to suit your play style using the Xbox Accessories app. This app is available on Xbox consoles and Windows PCs.

1. Download and open the Xbox Accessories app.
2. Connect your controller.
3. Select your controller and follow the on-screen instructions to remap buttons and create custom profiles.



Textured grip on the triggers, bumpers, and side caps

Figure 8: Custom button mapping via the Xbox Accessories app.

5. MAINTENANCE

5.1 Battery Care


- Always use fresh, high-quality AA batteries.
- Remove batteries if the controller will not be used for an extended period to prevent leakage.
- If using a rechargeable battery pack, follow the manufacturer's instructions for charging.

5.2 Cleaning

Wipe the controller with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish or internal components.

5.3 USB-C Port

The USB-C port can be used for wired gameplay or to power the controller. Ensure the port is free of debris before connecting a cable.



Hybrid D-pad

Figure 9: USB-C port for wired connection and power.

6. TROUBLESHOOTING

6.1 Controller Not Connecting

- Ensure batteries are correctly installed and charged.
- Verify that the controller is within range of your device.
- Attempt to re-pair the controller with your device (refer to Section 3.2).
- If connecting to a PC, ensure Bluetooth drivers are up to date.

6.2 Input Lag or Disconnections

- Minimize interference by moving closer to your console/PC or reducing other wireless devices nearby.
- Ensure your controller's firmware is up to date via the Xbox Accessories app.
- Try connecting the controller directly via a USB-C cable to rule out wireless issues.

7. SPECIFICATIONS

Feature	Detail
Model Number	QAU-00103
ASIN	B0CTS4LGFZ
Product Dimensions	2.83 x 7.01 x 6.97 inches
Item Weight	14.4 ounces
Connectivity	Xbox Wireless, Bluetooth, USB-C
Power Source	2 AA batteries (included)
Battery Life	Up to 40 hours (with AA batteries)
Manufacturer	Microsoft
Language	English

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Xbox support website. Keep your proof of purchase for warranty claims.