

[Manuals.plus](#) /

> [ZEZEFUFU](#) /

> ZEZEFUFU Blade Slide Holder for WAHL Hair Clippers (Models 1919/8504) - Instruction Manual

ZEZEFUFU Blade Slide Holder

ZEZEFUFU Blade Slide Holder for WAHL Hair Clippers (Models 1919/8504) - Instruction Manual

1. PRODUCT OVERVIEW

The ZEZEFUFU Blade Slide Holder is a replacement component designed for specific WAHL hair clipper models, including the 1919 and 8504. Crafted from gold-plated metal, this part ensures durability and resistance to rust, contributing to the longevity of your clipper's performance. It facilitates the proper movement and alignment of the clipper blades, which is essential for effective hair cutting.



Figure 1: The ZEZEUFU Blade Slide Holder, a gold-plated metal component.

2. SAFETY INFORMATION

- Always disconnect the hair clipper from its power source before attempting any installation, removal, or maintenance.
- Handle sharp clipper blades with care to prevent injury.
- Keep small parts, such as screws, out of reach of children.
- Ensure all components are correctly installed and secured before operating the clipper.

3. PACKAGE CONTENTS

Verify that your package contains the following items:

- 1x ZEZEUFU Blade Slide Holder
- 2x Mounting Screws



Figure 2: Package contents including the blade slide holder and two screws.



Figure 3: Close-up view of the two gold-plated mounting screws.

4. SETUP AND INSTALLATION

This section outlines the steps for replacing the blade slide holder on compatible WAHL hair clippers

(models 1919/8504).

1. **Power Disconnection:** Ensure your WAHL hair clipper is unplugged from the power outlet before beginning.
2. **Remove Existing Blades:** Carefully remove the existing clipper blades and the old blade slide holder from the clipper body. Refer to your clipper's original manual for specific blade removal instructions if needed.
3. **Position New Holder:** Place the new ZEZEUFUFU Blade Slide Holder into the designated slot on the clipper. Ensure it aligns correctly with the internal mechanisms.
4. **Secure with Screws:** Use the two provided screws to firmly attach the new blade slide holder. Do not overtighten, as this may strip the threads or damage the component.
5. **Reattach Blades:** Reinstall the clipper blades onto the new slide holder, ensuring they are properly aligned and secured according to your clipper's specifications.



Figure 4: The blade slide holder with screws in place, ready for installation.

5. OPERATING CONSIDERATIONS

Once the blade slide holder is installed, ensure the clipper blades move smoothly and freely. The slide holder's function is to guide the moving blade against the stationary blade. If you notice any resistance or improper blade movement, recheck the installation steps.

6. MAINTENANCE

- **Cleaning:** Periodically remove the blades and clean any hair or debris from the blade slide holder and surrounding areas using a small brush.
- **Lubrication:** Apply a few drops of clipper oil to the blades and the contact points of the slide holder as recommended by your clipper's manufacturer to ensure smooth operation and reduce wear.
- **Inspection:** Regularly inspect the blade slide holder for any signs of wear or damage. Replace if necessary to maintain optimal clipper performance.

7. TROUBLESHOOTING

- **Blades not moving smoothly:** Ensure the blade slide holder is correctly seated and the screws are not overtightened. Check for any hair or debris obstructing movement.
- **Unusual noise from clipper:** This could indicate improper blade alignment or a loose component. Disconnect power and re-check the installation of the blade slide holder and blades.
- **Part does not fit:** Verify that your WAHL clipper model is either 1919 or 8504. This blade slide holder is specifically designed for these models.

8. SPECIFICATIONS

Material	Gold-plated Metal
Compatibility	WAHL Hair Clippers (Models 1919, 8504)
Color	Gold
Item Weight	0.35 ounces

9. WARRANTY AND SUPPORT

For any questions regarding the installation or function of your ZEZEUFUFU Blade Slide Holder, please contact the seller or manufacturer directly. Specific warranty information may vary; please refer to your purchase documentation for details.