

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rolynn](#) /

› [Hopestar Series P65 Portable Wireless Bluetooth Speaker User Manual](#)

Rolynn P60

Hopestar Series P65 Portable Wireless Bluetooth Speaker

USER MANUAL

Model: P60 | Brand: Rolynn

Introduction

Thank you for choosing the Hopestar Series P65 Portable Wireless Bluetooth Speaker. This speaker is designed to provide high-quality audio with dynamic RGB lighting, making it ideal for various indoor and outdoor settings. Its compact size, robust sound, and waterproof design ensure an enjoyable listening experience wherever you go. Please read this manual carefully to understand the features and proper operation of your new speaker.

Package Contents

- Hopestar Series P65 Portable Wireless Bluetooth Speaker
- USB Type-C Charging Cable
- User Manual (this document)

Product Overview



Figure 1: Front view of the Hopestar Series P65 speaker, showcasing its compact design, fabric finish, and integrated RGB light panel.



Figure 2: Illustration of the speaker's internal dual speaker configuration, emphasizing the 20W audio output capability.

Key Features:

- **Dynamic RGB Lights:** Integrated LED lights that pulsate and flow with music, enhancing the ambiance.
- **Powerful Audio:** Small in size, yet delivers crisp, balanced sound with enhanced bass.
- **Portable Design:** Equipped with a durable, tear-resistant silicone strap for easy carrying and attachment.
- **360° True Wireless Stereo (TWS):** Supports pairing with another P65 speaker for immersive stereo sound.
- **Waterproof (IPX6):** Designed to withstand water splashes, making it suitable for outdoor use.

Controls and Ports:

The speaker features intuitive buttons on its top panel for power, volume control, playback, and light mode selection. A USB Type-C port is located on the side or rear for charging.

Setup

1. Initial Charging:

Before first use, fully charge the speaker. Connect the supplied USB Type-C cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status and turn off or change color once fully charged.

2. Powering On/Off:

- To Power On: Press and hold the Power button (usually marked with or a power symbol) for approximately 2-3 seconds until you hear an audible prompt or see the indicator lights activate.
- To Power Off: Press and hold the Power button again for approximately 2-3 seconds until you hear an audible prompt or the indicator lights turn off.

Operating Instructions

1. Bluetooth Pairing:

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The Bluetooth indicator light will typically flash rapidly.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "**Hopestar P65**" from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the Bluetooth indicator light will become solid.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

2. Controlling RGB Lights:

20W DUAL SPEAKER

20W speaker, even in
Outdoor can also enjoy excellent sound quality.



Figure 3: The speaker displaying its vibrant RGB lighting effects, which can synchronize with music.



Figure 4: A close-up of the speaker's RGB lights in action, highlighting their visual appeal.

The Hopestar P65 features multiple RGB light modes. Use the dedicated Light Mode button (if available, refer to speaker's physical buttons) to cycle through different lighting effects, or to turn the lights off. The lights are designed to pulsate and flow with the rhythm of your music.

3. True Wireless Stereo (TWS) Pairing:

To achieve a 360° surround stereo experience, you can pair two Hopestar P65 speakers together.

1. Ensure both P65 speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be the primary speaker), press and hold the TWS pairing button (refer to speaker's physical buttons, if not explicitly marked, it might be the Play/Pause button or a dedicated TWS button).
3. The speakers will search for each other and automatically pair. You will hear an audible confirmation once TWS pairing is successful.
4. Once TWS paired, connect your device to the primary speaker via Bluetooth as described in "Bluetooth Pairing" section. Audio will now play through both speakers in stereo.

4. Basic Playback Controls:

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the Volume Up (+) button. Hold to continuously increase volume.
- **Volume Down:** Press the Volume Down (-) button. Hold to continuously decrease volume.
- **Next Track:** Press and hold the Volume Up (+) button (or a dedicated next track button).
- **Previous Track:** Press and hold the Volume Down (-) button (or a dedicated previous track button).

Maintenance

Cleaning:

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface or internal components. Ensure the charging port cover is securely closed before cleaning if exposed to water.

Storage:

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the speaker every 3-6 months to maintain battery health.

Water Resistance:

The P65 speaker is IPX6 waterproof, meaning it can resist high-pressure, heavy sprays of water. It is not designed to be submerged in water. Ensure the charging port cover is sealed tightly before exposing the speaker to water.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully using the provided USB Type-C cable.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing light). Turn Bluetooth off/on on your device. Move device closer to speaker (within 10 meters).
No sound or distorted sound.	Volume too low; speaker not connected; audio source issue.	Increase speaker and device volume. Re-pair Bluetooth. Check audio source (e.g., music app).
TWS pairing fails.	Speakers already connected to other devices; not in TWS pairing mode.	Ensure both speakers are disconnected from other Bluetooth devices. Follow TWS pairing instructions carefully.
RGB lights not working.	Lights turned off; malfunction.	Press the Light Mode button to cycle through modes or turn lights on. If issue persists, contact support.

Specifications

Model Name	P60
------------	-----

Brand	Rolynn
Connectivity Technology	Bluetooth V5.3, USB Type-C
Speaker Type	Portable, Outdoor
Special Feature	RGB LED Light, Waterproof (IPX6)
Audio Output Mode	Stereo (2.0 Channel)
Speaker Maximum Output Power	20 Watts
Power Source	Battery Powered (1 Lithium Ion battery included)
Product Dimensions (D x W x H)	8.46" x 4.92" x 4.92"
Item Weight	2.29 pounds
Compatible Devices	MP3 Player, Laptop, Desktop, Tablet, Smartphone

Warranty and Support

This product is covered by a manufacturer's warranty. For detailed warranty information, please refer to the product packaging or contact Rolynn customer support. If you encounter any issues or have questions regarding your Hopestar Series P65 speaker, please reach out to the seller or manufacturer for assistance.

For further support, you may visit the official Rolynn website or contact their customer service department. Please have your product model number (P60) and purchase details ready when seeking support.