

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [G GENEINNO](#) /
- › [GENEINNO S1 Plus Underwater Scooter Instruction Manual](#)

G GENEINNO S1 Plus

GENEINNO S1 Plus Underwater Scooter Instruction Manual

Comprehensive guide for setup, operation, and maintenance of your GENEINNO S1 Plus Underwater Scooter.

1. PRODUCT OVERVIEW

The GENEINNO S1 Plus Underwater Scooter is a versatile and powerful device designed for water sports enthusiasts. It features dual propellers, smart APP control, and is suitable for various activities including swimming, pool use, scuba diving, free diving, and snorkeling for both kids and adults. This upgraded version offers enhanced performance and user-friendly features.



Image: The GENEINNO S1 Plus Underwater Scooter in blue, shown with an extra battery pack and a hand strap.

2. WHAT'S INCLUDED (PACKING LIST)

Upon unboxing your GENEINNO S1 Plus Underwater Scooter, please verify that all the following components are present:

- 1 x S1 Underwater Booster (Scooter)
- 1 x Anti-loss Rope
- 1 x Charger / Adapter
- 1 x User Manual
- 1 x Carrying Bag
- Extra Battery (if purchased with this variant)

— Packing List —



Image: Visual representation of the GENEINNO S1 Plus packing list, including the scooter, lithium-ion batteries, anti-lost rope, user manual, fast-charge adapter, and carrying bag.

3. SETUP

3.1 Battery Installation

Proper battery installation is crucial for the safe and effective operation of your S1 Plus Underwater Scooter. Follow these steps carefully:

1. Locate the battery compartment cover on the scooter.
2. Slide the cover backward to open the compartment.
3. Carefully insert the battery into the compartment.
4. Align the battery connector with the plug-in port inside the scooter and firmly plug it in.
5. Clockwise tighten the connector to ensure a secure and waterproof seal.
6. Slide the cover forward until it is fully closed and latched.

Your browser does not support the video tag.

Video: A demonstration of how to replace the battery in the GENEINNO S1 Plus Underwater Scooter, showing the steps for opening the compartment, connecting the battery, and securing the cover.

4. OPERATING INSTRUCTIONS

The GENEINNO S1 Plus is designed for intuitive operation. Familiarize yourself with the controls before use.

4.1 Basic Operation

1. **Unlock Security Lock:** Before starting, toggle the security lock to the unlocked state. This is a child safety feature to prevent accidental activation.
2. **Start/Stop:** To start the scooter, press both buttons (power button on the left handle and start button on the right handle) simultaneously. Ensure a firm grip on the handles while in water.
3. **Speed Control:** The S1 Plus offers two variable speeds. You can toggle the speed mode to switch between leisure and sports mode. To manually switch gears between low and high speed, keep pressing the power button (left hand) and press

the start button (right hand) twice.

Your browser does not support the video tag.

Video: An overview of the GENEINNO S1 Plus Underwater Scooter in action, demonstrating its features like maximum depth, running time, child safety lock, speed modes, and thrust.

Your browser does not support the video tag.

Video: A short demonstration highlighting the GENEINNO S1 as a consumption-level, intelligent underwater scooter, showcasing its ease of use and integrated design.

Your browser does not support the video tag.

Video: This video illustrates the GENEINNO S1 as a consumption-level, integrated underwater scooter, showing its application in various underwater activities.

4.2 Smart APP Control

The S1 Plus underwater scooter can be controlled and monitored via a dedicated smartphone application. The APP provides access to various functions and real-time data:

- **Gear Shift:** Remotely control the speed settings.
- **Real-time Data:** Monitor battery level, duration time, depth, and water temperature.
- **Activity Log:** View recorded mileage, total time, and log start/stop times.
- **Sharing:** Share your diving information and experiences directly from the app.
- **Parental Mode:** Adults can control the scooter from the ground via the app, which is ideal for supervising children learning to swim in a pool.



Image: Screenshot of the GENEINNO S1 Plus Smart APP interface, showing controls for speed, battery status, depth, temperature, and activity logging.

Explore the Majestic Marine Life



Image: An adult using the GENEINNO S1 Plus APP in Parental Mode to control the scooter for a child swimming in a pool.

5. KEY FEATURES



Extended Runtime: Powered by a 6300mAh Li-polymer battery, the S1 Plus offers a running time of 45-60 minutes on a full charge, with a quick recharge time of only 1.5 hours. It also features an automatic low battery alert.



Dual Speed Modes: Achieve a maximum speed of 4 mph (6.4 km/h) for rapid movement or switch to a low speed of 2.2 mph (3.5 km/h) for underwater filming or leisurely exploration.



Impressive Depth Capability: Designed to operate safely down to 164 feet (50 meters), allowing for exploration of deeper ocean environments.



Portable and Lightweight: Weighing only 8 lbs (3.6 kg) and measuring 19" x 8" x 9", the S1 Plus is easy to transport and fits in airplane carry-on luggage.



Powerful and Durable Motor: Features a newly designed, maintenance-free ultra-durable motor with over 1000 hours lifetime. The omni-sealed inner rotor ensures high water pressure resistance and corrosion resistance.



Versatile Use: Ideal for swimming, snorkeling, scuba diving, and free diving. Compatible with GoPro cameras and LED lights for extended functionality.



Safety and Buoyancy: Designed with positive buoyancy, ensuring it floats to the surface if power runs out or if accidentally dropped. Includes a child safety lock.

6. MAINTENANCE

To ensure the longevity and optimal performance of your GENEINNO S1 Plus Underwater Scooter, follow these maintenance guidelines:

- **Motor Maintenance:** The S1 Plus features a maintenance-free ultra-durable motor. Due to its omni-sealed inner rotor and exclusive oil-sealed bearing, regular motor maintenance is not typically required.
- **Battery Care:** When the battery runs low, the scooter's positive buoyancy allows it to float to the surface for easy battery replacement. The professional waterproof port ensures safety during this process. Always ensure the battery compartment is dry and clean before closing.
- **Cleaning:** After each use, especially in saltwater, rinse the scooter thoroughly with fresh water to prevent salt buildup and corrosion.
- **Storage:** Store the scooter in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is fully charged before long-term storage.

7. TROUBLESHOOTING

This section provides general troubleshooting tips. For more complex issues, please refer to the official GENEINNO support channels.

- **Scooter Not Starting:**

- Ensure the battery is fully charged and correctly installed.
- Verify that the security lock is in the unlocked position.
- Confirm that both power and start buttons are pressed simultaneously and firmly.

- **Reduced Performance/Speed:**

- Check the battery level via the APP or indicator lights.
- Ensure propellers are free from debris or obstructions.
- Verify that the scooter is in the desired speed mode (leisure vs. sports).

- **APP Connectivity Issues:**

- Ensure Bluetooth is enabled on your smartphone.
- Make sure the scooter is powered on and within range.
- Try restarting both the scooter and the APP.

8. SPECIFICATIONS

Item Weight	8 Pounds (approx. 3.6 kg)
Brand Name	G GENEINNO
Model Name	GENEINNO S1-Plus Blue Underwater Scooter
Color	S1 Plus Scooter Blue+Extra Battery+Handstrap
Material	Plastic
Dimensions	22 x 14 x 11 inches (approx. 55.9 x 35.6 x 27.9 cm)
Max Depth	164 ft (50 m)
Speed Modes	2 gear speed (Low: 2.2 mph, High: 4 mph)
Battery Time	25-45 minutes (depending on speed mode)
Thrust	Up to 26 lbs (12 kg)
Buoyancy	Positive
Extension Interface	Go-Pro or light mount compatible
Bluetooth Function	Available for Geneinno APP

9. WARRANTY & SUPPORT

The GENEINNO S1 Plus Underwater Scooter comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards.

For any technical assistance, warranty claims, or further inquiries, please contact GENEINNO customer support through their official website or the contact information provided in your product packaging. Retain your proof of purchase for warranty validation.

