

VTech XS1050

VTech XS1050 Cordless Phone User Manual

Model: XS1050

[Introduction](#) [Setup](#) [Operation](#) [Features](#) [Maintenance & Support](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)

1. INTRODUCTION

Thank you for purchasing the VTech XS1050 Cordless Phone. This manual provides essential information for setting up, operating, and maintaining your new phone. Please read it thoroughly to ensure proper use and to take full advantage of its features.



Figure 1: VTech XS1050 Cordless Phone and Base Unit

This image shows the VTech XS1050 cordless phone handset resting in its white base unit. The handset features a digital display and a numeric keypad. The base unit also has controls for the answering machine.

2. SETUP

2.1 Package Contents

Before you begin, ensure all items are present:

- VTech XS1050 Handset
- VTech XS1050 Base Unit
- Power Adapter for Base Unit
- Telephone Line Cord
- 2 x Product-Specific Batteries (included)
- User Manual (this document)

2.2 Battery Installation

1. Open the battery compartment cover on the back of the handset.
2. Insert the two supplied batteries, observing the correct polarity (+ and -).
3. Close the battery compartment cover securely.

2.3 Connecting the Base Unit

1. Connect the power adapter to the base unit and plug it into a wall outlet.
2. Connect one end of the telephone line cord to the base unit and the other end to your telephone wall jack.

2.4 Initial Charge

Place the handset on the base unit. The battery indicator on the handset display will show charging. Allow the handset to charge for at least 16 hours before initial use to ensure optimal battery performance.

3. OPERATING INSTRUCTIONS

3.1 Making and Receiving Calls

- **Making a Call:** Pick up the handset, dial the number, and press the **Call** button.
- **Receiving a Call:** When the phone rings, press the **Call** button.
- **Ending a Call:** Press the **End Call** button or place the handset back on the base unit.

3.2 Using the Answering Machine

The VTech XS1050 features a digital answering machine with up to 30 minutes of recording time.

- **Playing Messages:** Press the **Play** button on the base unit.
- **Recording a Greeting:** Refer to the detailed instructions in the full manual for custom greeting setup.

3.3 Hands-Free Speakerphone

To activate the hands-free speakerphone during a call, press the **Speakerphone** button on the handset. Press it again to switch back to handset mode.



Figure 2: Hands-Free Speakerphone Function

This image shows a person in a kitchen setting, using the VTech XS1050 handset on speakerphone mode while performing other tasks, indicating the convenience of the hands-free function.

3.4 Volume Adjustment

During a call, use the **Volume Up** and **Volume Down** buttons on the side of the handset to adjust the earpiece volume. The base unit also has volume controls for the speakerphone and answering machine playback.

3.5 Phonebook and Speed Dial

- **Phonebook:** Store up to 100 names and numbers. Access and manage entries via the handset menu.
- **Speed Dial:** Assign frequently called numbers to 8 dedicated speed dial keys for quick access.

3.6 Caller ID and Call History

The phone displays caller information (if available from your service provider) and stores a history of the last 20 incoming calls.

Identification de l'appel/appel en attente/ historique des appels 20 enregistrements



Figure 3: Caller ID and Call History Display

This image illustrates the handset's display showing multiple entries in the call history, including caller names and numbers, demonstrating the caller ID and call waiting features.

3.7 Conference Function

The intercom/hands-free function allows multiple users to participate in a conversation simultaneously, facilitating three-way conference calls.

Conférence à trois



Figure 4: Three-Way Conference Call

This image depicts three individuals engaged in separate phone conversations, symbolizing the three-way conference call capability of the VTech XS1050.

3.8 Alarm and Mute Function

The handset includes an alarm function for reminders and a mute function to temporarily silence your microphone during a call.

Fonction d'alarme et de sourdine



Figure 5: Alarm and Mute Function Icons

This image shows the VTech XS1050 handset on a table, with graphic overlays of an alarm clock and a muted speaker icon, illustrating the alarm and mute functionalities.

4. KEY FEATURES

4.1 Volume Amplifier

The VTech XS1050 features an integrated volume amplifier that boosts incoming sound and voice for enhanced clarity and volume. This feature is particularly beneficial for users with hearing impairments or those who prefer a louder audio experience.

Amplificateur de volume



Figure 6: Volume Amplifier in Action

This image visually represents the volume amplification feature, showing sound waves emanating from the handset and an ear icon with a plus sign, indicating increased audio output for clearer conversations.

4.2 Digital Answering Machine

Record and store incoming calls when you are unavailable. The digital answering machine offers a maximum storage duration of 30 minutes, ensuring you don't miss important messages.

4.3 Backlit Screen and Keypad

The handset features a backlit screen and keypad, providing improved visibility in low-light conditions and enhancing ease of use.

Écran et clavier rétro-éclairés



Figure 7: Backlit Screen and Keypad

This image highlights the illuminated display and keys of the VTech XS1050 handset, demonstrating its backlit feature for better visibility in dim environments.

4.4 Long Battery Life

Enjoy extended conversations with up to 18 hours of talk time on a single charge, ensuring your phone is ready when you need it.

Jusqu'à 18 heures de durée de fonctionnement de la batterie



Figure 8: Up to 18 Hours Battery Life

This image features a woman talking on the VTech XS1050 handset, with a graphic overlay indicating '18 hours' talk time, emphasizing the product's long battery endurance.

4.5 Adjustable Ringtone Volume and Melodies

Customize your phone experience by adjusting the ringtone volume and choosing from various melodies to suit your preference.

Volume et mélodies des sonneries réglables



Figure 9: Adjustable Ringtone Settings

This image shows the VTech XS1050 handset with graphic icons representing a bell (ringtone) and musical notes, indicating the ability to adjust ringtone volume and select melodies.

4.6 Multilingual Help Messages

The phone supports multilingual help messages, providing assistance in various languages for user convenience.

Messages d'aide multilingues



Figure 10: Multilingual Help Messages

This image displays the VTech XS1050 handset with various greetings like 'Hello', 'Bonjour', 'Olá', and 'Ciao' floating around it, illustrating the multilingual support feature.

5. MAINTENANCE

5.1 Cleaning

Wipe the phone and base unit with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure no liquid enters the phone's openings.

5.2 Battery Care

- Always use the supplied batteries.
- If the phone will not be used for an extended period, remove the batteries to prevent leakage.
- Dispose of old batteries responsibly according to local regulations.

6. TROUBLESHOOTING

If you experience issues with your VTech XS1050, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No dial tone	Telephone line cord is not connected properly.	Ensure the telephone line cord is securely plugged into the base unit and the wall jack.
Phone does not power on	Batteries are not charged or incorrectly installed.	Check battery polarity and ensure the handset is properly seated on the base unit for charging. Verify power adapter connection.
Poor sound quality	Interference from other electronic devices.	Move the base unit or handset away from other electronic devices such as TVs, computers, or microwaves.
Answering machine not recording	Memory full or answering machine is off.	Delete old messages to free up space. Ensure the answering machine function is activated.

7. SPECIFICATIONS

Feature	Detail
Brand	VTech
Model	XS1050
Color	White
Phone Type	Cordless (DECT)
Number of Batteries	2 (Product Specific - Included)
Material	Plastic
Power Source	Battery Powered
Dialer Type	Single Keypad
Item Dimensions (L x W x H)	18.5 x 15.1 x 6.6 centimeters
Answering System Type	Digital
Item Weight	400 Grams
Answering Machine Capacity	Up to 30 minutes
Phonebook Capacity	100 names and numbers
Call History	20 entries
Talk Time	Up to 18 hours

8. WARRANTY & SUPPORT






8.1 Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official VTech website. Keep your purchase receipt as proof of purchase.

8.2 Customer Support

If you require further assistance or have questions not covered in this manual, please contact VTech customer support. Contact details can typically be found on the VTech website or in the product packaging.

Related Documents - XS1050

<div><div>VG 208 208-2</div><div><div>vttech</div><div>User's manual</div></div></div>	<p>VTech VG208 / VG208-2 User Manual: Features, Safety, and Operation Guide</p> <p>Comprehensive user manual for the VTech VG208 and VG208-2 DECT 6.0 cordless phones. Learn about installation, operation, features like answering machine, caller ID, call blocking, intercom, safety instructions, and technical specifications.</p>
<div><div></div></div>	<p>VTech CS2050/CS2051/CS2052/CS2053 Quick Start Guide</p> <p>Comprehensive guide to setting up and using your VTech CS2050, CS2051, CS2052, or CS2053 cordless phone system, including safety instructions, product registration, warranty information, and feature setup.</p>
<div><div>VS122-16</div><div></div></div>	<p>VTech VS122-16 Cordless Phone Quick Start Guide</p> <p>A quick start guide for the VTech VS122-16 cordless phone, covering setup, features like Smart Call Blocker, Caller ID, Phonebook, Answering System, and Bluetooth connectivity.</p>
<div><div></div></div>	<p>VTech CS5229 Cordless Phone Quick Start Guide</p> <p>This guide provides instructions for setting up and using the VTech CS5229 DECT 6.0 cordless telephone, including installation, basic operation, phonebook, caller ID, call blocking, and answering system features.</p>
<div><div>VS122-16</div><div></div></div>	<p>VTech VS122-16 Cordless Phone with Bluetooth: Quick Start Guide</p> <p>Get started with your VTech VS122-16 cordless phone. This guide covers essential safety instructions, setup, operation of features like Smart Call Blocker and Bluetooth, technical specifications, and warranty information.</p>

EU Declaration of Conformity Manufacturer Name: VTech Telecommunications
Limited Address: 23/F, Tai Ping Industrial Centre, Block 1, 57 Ting Kok Road, Tai Po,
Hong Kong Product: DECT Phone Model Name: **XS1050**, XS1051 We, VTech,
declare under our sole responsibility that the above referenced prod...
lang:en score:30 filesize: 78.87 K page count: 1 document date: 2022-06-15



[pdf] Decleration of Conformity

Microsoft Word XS1050 Declaration of Conformity docx VTT07806 vtechphones eu assets 984c1d4c7cc4 468b b2bd 947c9c067564 |||

UKCA Declaration of Conformity Manufacturer Name: VTech Telecommunications Limited Address: 23/ ... nce Park, Abingdon, Oxfordshire, OX14 3YT, United Kingdom Product Model Name: DECT phone Model No.: **XS1050** We, Vtech Telecommunications Limited. hereby declares that the above equipment has been teste...

lang:en score:27 filesize: 110.92 K page_count: 1 document date: 2024-08-05



[pdf] Decleration of Conformity

Microsoft Word XS1050 XS1051 Declaration of Conformity docx VTT07806 vtechphones eu assets da5928b0 fbc6 45a7 a9df 3405f754fcf1 |||


UKCA Declaration of Conformity Manufacturer Name: VTech Telecommunications Limited Address: 23/ ... nce Park, Abingdon, Oxfordshire, OX14 3YT, United Kingdom Product Model Name: DECT phone Model No.: **XS1050**, XS1051 We, Vtech Telecommunications Limited. hereby declares that the above equipment has be... lang:en score:27 filesize: 110.98 K page_count: 1 document date: 2024-08-06



[pdf] Decleration of Conformity

Microsoft Word XS1050 XS1051 Declaration of Conformity docx VTT07806 Product Support Official VTechvtechphones eu assets da5928b0 fbc6 45a7 a9df 3405f754fcf1 |||

UKCA Declaration of Conformity Manufacturer Name: VTech Telecommunications Limited Address: 23/ ... nce Park, Abingdon, Oxfordshire, OX14 3YT, United Kingdom Product Model Name: DECT phone Model No.: **XS1050**, XS1051 We, Vtech Telecommunications Limited. hereby declares that the above equipment has be... lang:en score:26 filesize: 110.98 K page_count: 1 document date: 2024-08-06



[\[pdf\]](#) Quick Start Guide Installation Guide Instructions Guide

XS1050 XS1051 XS1052 XS1053 XS105X QSG V2 230315 EU 5 langs vtechphones eu assets 68c55ea1 46b8 4f1a 8bca 601e79829d45 |||

Scan the QR code or go to [euphones.vtech.com/ support](http://euphones.vtech.com/support) for support information
Scannen Sie den QR cod ... orte Scansionare il codice QR o andare su euphones.vtech.com/support per informazioni di supporto **XS1050** Connect the b b XS1051 XS1052 XS1053 base/charger Schließen Sie die Basisstation an/ lad...

lang:en **score:26** filesize: 12.19 M page_count: 2 document date: 2023-03-15




[\[pdf\]](#) Quick Start Guide Instructions Guide

English Product Support Official VTech XS105X QSG UK v1 20220421 cdn vtech jouets assets 6212570a cc80 475f 8ef1 a1f7d63d2e43 |||

XS1050 XS1051 XS1052 XS1053 Scan the QR code or go to euphones.vtech.com/support for support information Quick Start Guide Important safety instructions
When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, in...

lang:en **score:24** filesize: 4 M page_count: 2 document date: 2022-04-21



[\[pdf\]](#) Quick Start Guide Installation Guide Instructions Guide

XS105X QSG V2 231025 EU 5 langs vtechphones eu assets 4c04780e e6fa 4c9c a42c 5b239fa425af |||

Scan the QR code or go to [euphones.vtech.com/ support](http://euphones.vtech.com/support) for support information
Scannen Sie den QR cod ... orte Scansionare il codice QR o andare su euphones.vtech.com/support per informazioni di supporto **XS1050** Connect the b b XS1051 XS1052 XS1053 base/charger Schließen Sie die Basisstation an/ lad...

lang:en **score:18** filesize: 12.19 M page_count: 2 document date: 2023-10-25



[\[pdf\]](#) User Manual Installation Guide Instructions Troubleshooting Guide

XS105x UK WEBCIB v2 221213 VTech prieš 1 dieną — Input 100 240V AC 50 60Hz 0 15A Output 6VDC 45A 2 7W Power consumption Operating condition Off mode cdn vtech jouets assets 74aa659e 4251 4666 b2dc 21262e3dfa26 |||

XS 1050 1051 1052 1053 Scan the QR code for support information Congratulations on purchasing your ... s and telecommunication equipment. VTech Telecommunication Ltd. hereby declares that this telephone **XS1050/XS1051/XS1052/XS1053** is in compliance with the essential requirements and other relevant prov...

lang:en **score:16** filesize: 16.27 M page_count: 52 document date: 2022-12-13

XS
1050
1051
1052
1053

Scan the QR code for
support information



vtech®

[\[pdf\]](#) User Manual Installation Guide Instructions Troubleshooting Guide

XS105x DE EN WEBCIB v2 230315 vtechphones eu assets 2a18e383 acf1 4951 ad74 a081b7f4571a |||

XS 1050 1051 1052 1053 Scan the QR code for support information Congratulations
on purchasing your ... s and telecommunication equipment. VTech

Telecommunication Ltd. hereby declares that this telephone

XS1050/XS1051/XS1052/XS1053 is in compliance with the essential requirements
and other relevant prov...

lang:en score:12 filesize: 13.89 M page_count: 24 document date: 2023-03-15