Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Livoo /
- > Livoo Electric Plancha DOC302 User Manual

Livoo DOC302

Livoo Electric Plancha DOC302 User Manual

Model: DOC302 | Brand: Livoo

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- · Keep the appliance out of reach of children and pets.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- · Avoid touching hot surfaces. Use handles or knobs.
- Ensure adequate ventilation when operating the plancha.
- Do not use abrasive cleaning agents or sharp objects on the cooking surface.

PRODUCT OVERVIEW

Components

The Livoo Electric Plancha DOC302 consists of the following main components:

- Stainless Steel Cooking Plate: Large 51 x 36 cm surface for various foods.
- **Control Panel with Thermostats:** Two independent adjustable thermostats with indicator lights.
- Grease Drip Tray: Removable tray for collecting excess grease.
- Heating Element: Integrated for rapid and even heating.



Image: Front view of the Livoo Electric Plancha DOC302, showcasing the stainless steel cooking surface, two independent temperature control knobs, and power indicator lights. The Livoo brand logo is visible on the right side of the control panel.

Features

- · Electric Plancha
- Cooking surface 51 x 36 cm
- 2 independent thermostats
- · 2800 Watts power
- · Removable grease drip tray

SETUP

Follow these steps to set up your electric plancha for first use:

- 1. Unpack: Carefully remove all packaging materials from the plancha and its components.
- 2. Inspect: Check the appliance for any signs of damage. Do not use if damaged.
- 3. **Position:** Place the plancha on a flat, stable, and heat-resistant surface, ensuring sufficient space around it for ventilation.
- 4. **Install Grease Tray:** Ensure the removable grease drip tray is correctly inserted into its designated slot beneath the cooking plate.
- 5. **Initial Cleaning:** Before first use, wipe the cooking plate with a damp cloth and mild detergent, then dry thoroughly. Refer to the 'Cleaning and Maintenance' section for detailed instructions.
- 6. **Connect Power:** Plug the power cord into a grounded electrical outlet. Ensure the outlet voltage matches the appliance's requirements (220-240V).

OPERATING INSTRUCTIONS

Pre-heating

Proper pre-heating ensures optimal cooking results.

- 1. After plugging in the plancha, turn the desired thermostat knob(s) to the desired temperature setting (e.g., 200°C 300°C).
- 2. The indicator light(s) will illuminate, indicating that the heating element is active.
- 3. Allow the plancha to pre-heat for approximately 5-10 minutes, or until the indicator light turns

off, signaling that the set temperature has been reached. The light may cycle on and off during cooking to maintain temperature.

Cooking

The large stainless steel cooking surface is suitable for a variety of foods.

- Lightly grease the cooking surface with a small amount of cooking oil before placing food.
- Place food directly onto the hot cooking plate.
- Utilize the two independent thermostats to cook different foods at varying temperatures simultaneously.
- Use heat-resistant utensils (wood or silicone recommended) to turn and remove food.




Image: The Livoo Electric Plancha DOC302 in operation on a kitchen counter, grilling shrimp and sliced zucchini. Bowls of salad and limes are visible nearby, illustrating a typical cooking scenario.

Temperature Control

The plancha features two independent thermostats, allowing precise temperature management for different cooking zones. Each thermostat can be adjusted from 100°C to 300°C. The indicator lights will show when the heating elements are active.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will extend the life of your plancha.

Daily Cleaning

- 1. **Unplug and Cool:** Always unplug the plancha from the power outlet and allow it to cool completely before cleaning.
- 2. **Remove Excess Food:** Scrape off any food residue from the cooking plate using a wooden or plastic spatula.
- 3. **Empty Grease Tray:** Carefully remove the grease drip tray and dispose of the collected grease. Wash the tray with warm, soapy water or place it in a dishwasher.
- 4. **Clean Cooking Plate:** The stainless steel cooking plate is removable and dishwasher-safe. Alternatively, wash it by hand with warm, soapy water and a non-abrasive sponge. For stubborn residue, you may soak the plate briefly. Rinse thoroughly and dry completely.
- 5. **Clean Base Unit:** Wipe the exterior of the base unit with a damp cloth. Do not use abrasive cleaners or immerse the base unit in water.



Image: The Livoo Electric Plancha DOC302 with its stainless steel cooking plate detached from the base unit, revealing the internal heating elements. This illustrates the removable design for easier cleaning.



Image: Side view of the Livoo Electric Plancha DOC302, highlighting the easily accessible and removable grease drip tray located at the front of the appliance.

Storage

Ensure the plancha is clean and completely dry before storing. Store it in a cool, dry place, away

from direct sunlight and moisture. Do not wrap the power cord tightly around the appliance.

TROUBLESHOOTING

If you encounter issues with your plancha, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Plancha does not heat up.	Not plugged in; power outlet issue; thermostat off or set too low.	Check power connection; test outlet with another appliance; turn thermostat to desired temperature.
Food sticks to the cooking plate.	Insufficient oil; plate not pre-heated enough.	Apply a thin layer of cooking oil; ensure plancha is fully pre-heated before adding food.
Smoke or unusual odor during first use.	Residual manufacturing oils burning off.	This is normal for first use. Ensure good ventilation. It should dissipate quickly.
Indicator light not working.	Light malfunction; thermostat not turned on.	Ensure thermostat is turned to a heating setting. If problem persists, contact support.

SPECIFICATIONS

• Brand: Livoo

• Model Number: DOC302

• Color: Grey

Product Dimensions (L x W x H): 52.9 x 14.7 x 47 cm

• Power: 2800 Watts

Material: Stainless Steel

• Item Weight: 11.5 Kilograms

• Included Components: Grease drip tray

• Number of Settings: 2 (independent thermostats)

WARRANTY AND SUPPORT

This Livoo Electric Plancha DOC302 comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the duration and coverage.

For technical support, spare parts, or warranty claims, please contact Livoo customer service. Contact information can typically be found on the manufacturer's website or on the product packaging.

When contacting support, please have your model number (DOC302) and proof of purchase readily available.

© 2024 Livoo. All rights reserved.

Related Documents - DOC302



Livoo Plancha Gaz Station 3 Burners Instruction Manual

Comprehensive instruction manual for the Livoo Plancha Gaz Station 3 Burners, detailing safety precautions, assembly steps, operating instructions, cleaning procedures, and technical specifications for outdoor gas cooking.



Livoo 2 Burner Gas Plancha Instruction Manual

Comprehensive instruction manual for the Livoo 2 burner gas plancha, covering safety advice, assembly, usage, and maintenance.



LIVOO Plancha Table User Manual and Assembly Guide

Official user manual and assembly instructions for the LIVOO Plancha Table (Model GS147). Learn how to assemble and use your LIVOO working table cart.



Livoo Instruction manua

Raclette grill fondue 12



Livoo Raclette Grill Fondue 12 Persons Instruction Manual

Official instruction manual for the Livoo Raclette Grill Fondue 12 Persons (Model DOC234). Learn how to safely operate, clean, and maintain your appliance.



LIVOO Raclette Grill 2 Persons Instruction Manual



Official instruction manual for the LIVOO Raclette Grill 2 Persons (Model DOC156). Provides safety instructions, usage guidelines, cleaning, and specifications for household use.



Livoo Plancha Gaz Station 3 Burners Instruction Manual

Comprehensive instruction manual for the Livoo Plancha Gaz Station 3 Burners, detailing safety precautions, assembly steps, operating instructions, cleaning procedures, and technical specifications for outdoor gas cooking.



[pdf] Dimension Guide

Fiche produit technique Plancha LIVOO DOC302 U Techno fr ts 1730108449 u techno media 07 2d 7a 1721136083 |||

LIVOO - Petit Ictromenager **DOC302** Plancha inox 2 thermostats Les plus produit Grande surface de cuisson de 51 x 36 cm Plaque en acier inoxydable amovible Puissance 2800 W 2 thermostat ajustable indpendants avec tmoin lumineux Bac rcuprateur de graisse compatible lave- vaisselle 4 pieds antid...

lang:fr score:32 filesize: 160.29 K page_count: 1 document date: 2024-01-24


Notice d'utilisation





Livoo Version : v.l.0

www.livoo



DOC302 NOTICE FR EN ES IT GE PT NL REV SUR BASE 60335 2 78 att LVD et notice Isemavoine Notice d utilisationPlancha électrique LIVOO Pulsat1000135246 notpulsat fr media manual 1000135246 not |||

Notice d utilisation User Manual / Manual de instrucciones / Bedienungsanleitung / Manuale d uso / Manual de instru es / Gebruiksaanwijzing R f rence : **DOC302**Plancha lectrique inox Electric inox plancha/Plancha el ctrica de acero inoxidable/ Elektrische Plancha aus Edelstahl/ Griglia elet...

lang:fr score:32 filesize: 442.04 K page_count: 43 document date: 2023-11-15



[pdf] Dimension Guide

Fiche produit Plancha intérieure LIVOO DOC302 Villatech 201668 20240314214128 3230 villatech fr media source articles documents 8 6 1 $\mid\mid\mid$

LIVOO - Petit Ictromenager **DOC302** Plancha inox 2 thermostats Les plus produit Grande surface de cuisson de 51 x 36 cm Plaque en acier inoxydable amovible Puissance 2800 W 2 thermostat ajustable indpendants avec tmoin lumineux Bac rcuprateur de graisse compatible lave- vaisselle 4 pieds antid...

lang:fr score:32 filesize: 158.16 K page_count: 1 document date: 2024-03-07



[pdf] Dimension Guide

Fiche produit Plancha électrique LIVOO DOC302 Pulsat201668 20250320224122 5388pulsat fr media source articles documents 8 6 1 201668 5388 |||

LIVOO - Petit I ctromenager **DOC302** Plancha inox 2 thermostats Les plus produit Grande surface de cuisson de 51 x 36 cm Plaque en acier inoxydable amovible Puissance 2800 W 2 thermostat ajustable ind pendants avec t moin lumineux Bac r cup rateur de graisse compatible lav...

lang:fr score:32 filesize: 158.16 K page count: 1 document date: 2024-03-07



[pdf] User Manual Instructions

DOC302 NOTICE FR EN ES IT GE PT NL REV SUR BASE 60335 2 78 att LVD et notice Isemavoine Notice d utilisation 1 giorno fa — tension alimentation indiquée sur la plaque signalétique de I appareil correspond bien à celle votre installation électrique Les instructions 179548 media nouveauxmarchands pj |||

Notice d utilisation User Manual / Manual de instrucciones / Bedienungsanleitung / Manuale d uso / Manual de instrues / Gebruiksaanwijzing Rfrence : **DOC302** Plancha lectrique inox Electric inox plancha/Plancha elctrica de acero inoxidable/ Elektrische Plancha aus Edelstahl/ Griglia elettrica in accia...

lang:fr score:28 filesize: 442.04 K page_count: 43 document date: 2023-11-15



[pdf] Dimension Guide

Fiche produit ManoManoDOC302 Plancha inox 2 thermostats Photos Packaging Les plus Descriptif Caractéristiques Logistique LIVOO Petit éléctromenager 1 rue Foch

BP cb311ed264931f69c34a751c6e4c2904c7c7cb86cdn manomano pim dam img 1498 101975469 cb311ed264931f69c34a751c6e4c2904c7c7cb86 |||

LIVOO - Petit I ctromenager **DOC302** Plancha inox 2 thermostats Les plus produit Grande surface de cuisson de 51 x 36 cm Plaque en acier inoxydable amovible Puissance 2800 W 2 thermostat ajustable ind pendants avec t moin lumineux Bac r cup rateur de graisse compatible lav...

lang:fr score:23 filesize: 160.29 K page count: 1 document date: 2024-01-24