

[manuals.plus](#) /

› [Phomemo](#) /

› [Phomemo D30 Portable Bluetooth Label Maker Instruction Manual](#)

## Phomemo D30

# Phomemo D30 Portable Bluetooth Label Maker Instruction Manual

Model: D30 | Brand: Phomemo

## 1. INTRODUCTION

Thank you for choosing the Phomemo D30 Portable Bluetooth Label Maker. This compact and versatile device allows you to create custom labels directly from your smartphone, offering a convenient solution for organization at home, in the office, or on the go. This manual provides essential information for setting up, operating, and maintaining your D30 label maker to ensure optimal performance.

## 2. PACKAGE CONTENTS

Your Phomemo D30 Label Maker package includes the following items:

- 1x Green D30 Label Maker Machine
- 1x Green Case
- 4 Rolls of White Label Tape
- 1 Roll of Clear Label Tape
- 2 Rolls of Starry Pattern Label Tapes
- 1x USB Charging Cable

## 3. SETUP GUIDE

### 3.1 Charging the Device

Before first use, ensure your Phomemo D30 is fully charged. Connect the provided USB charging cable to the charging port on the device and a suitable power source. The indicator light will show charging status.

### 3.2 Installing the Label Roll

1. Open the cover of the label maker by gently sliding the top part.
2. Insert the label roll into the compartment, ensuring the printing side of the label faces upwards and

the leading edge extends slightly out of the slot.

3. Close the cover firmly until it clicks into place.

### 3.3 Downloading and Connecting the App

1. Scan the QR code in the instruction manual or search for "Print Master" in your smartphone's app store (iOS/Android).
2. Install and open the "Print Master" app.
3. Turn on your Phomemo D30 by pressing and holding the power button until the indicator light turns green.
4. Enable Bluetooth on your smartphone.
5. Within the "Print Master" app, search for your D30 device and tap to connect. The app will automatically detect the label size.



Figure 1: The Phomemo D30 app interface on a smartphone, displaying connection status and various label design options. The label maker is shown next to the phone.

Your browser does not support the video tag.

Video 1: A short demonstration by the seller showing how to create and print labels using the Phomemo D30 label maker and its accompanying app.

## 4. OPERATING INSTRUCTIONS

### 4.1 Designing Your Labels

The "Print Master" app offers a wide array of customization options:

- **Templates:** Choose from 1000+ symbols, 60+ frames, and various fonts.
- **Content:** Easily add text, icons, tables, symbols, logos, barcodes, QR codes, images, and time stamps.
- **Advanced Features:** Insert data from Excel, use Scan, OCR, and Voice RECG for efficient label creation.

### 4.2 Printing Labels

After designing your label in the app:

1. Review the label preview to ensure it meets your requirements.
2. Adjust the number of copies if needed.
3. Tap the "Print" button in the app. The label maker will quickly print your design.
4. Use the built-in cutter to neatly detach the printed label from the roll.



Figure 2: The Phomemo D30 label maker positioned on a kitchen counter, surrounded by various food containers clearly labeled with custom-printed stickers, demonstrating its use for kitchen organization.



Figure 3: Three transparent glass jars containing mung beans, melon seeds, and walnuts, each clearly identified with a custom-printed label from the Phomemo D30 label maker.



Figure 4: A collection of colorful file folders (yellow, pink, blue) with white labels reading 'record 1', 'record 2', and 'record 3', created using the Phomemo D30 label maker, alongside a pen.

## 5. KEY FEATURES

---

- **2024 Upgrade Version:** The D30 is significantly lighter and smaller than traditional label makers. It features a German thermal print head with 25% increased DPI, ensuring superior print clarity and smooth, hassle-free printing. Supports both continuous and fixed-length label tapes.
- **Multiple Creative Functions & Convenient Label Templates:** Access over 1000 symbols, 60+ frames, and a variety of fonts. Easily design labels with icons, text, tables, logos, barcodes, QR codes, images, time, and data from Excel.
- **Protective Case:** The included case is made of high-quality Nylon PU Synthetic material, offering water-proof, dust-proof, and crush-resistant protection for your D30 printer. An internal elastic strap secures the device.
- **Reliable & Portable:** Designed for convenience, the case includes a climbing buckle, allowing you to easily attach it to a bike, car, school bag, or bracket. Its compact size makes it ideal for both indoor and outdoor use without taking up much space.

# Good Helper for Kitchen Storage



Figure 5: The Phomemo D30 label maker and its protective case are shown on a wooden table, surrounded by several glass jars containing various food items, all neatly labeled for kitchen storage.

# Convenient & Securely Design



Large storage space

## Outdoor friendly

Waterproof & Wear-resistant



Figure 6: A close-up view of the Phomemo D30 case interior, highlighting its large storage space with a mesh pocket for accessories like label tape and the charging cable.

# Convenient & Securely Design



**Carabiner**  
fasten with a buckle

**Elastic Band**  
for stable protection



Figure 7: The Phomemo D30 case featuring a carabiner for easy attachment and an internal elastic band designed to securely hold the label maker in place, ensuring stable protection.

# Easy to Find & Space Saving



Figure 8: A visual comparison illustrating the benefits of organization: a 'Messy' top panel shows loose label maker components, while a 'Neat' bottom panel displays the organized Phomemo D30 label maker and case, emphasizing space-saving and ease of finding items.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Phomemo
Model Name	D30
Connectivity Technology	Bluetooth
Printing Technology	Thermal
Special Feature	Portable
Printer Output	Monochrome
Compatible Devices	Smartphones

Feature	Detail
Maximum Black and White Print Resolution	254 dpi
Maximum Color Print Resolution	Approximately 25% higher than the previous version
Print Media	Labels
Control Method	Voice (via app features)
Item Model Number	D30

## 7. TROUBLESHOOTING

- **Printer not connecting via Bluetooth:** Ensure the printer is turned on and within range of your smartphone. Check your phone's Bluetooth settings to confirm it's enabled and the D30 is paired. Restart both the printer and the app if issues persist.
- **Poor print quality:** Verify that the label roll is inserted correctly and the printing side is facing up. Ensure the label maker's battery is sufficiently charged. Adjust the print density settings within the "Print Master" app.
- **Labels not feeding correctly:** Check for any obstructions in the label output slot. Ensure the label roll is properly seated and not jammed.
- **App not recognizing label size:** Make sure the label roll is correctly installed. The D30 uses RFID to automatically detect label size; ensure the label roll is a genuine Phomemo D30 compatible roll.

## 8. MAINTENANCE

- **Cleaning the Print Head:** Regularly clean the thermal print head with a soft, lint-free cloth lightly dampened with rubbing alcohol to prevent print quality degradation. Ensure the device is off before cleaning.
- **Storage:** Store the label maker and label rolls in a cool, dry place away from direct sunlight and extreme temperatures to preserve label quality and device longevity.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, even if not in constant use.

## 9. WARRANTY AND SUPPORT

The Phomemo D30 Label Maker comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to purchase additional label rolls, please refer to the official Phomemo website or contact their customer service directly. Contact information can typically be found in the packaging or on the brand's official online store.