



Manuals.plus /

› Funstorm /

› Funstorm 4K HD Mini Nanny Cam User Manual

Funstorm B11

Funstorm 4K HD Mini Nanny Cam User Manual

Brand: Funstorm | **Model:** B11

1. INTRODUCTION

The Funstorm 4K HD Mini Nanny Cam is an advanced indoor security camera designed for comprehensive surveillance. Featuring 4K UHD picture quality, extended battery life, and smart motion detection, it provides reliable monitoring for your home or office. This manual will guide you through the setup, operation, and maintenance of your new camera.



Figure 1: Funstorm 4K HD Mini Nanny Cam and its compact size.

Wireless Cameras for Home Security

Giant in features!



 2K	 Night Vision	 24/7 Recording	 Motion Detection
 Local/Cloud Storage	 Push Notification	 100 Days Standby	 2.4Ghz WiFi only

Figure 2: Key features including 4K resolution, night vision, motion detection, and 100-day standby.

2. WHAT'S IN THE BOX

Your Funstorm 4K HD Mini Nanny Cam package includes the following items:


- 1 x Funstorm 4K HD Mini Nanny Cam
- Charging Cable
- User Manual (this document)
- Mounting Accessories (if applicable, part of Combo Set)

3. SETUP

3.1 Quick Installation Guide

1. **Download the App:** Download the Ubox app from your device's app store.
2. **Full Charge:** Fully charge the camera using the provided charging cable.
3. **Connect to Wi-Fi:** Follow the in-app steps to connect the camera to your 2.4G Wi-Fi network *Note: This camera only supports 2.4GHz Wi-Fi.*

Quick Installation Guide



Step 1
Download " UBox " APP



Step 2
Fully charge and follow the steps
to connect to Wi-Fi(Only 2.4G).



Step 3
Now you're ready to see

Figure 3: Visual guide for downloading the app, charging, and connecting to Wi-Fi.

3.2 Wi-Fi Connection Details

Ensure your Wi-Fi router is broadcasting a 2.4GHz signal. If you have a dual-band router, you may need to separate the 2.4GHz and 5GHz networks or ensure your device is connected to the 2.4GHz network during setup. The camera will prompt you to confirm its status (e.g., blinking blue indicator LED or voice prompt) before pairing.



Figure 4: The camera supports 2.4GHz Wi-Fi for stable connections.

3.3 Micro SD Card Installation (Optional)

The camera supports local storage via a Micro SD card (up to 128GB, not included). Locate the SD card slot on the camera and gently insert the card until it clicks into place. Format the SD card through the Ubox app for optimal performance.

4. OPERATING THE CAMERA

4.1 4K Ultra-Clear Image Quality & Night Vision

The camera features upgraded 4K resolution and high-definition lenses, providing crystal-clear images during the day. With its advanced night vision capabilities, the camera ensures clear visibility even in low-light conditions, covering a 110° ultra-wide angle to capture a broad monitoring area.



Figure 5: The camera captures every detail with its high resolution.



**Super Vision,
Even at Night**

Figure 6: The camera provides clear vision even at night.



150° Wide-Angle for Ultimate Visual Coverage

Figure 7: The 150° wide-angle lens provides extensive visual coverage.

4.2 Impressive Battery Life

Equipped with a 2600mAh high-capacity battery, the camera offers up to 100 days of continuous use on a single charge. This extended battery life ensures consistent monitoring without frequent recharging.

IMPRESSIVE BATTERY LIFE



Figure 8: The camera boasts an impressive 100-day battery life.

4.3 Real-Time Monitoring & Motion Detection

Access live footage of your home or office anytime, anywhere through the intuitive Ubox app. The camera's motion detection feature sends instant notifications to your phone upon detecting unusual activity, keeping you informed and your property secure.




Figure 9: Motion detection helps keep your home safe by alerting you to suspicious activity.



Figure 10: The app displays a log of detected activities for easy review.

4.4 Storage Options

The camera offers flexible storage solutions. You can utilize local storage with a Micro SD card (up to 128GB) for continuous recording, or opt for cloud storage with a 30-day free trial for convenient access to your footage from anywhere.



Figure 11: Choose between local SD card storage or cloud storage for your recordings.

5. MAINTENANCE

To ensure optimal performance and longevity of your Funstorm camera, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Placement:** Place the camera in a stable, dry indoor environment. Avoid direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** For long-term storage, charge the battery to about 50% to prolong its lifespan.
- **Firmware Updates:** Regularly check the Ubox app for any available firmware updates to ensure your camera has the latest features and security enhancements.

6. TROUBLESHOOTING

If you encounter issues with your Funstorm camera, refer to the following common problems and solutions:

- **Camera Offline:**

- Ensure the camera is charged and powered on.
- Check your Wi-Fi connection and ensure it's a 2.4GHz network.
- Restart your Wi-Fi router and the camera.
- If the issue persists, try re-pairing the camera with the app.

- **Poor Image Quality:**

- Clean the camera lens.
- Ensure adequate lighting in the monitoring area, especially for night vision.
- Check your internet speed; a stable connection is crucial for 4K streaming.

- **Motion Detection Not Working:**

- Verify motion detection settings are enabled in the Ubox app.
- Adjust sensitivity settings if necessary.
- Ensure there are no obstructions blocking the camera's field of view.

- **Battery Drains Quickly:**

- Frequent motion detection events or continuous live viewing can reduce battery life.
- Ensure the camera is fully charged before use.

For further assistance, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	B11
Indoor/Outdoor Usage	Indoor
Power Source	Battery Powered
Connectivity Technology	Wireless (Wi-Fi)
Connectivity Protocol	Wi-Fi (2.4GHz only)
Video Capture Resolution	1080p (Effective Video Resolution: 4000)
Effective Still Resolution	4000 Pixels
Field Of View	150 Degrees
Night Vision Range	5 Meters
Battery Power	2600 Milliamp Hours
Item Dimensions (L x W x H)	2 x 2.7 x 0.7 inches
Item Weight	7.2 ounces
Material	Acrylonitrile Butadiene Styrene (ABS)
Alert Type	Motion Only
Control Method	App
UPC	658362002073

8. WARRANTY AND SUPPORT

Funstorm is committed to providing high-quality, innovative products and excellent customer service. Your camera comes with a **2-year return policy**, ensuring peace of mind.

Our dedicated customer service team is available **24/7** to assist you with any questions or issues you may encounter. Please do not hesitate to reach out for prompt and helpful solutions.

For support, please visit the official Funstorm website or contact us through the Ubox app.

A Brand You Can Trust



High quality
Innovative Products



Excellent
Customer Service



2 Years
Return policy



Figure 12: Funstorm's commitment to quality, customer service, and warranty.