

[Manuals.plus](#) /

› [Yaheetech](#) /

› Yaheetech Outdoor Glider Bench (Model YT-00134025) Instruction Manual

Yaheetech YT-00134025

Yaheetech Outdoor Glider Bench (Model YT-00134025) Instruction Manual

2-Person Outdoor Glider Bench, Patio Glider Chair

INTRODUCTION

Thank you for choosing the Yaheetech Outdoor Glider Bench. This manual provides essential information for the safe assembly, operation, and maintenance of your new glider bench. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- Do not exceed the maximum weight capacity of **408 pounds** for two people.
- Ensure the bench is stable and secure on a flat, level surface before use.
- Keep away from heat sources and sharp objects to prevent damage to the fabric.
- Supervise children when they are near or using the glider bench.
- Do not stand on the bench.
- Regularly inspect all bolts and connections to ensure they are tight.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.


Hard-wearing 620gsm Texteline Fabric



Breathable



Quick-dry



Tear-resistant



Weather-resistant



Image: Components of the glider bench, including the Texteline fabric and powder-coated steel frame.

SETUP AND ASSEMBLY

Simple assembly is required. The product comes with detailed assembly instructions. Please follow the steps carefully.


1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all hardware and components using the provided parts list.
3. Attach the seat and backrest sections to the frame using the provided bolts and tools. Do not overtighten.
4. Ensure all connections are secure before placing the bench upright.
5. Test the gliding mechanism to ensure smooth operation.

Video: Official Yaheetech installation guide for the 2-Person Patio Glider Bench. This video demonstrates the step-by-step assembly process.


2-PERSON GLIDER BENCH



Weather-resistant Texteline Fabric



Powder-coated Metal Frame



Comfortable Armrests



Non-slip Feet

Image: Key features of the glider bench, including the durable Texteline fabric, powder-coated frame, comfortable armrests, and non-slip feet.

OPERATING INSTRUCTIONS

The Yaheetech Outdoor Glider Bench is designed for a smooth and relaxing back-and-forth motion.

- Gently push off with your feet to initiate the gliding motion.
- Maintain a controlled, steady rhythm for optimal comfort.
- Avoid sudden or forceful movements that could strain the mechanism or cause instability.
- Ensure the bench is placed on a stable, level surface to prevent tipping during use.

Enjoy a smooth and relaxing gliding experience



Image: Illustration of the smooth gliding mechanism of the bench.

MAINTENANCE

Proper care will extend the life of your glider bench.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** The Texteline fabric is quick-dry, breathable, and weather-resistant. Allow it to air dry completely after cleaning or rain.
- **Frame Care:** The powder-coated steel frame is designed for outdoor use. Inspect for any signs of rust or damage periodically. Touch up any scratches to prevent corrosion.
- **Storage:** During prolonged periods of non-use or harsh weather conditions, consider covering the bench or storing it indoors to protect it from the elements.

TROUBLESHOOTING

If you encounter any issues with your Yaheetech Outdoor Glider Bench, refer to the following common solutions:

- **Squeaking during gliding:** Check all bolts and ensure they are tightened. Apply a silicone-based

lubricant to the gliding mechanism if necessary.

- **Instability:** Ensure the bench is placed on a flat, level surface. Verify that all assembly bolts are securely fastened.
- **Fabric sagging:** While the Texteline fabric is resilient, prolonged heavy use can cause some stretching. Ensure the weight capacity is not exceeded.

For further assistance, please contact Yaheetech customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	29"D x 42"W x 36"H
Materials	Texteline Fabric, Powder-coated Steel
Frame Material	Alloy Steel
Color	Beige
Style	Modern
Item Weight	24 Pounds
Seat Height	17.3 Inches
Maximum Weight Recommendation	408 Pounds
Seating Capacity	2
Required Assembly	Yes

Maximum
Weight Capacity:

407 lb




Image: Detailed dimensions and weight capacity of the glider bench.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Yaheetech store online. You can find more information and contact details at the [Yaheetech Store](#).