Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Akitas /
- > Akitas X6 Spot Cleaner Instruction Manual

Akitas X6

Akitas X6 Spot Cleaner Instruction Manual

Model: X6

1. Introduction

Thank you for choosing the Akitas X6 Spot Cleaner. This portable and compact carpet washer is designed to efficiently remove spills and stains from various surfaces, including carpets, stairs, and upholstery. With its powerful suction and versatile tools, maintaining a clean home is made easier.

Please read this manual thoroughly before operating the device to ensure safe and effective use. Keep this manual for future reference.



Image: The Akitas X6 Spot Cleaner, a compact and portable unit with clear water and dirty water tanks visible.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Unplug from outlet when not in use and before cleaning.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only low-foaming, low-acid detergents specifically designed for carpet and upholstery cleaners. Do not put highly corrosive or flammable liquids into the tanks.
- Ensure the dirty water tank is cleaned regularly to prevent overflow and maintain suction efficiency. The float mechanism will stop suction if the tank exceeds its maximum water level.

3. PRODUCT COMPONENTS

The Akitas X6 Spot Cleaner comes with the following main components:



Main Host Unit: The core of the cleaner, housing the motor, pumps, and connections for tanks and tools.



Clean Water Bucket (1100ml capacity): For holding clean water and cleaning solution.



Sewage Bucket (500ml capacity): Collects dirty water and extracted debris during cleaning.



Tough Stain Hand Brush Tool: Ideal for scrubbing and extracting tough stains from carpets and other fabrics.



Upholstery Tool: Designed for gentle yet effective cleaning of delicate upholstery and fabrics.



Suction Hose (1.2m) and Power Cord (3m): Provides extended reach for various cleaning tasks.

4. SETUP GUIDE

1. Unpack the Unit: Carefully remove all components from the packaging. Ensure all parts listed in Section 3

are present.

2. **Fill the Clean Water Bucket:** Remove the clean water bucket from the main unit. Fill it with clean water up to the MAX line. For enhanced cleaning, add a low-foaming, low-acid cleaning solution as per the detergent manufacturer's instructions. *Note: It is strongly suggested to spray detergent directly onto the target surface rather than adding it to the water tank to prevent excessive foaming.*



Image: A hand filling the clean water bucket from a tap.

- 3. Attach the Clean Water Bucket: Securely place the filled clean water bucket back onto the main unit until it clicks into place.
- 4. **Attach the Desired Tool:** Select either the Tough Stain Hand Brush Tool or the Upholstery Tool based on your cleaning needs. Attach it firmly to the end of the suction hose.



Image: Hands demonstrating how to attach a cleaning tool to the hose.

5. Plug In: Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

The Akitas X6 Spot Cleaner uses a spray, brush, and absorb method for effective cleaning.



Image: Diagram illustrating the spray, brush, and absorb cleaning process.

- 1. **Power On:** Press the power button on the main unit to turn on the cleaner.
- 2. **Pre-treat (Optional but Recommended):** For stubborn stains, spray a small amount of low-foaming, low-acid detergent directly onto the stained area. Allow it to penetrate for a few minutes as per detergent instructions.
- 3. **Spray and Scrub:** Position the cleaning tool over the stain. Press the spray trigger on the tool handle to release cleaning solution onto the stain. Gently scrub the area with the brush attachment to agitate the stain.



Image: A person using the Akitas X6 Spot Cleaner to clean a spill on a carpet.

4. **Extract Dirty Water:** Release the spray trigger and slowly pull the cleaning tool across the wet area. The powerful suction will lift the dirty water and debris into the sewage bucket. Repeat this step until the area is clean and as dry as possible.



Image: A split image showing a stained carpet area on one side and the same area clean after using the spot cleaner on the other.

5. **Pet-Friendly Cleaning:** The Akitas X6 is effective for cleaning pet urine and dirt from carpets and pet beds.

Follow the same spray, scrub, and extract steps.



Image: A person cleaning a carpet with a pet nearby, demonstrating the cleaner's use for pet messes.

6. **Upholstery and Car Seats:** Use the Upholstery Tool for cleaning delicate fabrics. Test on an inconspicuous area first. The compact size and hose length make it suitable for car interiors.



Image: A person cleaning the interior of a car with the spot cleaner.

- 7. **Monitor Sewage Bucket:** The cleaner has a float mechanism that will stop suction if the sewage bucket exceeds its maximum water level (500ml). Empty the tank promptly when this occurs.
- 8. Power Off: Once cleaning is complete, press the power button to turn off the unit and unplug it from the outlet.

Operation Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the Akitas X6 Spot Cleaner in action, showing its effectiveness on various stains and surfaces.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the life of your Akitas X6 Spot Cleaner.

Empty and Clean Sewage Bucket: After each use, remove the sewage bucket and empty the dirty water.
Rinse the bucket thoroughly with clean water. It is crucial to clean the sewage tank in time to prevent odors
and maintain hygiene.



Image: A hand emptying the dirty water from the sewage bucket into a sink.

- 2. Clean Clean Water Bucket: Rinse the clean water bucket with fresh water after each use, especially if cleaning solution was added.
- 3. **Clean Tools:** Detach the cleaning tools (Tough Stain Hand Brush Tool, Upholstery Tool) and rinse them under running water to remove any debris or residue. Allow them to air dry completely.
- 4. **Dry Components:** Allow all removable components (tanks, tools) to air dry naturally for at least 24 hours before reassembling or storing. This prevents mold and mildew growth.



Image: Various components of the cleaner laid out to air dry.

- 5. **Wipe Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- 6. **Storage:** Store the Akitas X6 Spot Cleaner in a cool, dry place. Its compact size (28x27x15cm) allows for easy storage in most cabinets.



Image: The Akitas X6 Spot Cleaner stored compactly in a cabinet.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No suction or weak suction	 Sewage bucket is full. Hose or tool is clogged. Tanks not properly seated. 	 Empty the sewage bucket. Check hose and tool for blockages and clear them. Ensure both clean and sewage tanks are securely in place.
No spray or weak spray	 Clean water bucket is empty. Spray nozzle is clogged. Pump issue. 	 Refill the clean water bucket. Clean the spray nozzle on the tool. Contact customer support if the issue persists after checking the above.
Machine not turning on	Not plugged in.Power outlet issue.Internal fault.	 Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. Contact customer support.
Excessive foaming	 Incorrect detergent used. Too much detergent. 	 Use only low-foaming, low-acid detergents. Reduce the amount of detergent. Consider spraying detergent directly onto the surface instead of mixing it in the clean water tank.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Akitas
Model Number	X6
Power	400W
Suction Pressure	10Кра
Clean Water Tank Capacity	1100ml

Feature	Specification
Dirty Water Tank Capacity	500ml
Noise Level	Less than 70 dBA
Suction Hose Length	1.2m
Power Cord Length	3m
Product Dimensions (L x W x H)	28 x 27 x 15 cm
Item Weight	3.4 kg

9. WARRANTY INFORMATION

The Akitas X6 Spot Cleaner comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures peace of mind with your purchase. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, neglect, unauthorized repairs, or normal wear and tear. For full warranty terms and conditions, please refer to the warranty card included with your product or contact customer support.

10. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact Akitas customer support:

Website: Visit the Akitas Store on Amazon

Email: Refer to your product packaging or warranty card for specific email contact.

Phone: Refer to your product packaging or warranty card for specific phone contact.

Our mission is to provide the most economical, practical, and reliable professional cleaning solutions. We are committed to helping you with your cleaning needs.

© 2024 Akitas. All rights reserved.

Related Documents - X6



Akitas X7 Spot Cleaner: User Manual and Guide

Comprehensive guide for the Akitas X7 Spot Cleaner, covering features, usage instructions, maintenance, troubleshooting, and warranty information.

