

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

Yaheetech YTIs4t0001001

Yaheetech 11x11 Pop Up Gazebo Instruction Manual

Model: YTIs4t0001001

IMPORTANT SAFETY INFORMATION

For optimal performance and safety, do not use this gazebo in conditions of strong breeze, continuous light rain, heavy rain, or any other extreme weather scenarios. Always anchor the gazebo to the ground when in use to prevent damage or injury.

PACKAGE CONTENTS

Please ensure all components are present before beginning assembly.



SUITABLE FOR OUTDOOR OCCASION



Backyard



Party



Deck

Image: All components of the Yaheetech Pop Up Gazebo, neatly laid out.

- Metal Frame (Pre-assembled pop-up structure)
- Top Cover Cloth (Main canopy fabric)
- Small Cover Cloth (Upper tier canopy fabric)
- Mesh Screen (Four mesh sidewalls with zippers)
- Carrying Bag (For storage and transport)
- Stakes (Two sizes for ground anchoring)
- Ropes (Two sizes for securing the canopy)
- Sandbags (Four empty bags to be filled for added stability)
- Hooks (24 pieces for attaching mesh screen)

SETUP INSTRUCTIONS


Assembly typically requires two or more adults. Follow these steps for a smooth setup:

1. **Unfold the Gazebo Frame:** Carefully pull the frame outwards from its folded position until it is partially open.
2. **Attach Canopy Tops:** Place the small cover cloth (upper tier) onto the top of the partially opened frame, ensuring it aligns correctly. Then, drape the main top cover cloth over the entire frame.
3. **Expand and Lock Frame:** With the canopy tops in place, push the central hub of the frame upwards until it fully extends and locks into position. Ensure all corner mechanisms are securely locked.
4. **Adjust Height:** Press the red buttons on each leg and extend the legs to your desired height (8.9', 9.2', or 9.5'). Ensure each leg clicks into place at the chosen height.
5. **Attach Mesh Sidewalls:** Use the provided hooks to attach the mesh screen panels to the top edge of the gazebo frame. Zip the panels together to fully enclose the gazebo.
6. **Secure to Ground:** Utilize the provided stakes and ropes to firmly anchor the gazebo to the ground. For hard surfaces, fill the four sandbags with sand or gravel and attach them to the gazebo legs using the Velcro straps for additional stability.

EASY TO SET UP- ✓

STEP 01 ▶

Unfold the gazebo frame and place the cover cloth.



◀ STEP 02

Push the button and lift the gazebo then lock the frame.



STEP 03 ▶▶

Adjust to height as needed.

Image: Step-by-step visual guide for unfolding the frame, attaching the cover, and locking the frame.

Video: Detailed installation process for the Yaheetech Pop Up Gazebo, demonstrating each step from

OPERATING INSTRUCTIONS

The Yaheetech Pop Up Gazebo is designed for versatile outdoor use, providing shade and protection.

- **Adjustable Height:** The gazebo features adjustable heights of 8.9', 9.2', and 9.5' to suit various needs and preferences. Simply press the red button on each leg to raise or lower the canopy.
- **Mesh Netting:** The easily-detachable mesh walls provide all-round protection from insects while maintaining airflow. They can be zipped closed for full enclosure or tied back to open up the space.
- **Vented Top:** The double-tiered roof design promotes effective heat regulation and improved air circulation, enhancing comfort on warm days. It also contributes to enhanced wind resistance.
- **Sun Shade & Water Resistance:** The polyester fabric with PA finish offers ample shade (approx. 121 sq. ft.) and is water-resistant, providing protection from light rain and harmful UV rays.



Image: The gazebo providing a comfortable shaded area in a backyard setting.

Video: Overview of the Yaheetech Pop Up Gazebo's features, including its design, mesh walls, and stability.


MAINTENANCE

Proper maintenance will extend the lifespan of your gazebo.

- **Cleaning:** Clean the fabric canopy and mesh walls with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Storage:** For prolonged service life, it is recommended to fold and store the gazebo during heavy windy and rainy days, or any other extreme weather scenarios. Store in the provided carrying bag in a dry, cool place.
- **Frame Care:** Inspect the powder-coated steel frame periodically for any signs of rust or damage. Clean and touch up any scratches to prevent rust.
- **Drainage:** The canopy features drainage holes to prevent water accumulation. Ensure these remain clear of debris.



UV protection



Waterproof



Drain Holes Prevent
Water Accumulation

***Folding the gazebo on heavy windy and rainy days can prolong its service life.**

Image: Features highlighting UV protection, water resistance, and drainage holes for easy maintenance.

TROUBLESHOOTING

Common issues and their solutions:

| Problem | Possible Cause | Solution |
|---|---|--|
| Gazebo is unstable or sways in wind. | Insufficient anchoring; strong winds. | Ensure all stakes and ropes are properly secured. Fill and attach sandbags to each leg. Disassemble during strong winds. |
| Water accumulates on the canopy. | Drainage holes are blocked; heavy rainfall. | Clear any debris from the drainage holes. While the canopy is water-resistant, it is not designed for heavy rain. Disassemble during heavy rainfall. |
| Difficulty extending/locking frame. | Frame not aligned; mechanism stuck. | Ensure the frame is fully unfolded and aligned before attempting to lock. Apply gentle, even pressure. Do not force. Lubricate joints if necessary. |
| Mesh netting does not close completely. | Zippers misaligned or stuck; netting not properly attached. | Check zipper alignment and clear any obstructions. Ensure all hooks are securely fastened to the frame. |

SPECIFICATIONS

- **Brand:** Yaheetech
- **Model:** YTI4t0001001
- **Product Dimensions:** 131.1"L x 131.1"W x 114.57"H (11x11 ft footprint)
- **Adjustable Heights:** 8.9', 9.2', 9.5'
- **Item Weight:** 42.4 Pounds
- **Material:** Polyester Fabric, Powder-coated Steel, Mesh
- **Frame Material:** Metal
- **Water Resistance Level:** Water Resistant
- **Ultraviolet Light Protection:** Yes
- **Assembly Required:** Yes
- **Occupancy:** 10-15 People
- **Color:** Brown

11FT x 11FT



Easy to set up



Waterproof



Sun-shading



Portable



Image: Detailed dimensions and portability features of the gazebo.

WARRANTY AND SUPPORT

Specific warranty details are not provided in the product information. For any questions, technical support, or warranty claims, please contact Yaheetech customer service directly through their official channels or the retailer where the product was purchased.

Visit the [Yaheetech Store](#) for more information and contact options.