

[Manuals.plus](#) /

› [Fendior](#) /

› Fendior S300 Ultra 2 Smart Watch Set User Manual

Fendior S300 Ultra 2

Fendior S300 Ultra 2 Smart Watch Set User Manual

Model: S300 Ultra 2

1. INTRODUCTION

Thank you for choosing the Fendior S300 Ultra 2 Smart Watch Set. This comprehensive package includes a smart watch, wireless earbuds, 7 interchangeable straps, a charger, and a protective watch case. This manual provides detailed instructions to help you set up, operate, and maintain your device for optimal performance.

Please read this manual carefully before using the product and retain it for future reference.

2. WHAT'S IN THE BOX

Upon opening your Fendior S300 Ultra 2 Smart Watch Set, please verify that all the following items are included:

- Fendior S300 Ultra 2 Smart Watch
- Wireless Earbuds (Airpod style)
- 7 x Interchangeable Straps
- Charging Cable
- Protective Watch Case
- User Manual (this document)



Image 1: The Fendior S300 Ultra 2 Smart Watch Set, showcasing the smart watch, wireless earbuds, 7 straps, charger, and watch case neatly arranged in its packaging.

3. PRODUCT OVERVIEW

3.1 Smart Watch

The Fendior S300 Ultra 2 Smart Watch features a 49mm square display with a touchscreen interface. It operates on an Android-based system and supports Bluetooth connectivity for pairing with your smartphone. Key features include an Always On Display, built-in speaker, and microphone.

3.2 Wireless Earbuds

The included wireless earbuds provide a convenient audio solution for calls and music, seamlessly connecting to your smart watch or smartphone via Bluetooth.

3.3 Interchangeable Straps

The set comes with 7 different straps, allowing for customization to suit various styles and occasions. These straps are designed for easy attachment and removal.



Image 2: A closer view of the Fendior S300 Ultra 2 Smart Watch, wireless earbuds, and the variety of included straps.

4. SETUP

4.1 Charging the Smart Watch and Earbuds

1. Connect the provided charging cable to the smart watch's charging port.
2. Plug the other end of the charging cable into a standard USB power adapter (not included) or a computer's USB port.
3. Allow the smart watch to charge fully before first use. A full charge typically takes 1-2 hours.
4. Place the wireless earbuds into their charging case. Ensure the case is also charged by connecting it to the charging cable if necessary.
5. The smart watch display will indicate charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button (usually on the side of the watch) for a few seconds until the screen lights up.
- **To Power Off:** Press and hold the power button, then select 'Power Off' on the screen.

4.3 Pairing with Your Smartphone

1. Ensure your smart watch is powered on and fully charged.
2. Enable Bluetooth on your smartphone.
3. On your smart watch, navigate to the Bluetooth settings.
4. On your smartphone, search for available Bluetooth devices. Select 'Fendior S300 Ultra 2' from the list.
5. Follow any on-screen prompts to confirm the pairing.
6. For full functionality, download the recommended companion app (refer to the watch's display or packaging for app name) from your smartphone's app store and follow the in-app instructions to complete the setup.

4.4 Pairing Wireless Earbuds

1. Ensure the earbuds are charged and in pairing mode (usually indicated by a flashing LED on the earbuds or case).
2. On your smart watch or smartphone, go to Bluetooth settings and search for new devices.
3. Select the earbuds from the list to pair.

5. OPERATING THE SMART WATCH

5.1 Navigating the Interface

- **Touchscreen:** Swipe left, right, up, or down to navigate through menus and notifications. Tap to select items.
- **Power Button:** Short press to wake/sleep the screen or return to the home screen. Long press for power options.
- **Crown/Rotary Button (if applicable):** Rotate to scroll through lists or zoom in/out. Press to select or return to the home screen.

5.2 Key Features

- **Always On Display:** The screen can remain partially active to show time and basic information without requiring a full wake-up. This feature can be toggled in settings.
- **Notifications:** Receive alerts for calls, messages, and app notifications from your paired smartphone.
- **Fitness Tracking:** Monitor steps, distance, calories burned, and other activity metrics.
- **Heart Rate Monitor:** Measure your heart rate (for reference only, not medical use).
- **Music Control:** Control music playback on your smartphone or directly from the watch if music is stored locally.
- **Calls:** Make and receive calls directly from the watch using its built-in speaker and microphone when connected to your smartphone.

6. MAINTENANCE

6.1 Cleaning

- Wipe the smart watch screen and body with a soft, lint-free cloth.
- For stubborn marks, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the charging contacts periodically with a dry cloth to ensure good connection.
- The straps can be cleaned according to their material type. For silicone or metal straps, a damp cloth is usually

sufficient.

6.2 Water Resistance

The Fendior S300 Ultra 2 Smart Watch is designed to be waterproof for sport use. However, it is not recommended for diving, hot showers, or prolonged submersion. Avoid exposure to hot water, steam, or high-pressure water jets, as this can compromise the seals.

6.3 Storage

When not in use for extended periods, store the smart watch and earbuds in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the devices are partially charged before storage to preserve battery health.

7. TROUBLESHOOTING

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes before attempting to power on again.
- **Cannot pair with smartphone:**
 - Ensure Bluetooth is enabled on both devices.
 - Make sure the watch is in pairing mode.
 - Restart both the watch and the smartphone.
 - Check if the companion app is installed and running correctly.
- **Notifications not appearing:**
 - Verify that the watch is successfully paired with your smartphone.
 - Check notification settings in the watch's settings and the companion app.
 - Ensure your smartphone's notification permissions are granted to the companion app.
- **Earbuds not connecting:** Ensure earbuds are charged and in pairing mode. Try re-pairing them with the watch or smartphone.
- **Inaccurate readings (e.g., heart rate, steps):** Ensure the watch is worn snugly on your wrist, not too loose or too tight. Clean the sensors on the back of the watch.

If you encounter issues not covered here, please refer to the support section or contact customer service.

8. SPECIFICATIONS

Brand	Fendior (Generic)
Model	S300 Ultra 2
Operating System	Android
Display Size	49 Millimetres
Display Resolution	240 x 240
Display Technology	OLED / LCD
Special Features	Always On Display, Built-in Speaker, Built-in Mic, Touchscreen
Connectivity	Bluetooth

Compatible Devices	Smartphone
Item Weight (Package)	475 g
Shape	Square

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Fendior S300 Ultra 2 Smart Watch Set comes with a **3-month warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact your retailer or the manufacturer's customer support. Refer to the product packaging or the retailer's website for specific contact details.

When contacting support, please have your product model number (S300 Ultra 2) and proof of purchase readily available.

© 2024 Fendior. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CV18KWTW>

More documents and user manuals: <https://manuals.plus/>