

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Troy Lighting](#) /
- › [Troy Lighting Bayu F2616 Pendant Light Instruction Manual](#)

Troy Lighting F2616

Troy Lighting Bayu F2616 Pendant Light Instruction Manual

Model: F2616

INTRODUCTION AND SAFETY INFORMATION

This manual provides essential instructions for the safe installation, operation, and maintenance of your Troy Lighting Bayu F2616 Pendant Light. Please read and understand all instructions before beginning installation. Retain this manual for future reference.

Important Safety Instructions:

- Always disconnect power at the main fuse or circuit breaker before installation or servicing.
- Installation must be performed by a qualified electrician in accordance with all local electrical codes.
- Use only the specified bulb type and wattage. The fixture is designed for one light source, compatible with Compact Fluorescent or Incandescent bulbs, up to 15 watts.
- Do not exceed the maximum wattage indicated on the fixture.
- Ensure all connections are secure and properly insulated.
- This fixture is intended for indoor use only.
- Handle the fixture with care, especially the shade, which is crafted from handmade paper.

PACKAGE CONTENTS

Carefully unpack your new pendant light and ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to install the fixture. Contact Troy Lighting customer support.

- Pendant Light Fixture (Bayu F2616)
- Mounting Hardware Kit
- Installation Instructions (this manual)

Note: Bulb is NOT included with this fixture.



Figure 1: Troy Lighting Bayu F2616 Pendant Light. This image shows the complete pendant light fixture, featuring the distinctive paper shade and the forged iron chain for ceiling suspension.

SETUP AND INSTALLATION

This pendant light is designed for ceiling mount installation. Professional installation is recommended.

Tools Required (Not Included):

- Screwdriver (Phillips and/or Flathead)

- Wire Strippers
- Pliers
- Electrical Tape
- Ladder
- Voltage Tester

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where the fixture will be installed. Verify power is off using a voltage tester.
2. **Prepare Mounting Plate:** Attach the mounting plate (included in hardware kit) to the junction box using the provided screws. Ensure it is securely fastened.
3. **Adjust Chain Length:** Determine the desired hanging height for your pendant. Adjust the length of the forged iron chain by removing or adding links as necessary. Secure the chain to the canopy and the fixture.
4. **Make Electrical Connections:** Carefully connect the fixture's wires to the corresponding wires from the junction box.
 - Connect the black (hot) wire from the fixture to the black (hot) wire from the junction box.
 - Connect the white (neutral) wire from the fixture to the white (neutral) wire from the junction box.
 - Connect the green or bare copper (ground) wire from the fixture to the ground wire from the junction box and to the mounting plate.

Secure all connections with wire nuts and electrical tape.

5. **Secure Canopy:** Carefully push the canopy up against the ceiling, covering the junction box and wiring. Secure it to the mounting plate using the provided screws.
6. **Install Bulb:** Insert one compatible bulb (Compact Fluorescent or Incandescent, max 15 watts) into the fixture's socket. (Bulb not included).
7. **Restore Power:** Turn the power back on at the circuit breaker or fuse box. Test the light fixture.

OPERATING INSTRUCTIONS

The Troy Lighting Bayu F2616 Pendant Light operates via a standard wall switch connected to the circuit. Simply toggle the wall switch to turn the light on or off.

MAINTENANCE

Cleaning:

- Ensure power is off before cleaning.
- Wipe the metal components with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- For the paper shade, use a soft, dry brush or a feather duster to gently remove dust. Avoid moisture or liquid cleaners, as they can damage the paper.

Bulb Replacement:

- Turn off power to the fixture at the circuit breaker.
- Allow the old bulb to cool completely before touching it.
- Carefully unscrew the old bulb and dispose of it properly.
- Screw in a new compatible bulb (Compact Fluorescent or Incandescent, max 15 watts).

- Restore power and test the light.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker/fuse.
	Loose wire connection.	Verify all wire connections are secure (ensure power is off first).
	Faulty bulb.	Replace bulb with a new, compatible one.
	Incorrect bulb wattage.	Ensure bulb wattage does not exceed 15 watts.
Light flickers.	Loose wire connection.	Check wire connections (ensure power is off first).
	Faulty bulb.	Replace bulb.

SPECIFICATIONS

- **Model:** F2616
- **Brand:** Troy Lighting
- **Dimensions (L x W x H):** 16.25" x 16.25" x 14.5"
- **Weight:** 4.4 Pounds
- **Material:** Alloy Steel (frame), Handmade Paper (shade)
- **Finish:** Forged Iron
- **Light Source:** 1 (Bulb not included)
- **Bulb Type Compatibility:** Compact Fluorescent, Incandescent
- **Max Wattage:** 15 Watts
- **Voltage:** 120 Volts
- **Mounting Type:** Ceiling Mount
- **Indoor/Outdoor Usage:** Indoor Only
- **UPC:** 197292072492

WARRANTY AND SUPPORT

This Troy Lighting fixture comes with a Limited Warranty. For specific details regarding warranty coverage, claims, or technical support, please contact Troy Lighting directly. Refer to the official Troy Lighting website or your purchase documentation for contact information.

Manufacturer: Troy Lighting

