

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Troy Lighting](#) /
- › [Troy Lighting Lechlan Pendant Light F1523-PBR User Manual](#)

Troy Lighting F1523

Troy Lighting Lechlan Pendant Light User Manual

Model: F1523-PBR

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Troy Lighting Lechlan Pendant Light, Model F1523-PBR. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Troy Lighting Lechlan Pendant Light, featuring a bell-shaped shade handwoven from natural Kalas Abaca in a dense crosshatch pattern. A fabric-covered cord extends from a decorative loop at the top of the shade, designed for ceiling suspension.

SETUP AND INSTALLATION

Safety Information

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with installing electrical wiring.

- This fixture is designed for indoor use only.
- Do not exceed the maximum wattage specified for the bulb.
- Handle the fixture with care. The woven shade is delicate.

What's in the Box

Verify that all components are present before beginning installation:

- Pendant Light Fixture (with woven shade and cord)
- Mounting Bracket
- Mounting Screws
- Wire Nuts
- Canopy/Ceiling Plate

Installation Steps

1. **Turn Off Power:** Locate the circuit breaker or fuse box that supplies power to the light fixture location. Turn off the power completely.
2. **Prepare Mounting:** Attach the mounting bracket to the junction box in the ceiling using the provided mounting screws. Ensure it is securely fastened.
3. **Wire Connections:** Carefully connect the electrical wires. Connect the fixture's live (black) wire to the house's live (black) wire, the fixture's neutral (white) wire to the house's neutral (white) wire, and the fixture's ground (green or bare copper) wire to the house's ground wire. Secure connections with wire nuts.
4. **Secure Fixture:** Tuck the wires neatly into the junction box. Align the canopy/ceiling plate of the pendant fixture with the mounting bracket and secure it with the provided screws or nuts.
5. **Install Bulb:** Insert the appropriate bulb (not included) into the socket. Refer to the specifications for maximum wattage.
6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker or fuse box.

OPERATING INSTRUCTIONS

The Troy Lighting Lechlan Pendant Light operates via a standard wall switch connected to the electrical circuit. Simply toggle the wall switch to turn the light fixture on or off.

Bulb Requirement: This fixture requires one bulb. Ensure the bulb type and wattage comply with the specifications listed in this manual to prevent damage to the fixture or fire hazard.

MAINTENANCE

Cleaning

- Always disconnect power before cleaning.
- To clean the woven abaca shade, gently dust with a soft, dry cloth or a soft brush.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or the natural material.
- For the metal components, wipe with a soft, damp cloth. Dry immediately.

Bulb Replacement

- Ensure the power is turned off at the circuit breaker before replacing the bulb.
- Allow the old bulb to cool completely before touching it.
- Unscrew the old bulb and screw in the new bulb, ensuring it is of the correct type and wattage as specified.
- Restore power after replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker or fuse. Ensure the wall switch is in the 'ON' position.
	Bulb is faulty or loose.	Replace the bulb with a new one. Ensure the bulb is screwed in tightly.
	Incorrect wiring.	Turn off power at the circuit breaker. Recheck all wire connections as per installation instructions. If unsure, consult a qualified electrician.
Light flickers.	Loose bulb or wiring.	Ensure the bulb is tightly screwed in. Check wire connections for looseness (with power off).
	Incompatible dimmer switch.	If using a dimmer, ensure it is compatible with the bulb type.

SPECIFICATIONS

- **Brand:** Troy Lighting
- **Model:** F1523-PBR
- **Product Dimensions:** 22.5 x 22.5 x 19 inches (Width x Length x Height)
- **Item Weight:** 8.8 pounds
- **Material:** Alloy Steel (frame), Brass (shade material - referring to finish/accent), Natural Kalas Abaca (shade)
- **Color:** Patina Brass Finish (Gold)
- **Mounting Type:** Ceiling Mount (Pendant)
- **Number of Lights:** 1
- **Voltage:** 120 Volts
- **Wattage:** 15 Watts (Max)
- **Assembly Required:** Yes
- **UPC:** 197292072218

WARRANTY INFORMATION

Troy Lighting products are manufactured to the highest standards and are backed by a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Troy Lighting website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions regarding the installation, operation, or maintenance of your Troy Lighting Lechlan Pendant Light, please contact Troy Lighting customer support. You can find contact information on the official Troy Lighting website or through your retailer.

Online Resources: For additional information, product updates, and FAQs, please visit the [Troy Lighting Store on Amazon](#).