

[Manuals.plus](#) /

› [CosmoLiving by Cosmopolitan](#) /

› CosmoLiving by Cosmopolitan Westerleigh 2-Door Accent Cabinet Instruction Manual

CosmoLiving by Cosmopolitan 4606918COM

Instruction Manual

COSMOLIVING BY COSMOPOLITAN WESTERLEIGH 2-DOOR ACCENT CABINET

Model: 4606918COM

Product Overview

The CosmoLiving by Cosmopolitan Westerleigh 2-Door Accent Cabinet is designed to provide customizable storage and enhance the aesthetic of any living space. This versatile piece features adjustable shelving and is crafted from durable painted MDF, ensuring ease of cleaning and maintenance. Its design is complemented by golden bronze-capped feet and hardware.

This cabinet is suitable for storing various items such as books or decorative glassware, and can be used individually or paired with another unit to form a larger credenza, console, or buffet cabinet.




Image: Front view of the CosmoLiving Westerleigh 2-Door Accent Cabinet in Pale Green, showcasing its two doors and golden bronze hardware.

Product Specifications

Feature	Detail
Dimensions (Assembled)	33.6" W x 16.1" D x 33.4" H
Item Weight	67.4 lbs
Material	Durable Painted MDF (Engineered Wood)
Color	Pale Green
Number of Shelves	2 (one adjustable)
Maximum Weight Capacity (Top)	50 lbs.
Maximum Weight Capacity (Adjustable Shelf)	25 lbs.

Maximum Weight Capacity (Fixed Shelf)	50 lbs.
Mounting Type	Floor Mount



Product Dimensions

33.6 in. W x 16.1 in. D x 33.4 in. H

Weight Limit: Top - 50 lbs.

Adjustable Shelf - 25 lbs.; Bottom Shelf - 50 lbs.



Black



Pale Pink



Pale Green

Image: Detailed diagram showing the dimensions of the Westerleigh Accent Cabinet, including width, depth, and height, and internal shelf measurements.

Safety Information

Always check the instruction manual thoroughly before assembly and use. Ensure all components are securely fastened according to the assembly instructions to prevent instability. Do not exceed the maximum weight capacities for the top, adjustable shelf, and fixed shelf as specified in the Product Specifications section.

This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, please refer to Proposition 65 warnings.

Setup and Assembly

Assembly of the CosmoLiving Westerleigh 2-Door Accent Cabinet is required. It is recommended that 1-2 adults

participate in the assembly process. The assembly manual included in the packaging contains 12 detailed steps for construction. The product ships in 1 box and contains 10 boards.

During assembly, handle all pieces with care to avoid chipping or scratching the finish. It is advisable to lay pieces on soft surfaces like towels to protect them from tools or hard surfaces.



Medium Assembly Level
1-2 adults recommended to assemble

Item ships in

1

BOX

12

Steps inside the assembly manual

10

Boards inside the box



1 Year Limited Warranty
for Manufacturer Defects



To Clean:
Wipe with a dry cloth
or duster

Image: Graphic indicating a medium assembly level, recommending 1-2 adults, and noting 1 box shipment, 12 assembly steps, and 10 boards. Also includes warranty and cleaning information.

Operating Instructions

The Westerleigh Accent Cabinet features two shelves, one of which is adjustable. To adjust the shelf height, carefully remove the shelf and reposition the shelf pins to the desired level. Ensure the shelf is securely seated on all four pins before placing items on it.

The cabinet doors are equipped with hinges and handles for easy access to the storage compartments. Ensure the doors close properly to protect contents.



Image: Interior view of the Westerleigh Accent Cabinet with its doors open, showing books and other items stored on the adjustable shelf.

Maintenance and Care

To maintain the appearance and longevity of your accent cabinet, regularly wipe it with a dry cloth or duster. Avoid using harsh chemicals or abrasive cleaners, as these may damage the painted MDF finish. Promptly clean any spills to prevent staining.

Warranty Information

This product comes with a 1-Year Limited Warranty covering manufacturer defects. Please retain your proof of purchase for warranty claims. For specific details regarding warranty coverage and claims procedures, refer to the documentation included with your product or contact customer support.

Customer Support

For assistance with assembly, missing parts, or any product-related inquiries, please refer to the customer support

information provided in your product packaging. You may also visit the official CosmoLiving by Cosmopolitan store page on Amazon for additional resources and contact options.

[Visit the CosmoLiving by Cosmopolitan Store](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question