

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Govee](#) /
- > [Govee Outdoor Wall Light Instruction Manual](#)

Govee H7075

Govee Outdoor Wall Light Instruction Manual

Model: H7075

PRODUCT OVERVIEW

The Govee Outdoor Wall Light (Model H7075) is a smart RGBIC porch light designed for outdoor decoration and functional illumination. It offers high brightness, customizable lighting effects, and robust weather resistance.

- **Dream-like Lighting Effects:** Simultaneously displays multiple colors horizontally with flexible DIY options and 45 immersive scene modes.
- **High-brightness White Light:** Up to 1500 lumens with adjustable color temperature (2700K-6500K) for daily accent lighting.
- **Reliability Outdoors:** IP65-waterproof aluminum housing ensures operation in various weather conditions (-4°F to 113°F / -20°C-45°C).
- **Smart Wi-Fi Control:** Control via Govee Home App, Alexa, Google Assistant, and Matter for timers and personalized effects.
- **Motion-Activated (Optional):** Can pair with Govee Outdoor Motion Sensor (sold separately) to trigger lighting effects.



Image: Two Govee Outdoor Wall Lights shown alongside a smartphone displaying the Govee Home App, highlighting smart control capabilities.

INSTALLATION GUIDE

Important Safety Note: Installation must be performed by a licensed electrician in accordance with local electrical codes. Ensure power is turned off at the circuit breaker before beginning any installation work.

- 1. Prepare the Installation Area:** Turn off power to the existing light fixture at the main circuit breaker. Carefully remove the old light fixture.
- 2. Install Backplate:** The Govee Outdoor Wall Light comes with a new mounting bracket (backplate). Securely screw this backplate to the junction box on a flat wall. Ensure it is firmly attached.
- 3. Wire the Wall Light:** Connect the wires from the wall light to your household wiring. The phase wire is typically black, the neutral wire is white, and the ground wire is bare (copper or green). Use the provided twist-on wire connectors to secure the connections.

Your browser does not support the video tag.

Video: Step-by-step guide on how to install the Govee Outdoor Wall Light, including wiring connections.

- 4. Mount the Light Fixture:** Once wiring is complete and wires are neatly tucked into the junction box, position the wall light onto the installed backplate. The light is designed to hinge onto the bracket for easier installation. Secure the light in place using the provided security screws on both sides.

5. **Seal the Fixture:** For optimal weather resistance, apply sealant caulking around the edges of the wall light where it meets the wall. This prevents rainwater from entering.
6. **Restore Power:** Once installation is complete and all connections are secure, turn the power back on at the circuit breaker.




Image: Included components for installation, such as wall light, backplate, screws, and wire connectors.

OPERATING INSTRUCTIONS

Smart Wi-Fi Control via Govee Home App

The Govee Outdoor Wall Light is primarily controlled through the Govee Home App, available for iOS and Android devices. This app provides extensive customization options and smart features.

1. **Download and Pair:** Download the Govee Home App from your device's app store. Follow the in-app instructions to pair your new Govee Outdoor Wall Light.
2. **Color and Brightness Adjustment:** Use the app to select from 16 million colors and adjust the brightness from 1% to 100%. You can also choose between warm white (2700K) and cool white (6500K) light.



Image: Govee Home App interface demonstrating color and brightness controls for the wall light.

3. **Scene Modes:** Explore over 45 preset scene modes for various occasions and moods, including holiday themes and nature-inspired effects.



Image: Govee Home App displaying a selection of 45+ preset scene modes.

4. **DIY Lighting Effects:** Create your own custom lighting effects by segmenting the light and assigning different colors horizontally.



Image: Govee Home App illustrating the DIY customization feature for multi-color display.

5. **Voice Control:** Integrate with Alexa, Google Assistant, and Matter for convenient voice commands.



Image: A user interacting with a smart assistant to control the Govee Outdoor Wall Lights.

6. **Scheduling and Timers:** Set schedules for automatic on/off times and specific lighting effects.

Your browser does not support the video tag.

Video: Demonstration of controlling Govee Outdoor Wall Lights using the Govee Home App, showcasing various features.

MAINTENANCE

The Govee Outdoor Wall Light is designed for durability and minimal maintenance. Its IP65 waterproof rating and aluminum housing protect it from harsh weather conditions.

- **Cleaning:** Periodically clean the exterior of the light with a soft, damp cloth to remove dirt and debris. Avoid using abrasive cleaners or solvents.
- **Sealing Check:** Annually inspect the sealant around the fixture to ensure it remains intact and provides adequate waterproofing. Reapply sealant if cracks or gaps are observed.
- **Environmental Conditions:** The light is designed to operate in temperatures from -4°F to 113°F (-20°C to 45°C). Ensure it is not exposed to conditions outside this range for prolonged periods.

High-brightness White Light

Up to 1500lm and 2700k-6500k color temp




Image: The Govee Outdoor Wall Light demonstrating its IP65 waterproof capabilities in rainy conditions.

TROUBLESHOOTING

While the Govee Outdoor Wall Light is designed for reliable performance, here are some common issues and their potential solutions:

- **Light Not Turning On:**

- Check the circuit breaker to ensure power is supplied to the fixture.
- Verify all wiring connections are secure and correct (black to black, white to white, ground to ground).
- Ensure the light switch is in the ON position.

- **App Connectivity Issues:**

- Ensure your Wi-Fi network is 2.4GHz (the light supports Wi-Fi connectivity).
- Restart the Govee Home App and your smartphone.
- Unplug the light from power for a few seconds and then plug it back in to reset it.
- Ensure your phone is within range of the light and your Wi-Fi router.

- **Inconsistent Lighting Effects:**

- Update the Govee Home App to the latest version.
- Check for firmware updates for the light within the Govee Home App.
- Ensure there are no obstructions blocking the light's output.

For further assistance, please refer to the official Govee support channels or the detailed user manual.

SPECIFICATIONS

Feature	Detail
Brand	Govee
Model Name	H7075
Color	Black
Material	Aluminum, Plastic
Product Dimensions	5.16"L x 2.44"W x 10.35"H
Power Source	AC (120 Volts)
Light Source Type	LED
Brightness	Up to 1500 Lumens
Color Temperature	2700K-6500K
Water Resistance Level	IP65 Waterproof
Control Method	App, Voice (Alexa, Google Assistant, Matter)
Connectivity Protocol	Wi-Fi
Included Components	Outdoor Wall Light, Screw, Twist-on Wire Connector, Backplate, Instruction Manual

WARRANTY AND SUPPORT

The Govee Outdoor Wall Light comes with a **2-year warranty** from the manufacturer.

For detailed information, technical support, or warranty claims, please refer to the official Govee User Manual (PDF) or visit the Govee support website.

Official User Manual (PDF): [Download Here](#)

Govee Store: [Visit Govee Store on Amazon](#)