

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JSP](#) /

> [JSP HardCap AeroLite Bump Cap User Manual](#)

JSP B0CV4FW6K3

JSP HardCap AeroLite Bump Cap User Manual

Model: B0CV4FW6K3

1. INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your JSP HardCap AeroLite Bump Cap. Designed as a safeguard against accidental head bumps, the HardCap AeroLite is ideal for areas where hard hats are not required. Weighing less than 5 oz., this micro brim bump cap is designed to be worn comfortably throughout the day, providing increased ventilation, coolness, and unparalleled comfort.

Important Note: Bump caps are NOT intended for use in ANSI designated hard hat areas. Use the HardCap AeroLite only in areas where a lightweight and comfortable bump cap is required for minor head protection.



Figure 1: Front view of the JSP HardCap AeroLite Bump Cap in black.

2. KEY FEATURES

The JSP HardCap AeroLite is engineered with user comfort and protection in mind. Key features include:

- **Ultra-Lightweight Design:** Weighing less than 5 oz., the HardCap AeroLite ensures day-long comfort without discomfort, making it the perfect choice for extended wear.
- **Ventilation for Coolness and Comfort:** Enjoy increased ventilation that provides unmatched coolness, keeping you comfortable throughout the day.
- **Terry Cloth Sweatband with Polygiene Coating:** Stay comfortable and odor-free with the terry cloth sweatband featuring Polygiene coating.
- **Water-Repellent Shell:** The water-repellent shell prevents staining and discoloration, ensuring durability and longevity.
- **One-Handed Adjuster for Quick Secure Fit:** The unique size adjuster on an elastic strip ensures a quick and secure fit, angled downward to fit under the nape of the neck.



Figure 2: Internal view of the HardCap AeroLite, highlighting the comfortable padding and adjustment mechanism.

3. SETUP AND ADJUSTMENT

The HardCap AeroLite is designed for easy and quick adjustment to ensure a secure and comfortable fit for various head sizes.

1. **Unpack:** Carefully remove the bump cap from its packaging.
2. **Position:** Place the bump cap on your head, ensuring the brim is facing forward and the cap covers the top and sides of your head adequately.
3. **Adjust Fit:** Locate the one-handed adjuster on the elastic strip at the back of the cap. Pull the strap to tighten the fit until the cap feels snug but not uncomfortably tight. The adjuster is angled downward to fit securely under the nape of the neck.
4. **Verify Comfort:** Ensure the cap is stable and does not shift easily when you move your head. The internal padding should feel comfortable against your scalp.

4. OPERATING INSTRUCTIONS AND USAGE

The JSP HardCap AeroLite is intended for use in environments where there is a risk of minor head bumps or scrapes, but where full industrial hard hat protection is not mandated.

- **Intended Use:** Wear the bump cap in areas such as warehouses, manufacturing facilities, maintenance areas, or any indoor/outdoor setting where overhead obstacles or low clearances pose a risk of minor head impact.
- **Proper Wear:** Always wear the bump cap correctly adjusted and securely on your head. The brim should be positioned to offer protection to the forehead.
- **Limitations:** This bump cap does not provide protection against falling objects, significant impacts, or electrical hazards. It is not a substitute for an ANSI-approved hard hat. Always assess the work environment to determine if a higher level of head protection is required.



Figure 3: Example of the HardCap AeroLite being worn by a user in a work environment.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life and effectiveness of your JSP HardCap AeroLite.

- **Cleaning:** The water-repellent shell can be wiped clean with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners, as these may damage the material or coating.

- **Sweatband Care:** The terry cloth sweatband with Polygiene coating is designed to resist odors. It can be gently hand-washed with mild soap and water if necessary. Allow to air dry completely before re-use.
- **Inspection:** Regularly inspect the bump cap for any signs of damage, such as cracks, tears, or deformation of the shell or internal components.
- **Storage:** Store the bump cap in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Replacement:** If the bump cap shows any signs of damage or has sustained a significant impact, it should be replaced immediately, even if visible damage is not apparent.

6. TROUBLESHOOTING

Most issues with the HardCap AeroLite can be resolved with simple adjustments or inspections.

| Problem | Possible Cause | Solution |
|--|---|---|
| Cap feels loose or shifts | Improper adjustment of the elastic strap. | Tighten the one-handed adjuster at the back of the cap until a snug fit is achieved. |
| Cap feels too tight or uncomfortable | Over-tightening of the elastic strap. | Loosen the one-handed adjuster slightly until comfortable. Ensure the internal padding is correctly positioned. |
| Unpleasant odor from sweatband | Accumulation of sweat and bacteria. | Gently hand-wash the sweatband with mild soap and water. Allow to air dry completely. The Polygiene coating helps, but regular cleaning is still recommended. |
| Visible damage to shell or internal components | Impact or wear and tear. | Discontinue use immediately and replace the bump cap. Damaged protective equipment may not provide adequate protection. |

7. SPECIFICATIONS

| Attribute | Detail |
|----------------|--------------------------------------|
| Model Name | HardCap AeroLite |
| ASIN | B0CV4FW6K3 |
| Brand | JSP |
| Weight | Less than 5 oz. |
| Shell Material | Water-repellent fabric |
| Sweatband | Terry Cloth with Polygiene Coating |
| Adjustment | One-handed adjuster on elastic strip |

| Attribute | Detail |
|--------------|--|
| Color | Black (as per current product variant) |
| Department | Mens |
| Manufacturer | JSP |
| Origin | Imported |

8. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation provided with your purchase or contact JSP directly. JSP is committed to providing high-quality personal protective equipment. If you have any questions regarding the use, maintenance, or performance of your HardCap AeroLite Bump Cap, please contact JSP customer support through their official website or the retailer from whom you purchased the product.

Visit the official JSP Store on Amazon: [JSP Safety Inc. Store](#)