

Ceybo RC813 FMB1

Ceybo RC813 FMB1 Voice Remote Control User Manual

MODEL: RC813 FMB1

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Ceybo RC813 FMB1 Voice Remote Control. This remote is designed to work seamlessly with a wide range of TCL QLED Smart TVs, offering convenient control and voice assistant capabilities.



Figure 1: Front and back view of the Ceybo RC813 FMB1 Voice Remote Control. The front features various buttons including navigation, volume, channel, and dedicated app shortcuts. The back is smooth and ergonomic.

Setup

1. Battery Installation

The RC813 FMB1 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Energy efficient

Requires 2 AAA batteries
(*not included*)



Figure 2: Illustration of the battery compartment and proper insertion of AAA batteries.

2. Pairing the Remote Control

To ensure full functionality, including voice control, the remote must be paired with your TCL Smart TV. Follow these steps:

1. Ensure your TCL Smart TV is powered on.
2. Point the remote control towards the TV.
3. Simultaneously press and hold the "**OK**" button (center of the navigation pad) and the "**Home**" button (house

icon) for approximately 2 seconds.

4. A pairing confirmation message should appear on your TV screen, indicating successful pairing.
5. If pairing fails, ensure the batteries are correctly installed and try again. Move closer to the TV if necessary.

Operating the Remote

Button Functions Overview

The RC813 FMB1 remote control features a variety of buttons for intuitive navigation and control of your TCL Smart TV. Refer to the image below for button layout.

- ▶ Quick access
- ▶ App shortcuts
- ▶ Compact design



Figure 3: The remote's design emphasizes quick access, app shortcuts, and a compact form factor for ease of use.

- **Power Button (>):** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right):** Used to navigate menus and select options.
- **OK Button:** Confirms selections or opens items.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button (House Icon):** Returns to the TV's home screen.
- **Volume Up/Down:** Adjusts the TV's volume level.
- **Channel Up/Down:** Changes TV channels.
- **Settings Button (Gear Icon):** Accesses TV settings.
- **Input Button:** Changes the TV's input source.

Voice Assistant Functionality

The remote features a dedicated button for Google Assistant, allowing you to control your TV and search for content using voice commands.

- **Google Assistant Button (Microphone Icon):** Press and hold this button, then speak your command clearly into the remote. Release the button when you are finished speaking.

- Examples of commands include: "Open Netflix," "Search for action movies," "What's the weather like?", "Turn up the volume."

Dedicated Shortcut Buttons

Quickly access your favorite streaming services and TCL features with the dedicated shortcut buttons located at the bottom of the remote.




Figure 4: Dedicated shortcut buttons for popular streaming services and TCL applications.

- **Netflix:** Direct access to the Netflix streaming service.
- **Prime Video:** Direct access to Amazon Prime Video.
- **YouTube:** Direct access to YouTube.
- **TCL Channel:** Direct access to the TCL Channel.
- **TCL Home:** Direct access to TCL Home features.
- **Apple TV:** Direct access to Apple TV.

Compatibility

The Ceybo RC813 FMB1 Voice Remote Control is compatible with a wide range of TCL QLED Smart TV models, including those with Google TV functionality. Below is a list of some compatible models:

Compatible with



65R646



75S546

Check the compatibility list below

Figure 5: Examples of compatible TCL QLED TV models.

- Google TV 65Q750G
- Google TV 55Q750G
- Google TV 75Q750G
- Google TV 50Q750G
- Google TV 43Q750G
- Google TV 58Q750G
- 65QM850G
- 55QM850G
- 75QM850G
- 58QM850G
- And many more TCL QLED Smart TV models.

Note: Always verify compatibility with your specific TV model before use.

Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

- Always replace both AAA batteries at the same time.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.

Cleaning the Remote

To maintain the remote control's appearance and functionality, clean it periodically.

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the remote's finish or internal components.

Troubleshooting

If you encounter issues with your Ceybo RC813 FMB1 remote control, refer to the following common problems and their solutions:

Problem	Possible Cause / Solution
Remote is not responding.	<ul style="list-style-type: none">• Check if batteries are correctly installed and have sufficient charge. Replace if necessary.• Ensure there are no obstructions between the remote and the TV's sensor.• Re-pair the remote with the TV (refer to "Pairing the Remote Control" section).
Voice control is not working.	<ul style="list-style-type: none">• Ensure the remote is successfully paired via Bluetooth. Voice functionality requires Bluetooth connection.• Speak clearly and directly into the microphone on the remote.• Check TV's internet connection for Google Assistant functionality.
Shortcut buttons are not working.	<ul style="list-style-type: none">• Ensure the remote is properly paired.• Verify that the corresponding apps are installed and updated on your TCL Smart TV.

Specifications

Feature	Detail
Model Number	RC813 FMB1

Feature	Detail
Brand	Ceybo
Connectivity Technology	Bluetooth
Compatible Devices	TCL QLED Smart Televisions
Special Feature	Voice Search (Google Assistant)
Power Source	2 x AAA Batteries (not included)
Item Weight	3.2 ounces (approx. 90.7 grams)
Package Dimensions	8 x 2 x 0.5 inches (approx. 20.3 x 5.1 x 1.3 cm)

© 2024 Ceybo. All rights reserved.

For further assistance, please visit the [Ceybo Store on Amazon](#).