

[Manuals.plus](#) /

› [SEDETA](#) /

› SEDETA L Shaped Desk with Drawers, 62.2" Home Office Desk with Fabric File Drawers and Power Outlet, L Shaped Desk with Hutch, Storage Shelves, LED Lights, Rustic Brown

SEDETA 351_1-brown

SEDETA L Shaped Desk User Manual

Model: 351_1-brown

Brand: SEDETA

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SEDETA L Shaped Desk. Designed for home office use, this versatile desk offers ample workspace, integrated storage, and modern features like LED lighting and a power outlet. Please read this manual thoroughly before assembly and use to ensure proper setup and safe operation.




Figure 1: SEDETA L Shaped Desk in a typical home office environment, showcasing its L-shape configuration, hutch, and integrated LED lighting.

IMPORTANT SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury or damage to the product:

- **WARNING:** This desk requires proper assembly for stability. Ensure all screws are tightened securely, especially at the tabletop joints. Do not use the desk until fully assembled.
- Keep electrical components (power outlet, LED lights) dry and away from water to prevent electrical shock.
- This desk is heavy (approximately 77 pounds) and may pose lifting hazards. Use caution when moving or assembling the desk. It is recommended that **2 people** assemble this product.
- Do not overload shelves or drawers. Refer to specifications for weight capacities if available.
- Ensure the desk is placed on a level surface to prevent wobbling and instability.

PRODUCT FEATURES

Desk with Fabric Drawers

The SEDETA office desk includes two fabric file drawers designed to hold various sizes of documents, including Letter or A4 size files. These drawers provide convenient storage for office supplies and personal items, helping to keep your workspace organized.



Figure 2: Detail of the two fabric drawers, suitable for legal, letter, or A4 size files, offering versatile storage solutions.

Reversible Configuration

This desk offers flexible configuration options. It can be assembled as a 62.2-inch L-shaped corner desk, ideal for maximizing space in a corner, or as an 86.6-inch long office desk, suitable for two-person use without interference. The top hutch can also be positioned on either the left or right side to suit your specific needs and room layout.




Figure 3: Visual representation of the desk's reversible design, illustrating both the L-shaped (62.2-inch) and long (86.6-inch) configurations with key dimensions.



Figure 4: Detailed diagrams showing four possible assembly configurations, highlighting the versatility of the desk's design.

Multiple Storage Options

Beyond the fabric drawers, the desk features a storage cabinet door and a top hutch. This multi-tiered storage system allows for efficient classification and organization of books, files, and other supplies, reducing desktop clutter and providing ample space under the desk.



Figure 5: The hutch provides both open shelving and enclosed cabinet space for diverse storage needs.

Integrated Charging Port

The desk is equipped with a convenient charging station that includes 4 AC outlets (125V/12A) and 2 USB ports (5V/2A). This allows you to power and charge up to 6 devices simultaneously, such as cell phones, tablets, and notebooks. A dedicated on-off switch ensures safe electricity use with a single button.




Figure 6: The built-in power strip with multiple outlets and USB ports for convenient device charging.

Cool & Smart LED Light Strips

Enhance your workspace ambiance with the included RGB LED light strip. Control it via a remote or a dedicated APP, choosing from over 60,000 colors and 29 flashing modes. The LED light strip also features a music sync function with a built-in adjustable microphone, allowing the light color to change with the rhythm of sound and music. A timer function is also available for smart control.



Figure 7: The desk illuminated by its RGB LED light strip, highlighting the various control options and dynamic lighting effects.

SETUP AND ASSEMBLY

The SEDETA L Shaped Desk is designed for straightforward assembly. While detailed step-by-step instructions are provided in the product packaging, here are general guidelines and important considerations:

- **Preparation:** Unpack all components and verify against the parts list provided in your instruction manual. Ensure all parts are present and undamaged.
- **Tools:** This product does not include all assembly tools. Please ensure you have the necessary tools as specified in the manual (e.g., screwdriver, hammer).
- **Team Assembly:** It is highly recommended that **two people** participate in the assembly process due to the size and weight of the desk components (Item Weight: 77 Pounds).
- **Configuration Choice:** Decide whether you will assemble the desk in the L-shaped corner configuration (62.2 inches) or the long office desk configuration (86.6 inches) before beginning. This choice will dictate the arrangement of certain components.

- **Component Identification:** Parts are typically labeled for easy identification during assembly. Follow the numerical or alphabetical sequence provided in your manual.
- **Secure Connections:** Ensure all screws, bolts, and fasteners are tightened securely at each step to guarantee the desk's stability and durability.



Figure 8: The desk assembled in its 86.6-inch long configuration, demonstrating ample space for multiple users or extensive setups.

Assembly Videos

Currently, there are no official seller-provided assembly videos available for this product. Please refer to the detailed written instructions and diagrams included in your product packaging for assembly guidance.

OPERATING INSTRUCTIONS

Using the Fabric Drawers

The two fabric drawers are designed for easy access and organization. Simply pull the handle to open and push to close. The internal bar allows for hanging file folders (Letter/A4 size) to keep documents neatly arranged. Ensure drawers are not overloaded to maintain smooth operation.

Utilizing the Integrated Power Outlet

To use the power outlet, ensure the desk's power cord is properly connected to a wall power source. Plug your devices into the 4 AC outlets or 2 USB ports. Use the red on/off switch located on the power strip to control power to all connected devices. Always turn off the switch when not in use or before unplugging the desk from the wall.

Controlling the LED Lights

The RGB LED light strip can be controlled via a physical remote control or a dedicated smartphone application. Refer to the separate LED light instruction sheet for specific pairing and operation details. Key functions include:

- **Color Selection:** Choose from over 60,000 colors.
- **Mode Selection:** Select from 29 flashing modes for dynamic lighting effects.
- **Music Sync:** Activate the music sync function to have the lights react to sound and music via the built-in microphone.
- **Timer Function:** Set a timer for the lights to automatically turn on or off.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your SEDETA L Shaped Desk:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the PVC laminate finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage to the engineered wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the desk remains stable.
- **Heat and Moisture:** Avoid placing hot items directly on the desk surface. Use coasters for drinks. Keep the desk away from direct sunlight and excessive humidity.
- **Adjustable Feet:** The adjustable feet protect your floor and ensure stability. Periodically check that they are properly adjusted and not causing scratches.



Figure 9: Adjustable feet provide stability and floor protection, allowing for minor leveling adjustments.

TROUBLESHOOTING

If you encounter issues with your SEDETA L Shaped Desk, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Desk is wobbly/unstable.	Loose fasteners; uneven floor; improper assembly.	Check and tighten all screws and bolts. Adjust the leveling feet on the bottom of the desk legs. Review assembly instructions to ensure all parts are correctly installed.

Problem	Possible Cause	Solution
Power outlet not working.	Not plugged in; power switch off; circuit breaker tripped.	Ensure the desk's power cord is securely plugged into a working wall outlet. Verify the red on/off switch on the power strip is in the "on" position. Check your home's circuit breaker.
LED lights not functioning.	Not powered; remote/app issue; loose connection.	Ensure the LED lights are properly connected to the power source (often via the integrated power outlet). Check batteries in the remote control. Re-pair the remote/app if necessary. Verify all light strip connections are secure.
Drawers are sticking or difficult to open/close.	Overloaded; obstruction; misaligned.	Reduce the weight or volume of items in the drawers. Check for any objects obstructing the drawer's path. Ensure the fabric drawers are correctly inserted and aligned within their compartments.

SPECIFICATIONS

Attribute	Detail
Brand	SEDETA
Model Number	351_1-brown
Product Dimensions	19"D x 66.2"W x 65"H (L-shaped configuration)
Long Desk Width	86.6 inches (when configured as a long desk)
Color	Rustic Brown
Style	Farmhouse
Base Material	Metal
Top Material Type	Engineered Wood (with PVC laminate finish)
Special Features	Reversible, Built-In USB Outlet, RGB LED Light Strips
Recommended Uses	Office, Working, Gaming, Writing
Number of Drawers	2 (Fabric File Drawers)
Number of Shelves	1 (in hutch)
Number of Cabinets	1 (in hutch)
Item Weight	77 Pounds
Required Assembly	Yes
Recommended People for Assembly	2
Includes All Assembly Tools	No

WARRANTY AND SUPPORT

The SEDETA L Shaped Desk comes with a**Limited Warranty**. For specific warranty terms, conditions, and duration, please refer to the warranty information included in your product packaging or contact SEDETA customer support directly. For any questions, missing parts, or assistance with assembly or operation, please reach out to the manufacturer's customer service. Contact information can typically be found on the product packaging or the brand's official website.

© 2025 SEDETA. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question