



Manuals.plus /

› SONGMICS /

› SONGMICS Electric Sit-Stand Desk User Manual

SONGMICS LSD134W01

SONGMICS Electric Sit-Stand Desk User Manual

Model: LSD134W01

Brand: SONGMICS

1. INTRODUCTION

Thank you for choosing the SONGMICS Electric Sit-Stand Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and retain it for future reference.

Key Features:

- **Strong and Stable:** Features a sturdy steel frame and particle board construction, supporting up to 70 kg for a reliable workspace at any height.
- **Premium Motor:** Ensures smooth and quiet height adjustment (below 50dB) for a peaceful working environment.
- **Flexible and Safe Height Adjustment:** Adjustable height range from 72 cm to 120 cm. Includes 4 memorizable height settings for quick transitions. An anti-collision feature automatically reverses movement if an obstacle is detected.
- **Organized Workspace:** Equipped with a durable oxford cloth pouch for storage, a hook for headphones or bags, and two cable management holes to keep your desk tidy.
- **Easy Assembly:** Designed for straightforward assembly with labeled parts and clear instructions.



An overview of the SONGMICS Electric Sit-Stand Desk, showcasing its spacious white desktop and sturdy frame, equipped with a laptop, dual monitors, and various office accessories.

SONGMICS
by SONGMICS HOME



The SONGMICS Electric Sit-Stand Desk positioned in a well-lit home office, demonstrating its aesthetic appeal and how it fits into a contemporary workspace with a comfortable chair and shelving.

2. SAFETY WARNINGS

- Ensure all components are securely fastened before use.
- Do not overload the desk beyond its maximum weight capacity of 70 kg.
- Keep children and pets away from the desk during height adjustment to prevent injury.
- Do not place hands or objects in the path of moving parts during operation.
- Only use the provided power adapter and ensure it is connected to a grounded outlet.

- If the desk malfunctions or makes unusual noises, disconnect power immediately and contact customer support.
- Avoid spilling liquids on the control panel or motor components.
- The anti-collision feature is a safety aid, but always be aware of your surroundings during adjustment.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact SONGMICS customer service.

- Desktop Panel
- Leg Frames (Left & Right)
- Motor and Control Box
- Control Panel with Display
- Power Adapter and Cable
- Storage Pouch
- Headphone Hook
- Assembly Hardware (Screws, Allen Keys, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of your SONGMICS Electric Sit-Stand Desk is designed to be straightforward. Follow the numbered steps and refer to the labeled parts for a smooth installation process.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the package contents list.
2. **Attach Leg Frames:** Secure the leg frames to the desktop panel using the provided screws. Ensure they are aligned correctly and tightened firmly.
3. **Install Motor and Control Box:** Mount the motor and control box to the designated positions under the desktop, following the pre-drilled holes.
4. **Connect Cables:** Connect the motor cables to the control box, and then connect the control panel cable to the control box. Ensure all connections are secure.
5. **Attach Control Panel:** Mount the control panel to the front edge of the desk in an easily accessible location.
6. **Install Accessories:** Attach the storage pouch and headphone hook to the desired locations on the desk frame.
7. **Cable Management:** Route all cables neatly using the integrated cable management holes and any provided cable ties to prevent tangles and ensure safety.
8. **Connect Power:** Plug the power adapter into the control box, and then plug the power cord into a wall outlet.

Once assembled, ensure the desk is stable and all connections are secure before initial operation.

5. OPERATING INSTRUCTIONS

Height Adjustment:

The desk's height can be adjusted between 72 cm and 120 cm.

- **Raise Height:** Press and hold the **UP (▲)** button on the control panel. The desk will move upwards. Release the button at your desired height.
- **Lower Height:** Press and hold the **DOWN (▼)** button on the control panel. The desk will move downwards. Release the button at your desired height.

Memory Presets:

The desk allows you to save up to 4 preferred height settings for quick recall.

1. **Set a Memory Height:** Adjust the desk to your desired height using the UP/DOWN buttons.
2. Press the **M** button (or 'S' on some models) once. The display will show 'S-' or 'M-'.
3. Within 3 seconds, press one of the memory buttons (**1, 2, 3, or 4**). The current height will be saved to that preset.
4. **Recall a Memory Height:** Simply press the corresponding memory button (**1, 2, 3, or 4**). The desk will automatically move to the saved height.

Anti-Collision Feature:

For safety, the desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage or injury.



Two individuals are shown using the desk: one seated at a lower height and another standing at a raised height, illustrating the desk's adjustable functionality. A close-up of the control panel with height display and memory buttons (M1, M2, M3, M4) is also visible.



Detailed view of the desk's organizational features, including a durable oxford cloth storage pouch for books and stationery, a convenient hook for headphones or bags, and two integrated holes for efficient cable management.



A visual representation of the desk's safety mechanism, showing that the height adjustment automatically reverses slightly if an obstacle is detected, preventing damage or injury.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure cables are not pinched or tangled, which could affect desk operation or

cause damage.

- **Motor Care:** The motor is maintenance-free. Do not attempt to open or lubricate it.
- **Weight Distribution:** Distribute weight evenly on the desktop to ensure smooth operation and prolong the desk's lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Control box error; Overload.	Check power connections. Unplug and replug the power for 10 seconds. Reduce weight on desk.
Desk moves unevenly.	Uneven weight distribution; Loose connections.	Distribute weight evenly. Check and tighten all assembly screws.
Display shows an error code (e.g., E01, E02).	Motor overheating; Sensor error.	Allow the desk to cool down for 20 minutes. Unplug and replug power. If error persists, contact support.
Anti-collision feature triggers too easily.	Sensitivity setting; Obstruction.	Ensure no objects are near the desk's path. Refer to control panel instructions for sensitivity adjustment (if available).

If you encounter issues not listed here or if solutions do not resolve the problem, please contact SONGMICS customer support.

8. SPECIFICATIONS

Brand	SONGMICS
Model Number	LSD134W01 (also referred to as LSD03X01)
Color	Cloud White
Dimensions (L x W x H)	140 cm x 60 cm x (72-120) cm
Adjustable Height Range	72 cm - 120 cm
Maximum Weight Capacity	70 kg (154 lbs)
Item Weight	23.9 Kilograms
Noise Level	Below 50dB
Assembly Required	Yes
Number of Drawers	1 (referring to the storage pouch)



A technical diagram illustrating the key dimensions of the desk: 140 cm length, 60 cm width, and adjustable height from 72 cm to 120 cm. It also highlights the maximum weight capacity of 70 kg.

9. WARRANTY AND SUPPORT

SONGMICS is committed to providing high-quality products and excellent customer service. For warranty information, technical support, or any questions regarding your Electric Sit-Stand Desk, please contact SONGMICS customer service through the retailer's platform or visit the official SONGMICS website. Please have your model number (LSD134W01) and purchase details ready when contacting support.

For more information, visit the SONGMICS Store on Amazon.

