

SONGMICS LSD132W01

SONGMICS LSD132W01 Height-Adjustable Electric Desk User Manual

Model: LSD132W01

Brand: SONGMICS

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SONGMICS LSD132W01 Height-Adjustable Electric Desk. Please read this manual thoroughly before use to ensure proper function and safety.

2. PACKAGE CONTENTS

Please verify that all components listed below are present in your package:

- 1 x Electric Desk
- 1 x Fabric Organiser
- 3 x Hooks (2 for organiser)
- 1 x Accessory Pack
- 1 x Instruction Manual



Image: The SONGMICS LSD132W01 Height-Adjustable Electric Desk in Cloud White, showcasing its clean design and integrated fabric organizer.

3. SAFETY INFORMATION & IMPORTANT NOTES

- Do not place the table directly against a wall during the lifting and lowering process to prevent scratches or damage.
- The adjustable desk is intended for indoor use only.
- Keep all electrical components away from liquids to prevent electric shock or damage.
- If the electric desk is raised or lowered continuously for 2 minutes, the overheating protection will automatically activate. You must wait 18 minutes before using the height adjustment function again.
- To protect the worktop from impacts and scratches, adjust the built-in sensor to a higher sensitivity value to detect solid objects during height adjustment.



Image: A visual representation of the desk's anti-collision mechanism, showing how it detects obstacles and reverses movement to prevent damage.

4. ASSEMBLY

The SONGMICS LSD132W01 desk is designed for straightforward assembly. All parts are marked, and clear instructions are provided in the accessory pack. Follow the step-by-step guide to ensure correct and secure setup.

SONGMICS

by SONGMICS HOME



Image: The SONGMICS electric desk integrated into a modern home office environment, demonstrating its functional use.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The desk's height can be adjusted electrically between 72 cm and 120 cm. Use the up and down arrow buttons on the control panel to precisely set your desired height.

5.2. Memory Function

The control panel allows you to store up to 4 preferred height settings for quick adjustments. To save a height:

1. Adjust the desk to the desired height.
2. Press and hold one of the memory buttons (M1, M2, M3, or M4) until the display confirms the setting is saved.

To recall a saved height, simply press the corresponding memory button (M1-M4).



Image: Close-up of the desk's control panel, showing the digital height display, up/down arrows, and four memory preset buttons (M1-M4).

5.3. Organization Features

The desk includes a fabric organizer for storing books and stationery, and a hook for hanging headphones or bags. Two holes are also provided for efficient cable management, helping to maintain a tidy workspace.



Image: Detailed view of the desk's integrated fabric organizer, designed to hold books and stationery, and a hook for hanging items like headphones or bags.

6. MAINTENANCE

- Regularly wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners.
- Check all screws and connections periodically to ensure they remain tight.

- Keep the motor and electrical components free from dust and debris.

7. TROUBLESHOOTING

- **Desk not moving:** Check if the power cord is securely plugged in. Ensure the overheating protection is not active (wait 18 minutes if it was used continuously for 2 minutes).
- **Desk stops unexpectedly:** The anti-collision sensor may have detected an obstacle. Remove any obstructions and try again. Consider adjusting the sensor sensitivity if this occurs frequently without an obvious obstacle.
- **Unusual noises:** Ensure the desk is on a level surface and all assembly screws are tightened.

8. SPECIFICATIONS



Image: A technical diagram illustrating the key dimensions (length, width, height range) and maximum static load capacity (70 kg) of the SONGMICS electric desk.

Feature	Detail
Brand	SONGMICS
Model Number	LSD132W01
Color	Cloudy White

Material	Wood chipboard, Steel, Oxford fabric
Product Dimensions (D x W x H)	60 x 120 x (72-120) cm (23.62"D x 47.24"W x 28.43"H)
Item Weight	21.8 kg (48.06 lbs)
Max. Static Load Capacity	70 kg (154 lbs)
Height Adjustment Range	72 cm - 120 cm (28.3 in - 47.2 in)
Motor Noise Level	< 50 dB
Special Features	Adjustable Height, Memory Function (4 presets), Anti-Collision, Fabric Organizer, Cable Management
Assembly Required	Yes

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SONGMICS website. You can also visit the [SONGMICS Store on Amazon](#) for additional product information and contact options.