

[Manuals.plus](#) /

› [MSI](#) /

› MSI Thin A15 B7UC-067IN Gaming Laptop User Manual

MSI B7UC-067IN

MSI Thin A15 B7UC-067IN Gaming Laptop User Manual

Model: B7UC-067IN

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MSI Thin A15 B7UC-067IN gaming laptop. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device.



Image: The MSI Thin A15 laptop with its lid open, showcasing the keyboard and display.

2. SETUP

2.1 Unboxing and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Verify that all components are present:

- MSI Thin A15 Laptop
- Power Adapter
- Power Cord

Inspect the laptop for any physical damage. If any damage is found, contact your retailer immediately.

2.2 Connecting the Power Adapter

Connect the power adapter to the laptop's power input port and then plug the power cord into a wall outlet. The laptop can be used while charging.



Image: Side profile of the MSI Thin A15, highlighting the available connectivity ports.

2.3 First Power On and Windows Setup

Press the power button located on the keyboard deck to turn on the laptop. Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes setting up your region, language, network connection, and user account.

2.4 Connecting Peripherals

You can connect external devices such as a mouse, keyboard, or external display using the available USB ports and HDMI port. The laptop supports Bluetooth v5.3 for wireless peripherals.

3. OPERATING INSTRUCTIONS

3.1 Basic Operation

The MSI Thin A15 features a backlit keyboard and a precision touchpad for navigation. Familiarize yourself with the keyboard layout and function keys (Fn) for quick access to system settings like volume, brightness, and Wi-Fi.



Image: Top view of the MSI Thin A15 keyboard, showing the backlit keys.

3.2 Display Settings

Your laptop is equipped with a 40cm FHD (1920x1080) 144Hz IPS-Level display. To optimize your viewing experience, especially for gaming, ensure the display refresh rate is set to 144Hz in Windows display settings.



Image: The MSI Thin A15 display showcasing its 144Hz refresh rate capability during gameplay.

3.3 MSI Center Software

The pre-installed MSI Center software allows you to monitor system performance, customize gaming modes, adjust fan speeds with Cooler Boost, and manage various laptop settings. Explore its features for an optimized user experience.



Image: Visual representation of the Cooler Boost feature, indicating enhanced cooling and reduced noise.

3.4 Gaming Performance

The laptop features an AMD Ryzen 5 7535HS processor and NVIDIA GeForce RTX 3050 graphics. For optimal gaming performance, ensure your graphics drivers are up to date and utilize the performance modes available in MSI Center.




Image: A detailed graphic of the AMD Ryzen 7000 Series processor, highlighting its advanced architecture.



Image: The MSI Thin A15 laptop showcasing its NVIDIA GeForce RTX graphics capabilities during a gaming session.

4. MAINTENANCE

4.1 Cleaning

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft brush or compressed air to remove dust. Wipe surfaces with a slightly damp cloth.
- **Vents:** Regularly clean the air vents on the bottom and sides of the laptop with compressed air to prevent dust buildup and maintain optimal cooling.



Image: The underside of the MSI Thin A15 laptop, illustrating the cooling vents.

4.2 Software Updates

Regularly update your Windows operating system, graphics drivers (NVIDIA), and MSI utilities to ensure system stability, security, and optimal performance.

4.3 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. For extended storage, charge the battery to about 50-60% and store the laptop in a cool, dry place.

4.4 Storage Management

Periodically check your 512GB NVMe PCIe Gen4x4 SSD for available space. Uninstall unused applications and delete unnecessary files to maintain system responsiveness.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your MSI Thin A15 laptop.

5.1 Laptop Not Powering On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Verify the power outlet is functional by plugging in another device.
- If the battery is completely drained, allow it to charge for at least 30 minutes before attempting to power on again.

5.2 Display Issues

- If the screen is black, try connecting an external monitor to check if the laptop is outputting a signal.
- Adjust screen brightness using the function keys.
- Ensure graphics drivers are updated.

5.3 Overheating

- Ensure the laptop's vents are clear of obstructions and dust.
- Use the Cooler Boost function in MSI Center to increase fan speed.
- Operate the laptop on a hard, flat surface to allow for proper airflow.

5.4 Poor Battery Life

- Adjust power settings in Windows to a more power-efficient mode.
- Reduce screen brightness.
- Close unnecessary background applications.
- Ensure battery drivers are updated.

5.5 System Lag or Freezing

- Close unnecessary applications running in the background.
- Check Task Manager for processes consuming high CPU or RAM.
- Ensure Windows and drivers are up to date.
- Run a system scan for malware.

6. SPECIFICATIONS

Below are the key technical specifications for the MSI Thin A15 B7UC-067IN laptop:

Feature	Specification
Model Name	Thin A15
Model Number	B7UC-067IN
Processor	AMD Ryzen 5 7535HS (Up To 4.5GHz)
Graphics Card	NVIDIA GeForce RTX 3050, GDDR6 4GB

Feature	Specification
RAM Memory	16GB DDR5 (8GBx2 Dual Channel)
Storage	512GB NVMe PCIe Gen4x4 SSD
Operating System	Windows 11 Home (Pre-loaded)
Display	40cm (15.6-inch) FHD (1920x1080), 144Hz, 45%NTSC, IPS-Level
Wireless Connectivity	Wi-Fi 6 + Bluetooth v5.3
Weight	1.86 Kg
Dimensions (L x W x Th)	35.9L x 25.4W x 2.1Th Centimeters
Battery Life (Approx.)	6 Hours

7. WARRANTY AND SUPPORT

Your MSI Thin A15 laptop comes with a**2-Year Carry-in warranty**. This warranty covers manufacturing defects from the unit's shipped date.

7.1 Warranty Validation

To validate your warranty and for self-service options, please visit the official MSI support page:

<https://in.msi.com/support/nb>

Assured, Always

Get nothing but the best with assured 2 Years Brand Warranty*

Validate Your Warranty

Self Service:

Visit: <https://in.msi.com/support/nb>



Queries on Warranty? Get in touch with us.



Visit us

More than 80 centres
all over India



Call us (9 to 5)

+91-22-4912 5588



Mail us

indiaservicenb@msi.com

*By default, the unit comes with two-years base domestic warranty from the unit shipped date and can be corrected by contacting MSI.

Image: MSI warranty and support contact information, including website, phone, and email.

7.2 Contacting Support

For any queries regarding your warranty or product support, you can contact MSI through the following channels:

- **Visit:** More than 80 service centers across India.
- **Call:** +91-22-4912 5588 (9 AM to 5 PM)
- **Email:** indiaservicenb@msi.com

Note: By default, the unit comes with a two-year base domestic warranty from the unit shipped date and can be corrected by contacting MSI.

8. VIDEO RESOURCES

Currently, no official product videos are available for embedding in this manual. Please refer to the MSI official website or authorized channels for any available video guides or demonstrations.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question