

[Manuals.plus](#) /

› [Klipsch](#) /

› Klipsch Flexus CORE 200 Sound Bar User Manual

Klipsch Core 200

Klipsch Flexus CORE 200 Sound Bar User Manual

Model: Core 200

INTRODUCTION

The Klipsch Flexus CORE 200 is a 3.1.2 channel sound bar designed to deliver immersive audio experiences for your home entertainment system. Featuring Dolby Atmos technology and custom-tuned bass, this sound bar is engineered to provide clear dialogue and powerful sound. It is powered by Onkyo, combining robust manufacturing with classic Klipsch acoustics for reliable performance.



Figure 1: Angled view of the Klipsch Flexus CORE 200 Sound Bar.

SAFETY INFORMATION

Please read all safety instructions carefully before operating this product. Retain this manual for future reference.

- Do not expose this appliance to dripping or splashing.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Ensure proper ventilation. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Klipsch Flexus CORE 200 Sound Bar (Speaker)
- Remote Control
- Power Cable
- HDMI Cable
- Wall Mount Template and Hardware (if applicable)
- Quick Start Guide



Figure 2: The Klipsch Flexus CORE 200 Sound Bar, the primary component included in the package.

Follow these steps to set up your Klipsch Flexus CORE 200 Sound Bar:

1. **Placement:** Place the sound bar on a stable, flat surface directly below your television, or mount it to the wall using the provided template and hardware. Ensure it is centered for optimal sound distribution.




Figure 3: Front view of the sound bar, illustrating its sleek design for optimal placement.

2. Connections:

- Connect the HDMI cable from the sound bar's HDMI eARC/ARC port to your TV's HDMI eARC/ARC port. This is the recommended connection for Dolby Atmos and best audio quality.
- Alternatively, connect an optical cable from the sound bar's OPTICAL input to your TV's optical digital audio output.
- If using an external subwoofer, connect it to the dedicated wired subwoofer output (RCA connection) on the sound bar.



Figure 4: Rear view of the sound bar, showing the various input and output ports for connection.

3. **Power:** Connect the power cable to the sound bar and then to a wall outlet. The sound bar will enter standby mode.
4. **Initial Power On:** Press the power button on the sound bar or the remote control to turn it on. The display on the sound bar will illuminate.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Press the **Power** button on the remote or sound bar.
- **Volume Control:** Use the **Volume Up (+)** and **Volume Down (-)** buttons on the remote.
- **Input Selection:** Press the **Input** button on the remote to cycle through available inputs (HDMI, Optical, Bluetooth).
- **Mute:** Press the **Mute** button to temporarily silence the sound. Press again to unmute.

Bluetooth Pairing

To connect a Bluetooth device:

1. Press the **Bluetooth** button on the remote or sound bar. The Bluetooth indicator will flash.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Klipsch Flexus CORE 200".
3. Select the sound bar from the list of available devices to pair. Once connected, the Bluetooth indicator will glow solid.

Dolby Atmos and Sound Modes

The Klipsch Flexus CORE 200 supports Dolby Atmos for an immersive, multidimensional sound experience. The sound bar automatically detects and processes Dolby Atmos content when connected via HDMI eARC.



Figure 5: Visual representation of Dolby Atmos immersive sound technology.

The sound bar features custom-tuned bass with dual 4-inch built-in subwoofers, providing powerful low-end performance without the need for an external subwoofer. You can adjust bass levels via the remote or the Klipsch Connect App.

BUILT-IN BASS




Figure 6: Graphic illustrating the powerful built-in bass capabilities of the sound bar.

App Control

For enhanced control and customization, download the Klipsch Connect App from your device's app store. The app allows you to:

- Adjust EQ settings and sound modes.
- Control volume and input selection.
- Receive firmware updates.
- Access product support.




Figure 7: A smartphone screen showing the Klipsch Connect App interface, demonstrating remote control capabilities.

Your browser does not support the video tag.

Video 1: An overview of the Klipsch Flexus Core 200 Sound Bar, highlighting its features and design.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your sound bar.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the sound bar. Do not use liquid cleaners or aerosol sprays.
- **Ventilation:** Ensure that the ventilation openings are not blocked by dust or debris. Periodically clean them with a soft brush or vacuum cleaner.
- **Storage:** If storing the sound bar for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Klipsch Flexus CORE 200 Sound Bar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from sound bar.	Power not connected, incorrect input selected, TV audio output settings.	Ensure power cable is securely connected. Verify correct input is selected on the sound bar (HDMI, Optical, Bluetooth). Check your TV's audio output settings to ensure it's set to external speakers or the correct HDMI/Optical output.
Bluetooth device won't pair.	Sound bar not in pairing mode, device too far, interference.	Ensure the sound bar is in Bluetooth pairing mode (flashing indicator). Move the Bluetooth device closer to the sound bar. Turn off other Bluetooth devices nearby to reduce interference.
Sound is distorted or unclear.	Volume too high, poor audio source, cable issues.	Reduce the volume. Try a different audio source to determine if the issue is with the source. Check HDMI or optical cables for secure connection and damage.

SPECIFICATIONS

Detailed technical specifications for the Klipsch Flexus CORE 200 Sound Bar:

- **Model Name:** Flexus Core 200
- **Brand:** Klipsch
- **Surround Sound Channel Configuration:** 3.1.2
- **Speaker Type:** Soundbar with built-in subwoofers
- **Connectivity Technology:** Bluetooth, HDMI eARC, Optical
- **Speaker Maximum Output Power:** 200 Watts
- **Frequency Response:** 43 Hz (lower limit)
- **Product Dimensions:** 4.9D x 44W x 3.1H Centimeters (approx. 12.4D x 111.7W x 7.9H cm)
- **Item Weight:** 8.48 kg (18.7 Pounds)
- **Controller Type:** Remote Control
- **Compatible Devices:** Television
- **Mounting Type:** Tabletop Mount (Wall mountable with included hardware)




Figure 8: Dimensions of the Klipsch Flexus CORE 200 Sound Bar.



Figure 9: The "Powered by Onkyo" branding, indicating a collaboration for enhanced performance.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Klipsch website or contact their customer service. Keep your proof of purchase for warranty claims.

- **Official Website:** www.klipsch.com
- **Customer Service:** Refer to the contact information provided on the official website for your region.

© 2024 Klipsch. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question