

[Manuals.plus](#) /

> [Wolfwise](#) /

> Wolfwise Portable Pop-Up Pet Playpen Instruction Manual (Model 23214)

Wolfwise 23214

Wolfwise Portable Pop-Up Pet Playpen

Model: 23214 - User Instruction Manual

INTRODUCTION

Thank you for choosing the Wolfwise Portable Pop-Up Pet Playpen. This manual provides essential information for the safe and effective use, setup, and maintenance of your new pet playpen. Please read these instructions carefully before use and retain them for future reference.

SAFETY INSTRUCTIONS

- Always supervise your pet while they are inside the playpen.
- Ensure all zippers and fasteners are securely closed to prevent accidental escape.
- Do not leave pets unattended for extended periods, especially in extreme weather conditions.
- Place the playpen on a flat, stable surface.
- Keep the playpen away from open flames, heaters, or other heat sources.
- Regularly inspect the playpen for any damage or wear. Discontinue use if damaged.
- This playpen is designed for pets. Do not allow children to play inside or on the playpen.

PRODUCT FEATURES

The Wolfwise Portable Pop-Up Pet Playpen is designed for convenience, durability, and pet comfort.

- **Foldable Design:** Easy to set up and store without the need for additional tools.
- **Spacious and Versatile:** Provides ample space for pets to play and relax. Suitable for various small animals including cats, dogs, rabbits, hamsters, chicks, and ducks. Available in multiple sizes, including Large (90 x 60 x 60 cm).
- **Sturdy and Safe Construction:** Made from premium 600D Oxford fabric for long-term durability. Features robust, claw-resistant mesh windows for added protection.
- **Breathable and Practical:** 360° mesh windows ensure excellent ventilation and visibility. Front and top zipper doors roll up and secure with hook-and-loop fasteners for convenient access and supervision.
- **Easy to Maintain:** Surfaces are designed for effortless cleaning, ensuring a hygienic environment for your pet.

Conception pliante

Il suffit de l'ouvrir pour l'assembler et de le replier pour le ranger facilement quand il n'est pas utilisé.



Image: The Wolfwise Pet Playpen (90x60x60cm) demonstrating its spaciousness and suitability for various small pets.

Robuste et sûr




Image: Close-up details highlighting the durable materials and secure components of the playpen.



Image: Visual representation of the playpen's excellent ventilation system.

SETUP GUIDE

The Wolfwise Pet Playpen features a pop-up design for quick and easy assembly.

1. Remove the playpen from its storage bag.
2. Hold the folded playpen and gently release the tension. It will automatically spring into shape.
3. Ensure all panels are fully extended and the structure is stable.
4. Zip up the top and front doors if you wish to secure your pet inside.
5. For added stability, ensure the playpen is placed on a flat surface.



Image: Step-by-step visual instructions for unfolding the playpen.

OPERATING INSTRUCTIONS

The playpen is versatile and can be used in various environments:

- **At Home:** Provide a safe and contained space for your pet indoors. The mesh windows allow for easy observation and interaction.
- **Travel:** Its foldable design makes it ideal for car trips. Ensure the playpen is secured during transit.
- **Camping & Outdoors:** Use it as a temporary shelter or play area for your pet while camping, at the beach, or in your backyard. The breathable mesh keeps your pet comfortable.

To provide access, simply unzip the front or top door and roll it up, securing it with the hook-and-loop fasteners. To secure your pet, ensure both doors are zipped closed.



Conçu pour une utilisation à l'intérieur et à l'extérieur.

Image: The playpen in various settings, demonstrating its versatility for indoor and outdoor use.

MAINTENANCE

Keeping your Wolfwise Pet Playpen clean is simple:

- **Cleaning:** Wipe down the mesh windows and Oxford fabric surfaces with a damp cloth and mild soap. Rinse thoroughly with a clean damp cloth to remove any soap residue.
- **Drying:** Allow the playpen to air dry completely before folding and storing to prevent mold or mildew.
- **Storage:** When not in use, fold the playpen flat and place it in its provided storage bag. Store in a cool, dry place.



Image: Demonstrating how to easily clean the playpen surfaces.

STORAGE

To fold and store your playpen:

1. Ensure the playpen is clean and dry.
2. Unzip all doors and flatten the playpen.
3. Twist the playpen into a compact, flat circle.
4. Place the folded playpen into the provided storage bag and secure it with the strap.



Image: The playpen folded into its compact storage bag, ready for travel.

TROUBLESHOOTING

- **Playpen not opening correctly:** Ensure there are no obstructions and gently guide the frame into shape. If it feels stiff, try twisting it slightly to release tension.
- **Playpen unstable:** Verify that the playpen is fully expanded and placed on a flat, even surface.
- **Zippers sticking:** Apply a small amount of zipper lubricant or rub a pencil lead along the teeth to ease movement.
- **Pet chewing on mesh:** While the mesh is claw-resistant, persistent chewing can cause damage. Consider using a chew deterrent spray or providing alternative chew toys for your pet.

SPECIFICATIONS

Attribute	Detail
Model Number	23214
Dimensions (L x W x H)	90 x 60 x 60 cm (35.4 x 23.6 x 23.6 inches)
Weight	1.34 kg (2.95 lbs)
Material	600D Oxford Fabric
Color	Green
Closure Type	Zipper
Special Features	Foldable, Collapsible, Breathable Mesh Windows
Recommended Uses	Travel, Camping, Home

WARRANTY AND SUPPORT

Wolfwise products are manufactured with quality and customer satisfaction in mind. For any questions, concerns, or warranty inquiries, please contact Wolfwise customer support through the retailer's platform or the official Wolfwise website. Please have your model number (23214) and purchase information ready when contacting support.

