Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Audibax Delta 42 BT Black

Audibax Delta 42 BT Black Bluetooth Speakers User Manual

Model: Delta 42 BT Black (Item Model Number: 10268245)

Introduction | Safety Information | What's in the Box | Product Overview | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for choosing the Audibax Delta 42 BT Black Bluetooth Speakers. These high-performance active wall speakers are designed to deliver clear, powerful, and immersive sound for various applications. Featuring Bluetooth connectivity, they offer versatile audio playback from compatible devices. This manual provides essential information for safe operation, setup, and maintenance of your speakers.



Figure 1.1: Audibax Delta 42 BT Black Speakers (Pair)

This image displays the Audibax Delta 42 BT Black speakers from an angled perspective, showcasing their compact design and black finish. Both speakers are visible, highlighting their identical appearance and the integrated mounting brackets at the top.

2. Safety Information

Please read and understand all safety instructions before using this product. Keep this manual for future reference.

- **Power Source:** Only use the power adapter supplied with the speakers. Ensure the voltage matches the requirements specified on the adapter.
- **Ventilation:** Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- **Water and Moisture:** Do not expose these speakers to rain, moisture, dripping, or splashing. Do not place objects filled with liquids, such as vases, on the speakers.
- **Heat:** Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth.
- **Mounting:** If wall-mounting, ensure the wall structure can support the weight of the speakers and that mounting is performed securely to prevent injury or damage.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to

rain or moisture, does not operate normally, or has been dropped.

3. What's in the Box

Upon unpacking, please verify that all the following items are included:

- 2 x Audibax Delta 42 BT Black Speakers (one active, one passive)
- 1 x Power Adapter
- 1 x Speaker Connection Cable (to connect active to passive speaker)
- 1 x User Manual (this document)

4. Product Overview

Familiarize yourself with the components of your Audibax Delta 42 BT Black speakers.

4.1 Front View



Figure 4.1: Front Panel

This image shows the front grille of both Audibax Delta 42 BT Black speakers. The grilles are black and cover the speaker drivers, with the Audibax logo visible at the bottom center of each speaker.

1. **Speaker Grille:** Protects the woofer and tweeter.
2. **Audibax Logo:** Indicates the brand.

4.2 Rear Panel and Connections



Figure 4.2: Rear Panel Connections

This image displays the rear panels of both Audibax Delta 42 BT Black speakers. The left speaker (active) shows a power input (12V/2A), a connection port for the right speaker, and a TWS (True Wireless Stereo) button. The right speaker (passive) shows a connection port for the active speaker. Both speakers have integrated mounting brackets.

1. **DC 12V/2A Power Input (Active Speaker):** Connect the provided power adapter here.
2. **Speaker Output (Active Speaker):** Connects to the passive speaker using the supplied cable.
3. **Speaker Input (Passive Speaker):** Connects to the active speaker using the supplied cable.
4. **TWS Button (Active Speaker):** Used for True Wireless Stereo pairing (if applicable, though primarily for Bluetooth pairing).
5. **Mounting Bracket:** For wall installation.

5. Setup

Follow these steps to set up your Audibax Delta 42 BT Black speakers.

5.1 Speaker Placement

The Audibax Delta 42 BT speakers are designed for versatile placement, including desktop or wall mounting. For optimal sound, place the speakers at ear level and equidistant from your listening position.



Figure 5.1: Example Wall Mounting

This image shows the Audibax Delta 42 BT Black speakers mounted on a wall in a modern living room setting, demonstrating a typical installation scenario above a television.

5.2 Wall Mounting (Optional)

If you choose to wall mount your speakers, use appropriate hardware (not included) for your wall type. Ensure the mounting surface is sturdy enough to support the speaker's weight (2.5 kg per pair).



Figure 5.2: Speaker with Mounting Bracket

This image shows a single Audibax Delta 42 BT Black speaker from an angled side view, clearly displaying the integrated L-shaped mounting bracket attached to its top and bottom surfaces.

1. Identify the desired mounting location.
2. Mark the drill points for the mounting bracket.
3. Drill pilot holes and insert appropriate wall anchors if necessary.
4. Secure the speaker to the wall using screws through the mounting bracket.
5. Adjust the speaker angle as desired.

5.3 Connecting the Speakers

One speaker is active (contains the amplifier and power input), and the other is passive. They must be connected to each other.

1. Locate the active speaker (with the power input and TWS button) and the passive speaker.
2. Connect the supplied speaker connection cable from the "Connect to R speaker" output on the active speaker to the "Connect from active speaker" input on the passive speaker. Ensure a secure connection.
3. Connect the provided DC 12V/2A power adapter to the "12V/2A" input on the active speaker.
4. Plug the power adapter into a suitable wall outlet. The speakers will power on.

6. Operating Instructions

6.1 Bluetooth Pairing

The Audibax Delta 42 BT speakers are designed for effortless wireless connectivity via Bluetooth.

1. Ensure the speakers are powered on. They will automatically enter Bluetooth pairing mode, indicated by a flashing LED (if present, refer to speaker for specific indicator).
2. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings.
3. Search for available devices. You should see "Audibax Delta 42 BT" or a similar name in the list.
4. Select "Audibax Delta 42 BT" to initiate pairing.
5. Once paired, the LED indicator will become solid (if present), and you will hear a confirmation tone.
6. You can now play audio from your device through the speakers.

Note: If prompted for a password, enter "0000" (four zeros).

6.2 True Wireless Stereo (TWS) Function (if applicable)

The TWS button on the active speaker is typically used to pair two identical Audibax Bluetooth speakers together for a true stereo experience from a single Bluetooth source. For the Delta 42 BT, the two speakers are already designed to work as a stereo pair via the wired connection. The TWS button may be for future compatibility or specific advanced pairing scenarios not typical for this wired pair.

- For standard use, simply connect the active and passive speakers with the provided cable.
- If you encounter issues with stereo separation or wish to explore advanced TWS pairing with another identical Audibax Bluetooth speaker (not this specific wired pair), consult the Audibax support website for detailed instructions.

7. Maintenance

Proper care will ensure the longevity and performance of your speakers.

- **Cleaning:** Wipe the speaker surfaces with a soft, dry, lint-free cloth. Do not use liquid cleaners, aerosols, or abrasive chemicals, as they may damage the finish or internal components.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Obstructions:** Ensure the speaker grilles and any ventilation openings remain clear of dust and debris.

8. Troubleshooting

If you experience issues with your speakers, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No power/Speakers not turning on	Power adapter not connected or faulty; power outlet not working.	Ensure the power adapter is securely connected to the active speaker and a working power outlet. Try a different outlet.
No sound from speakers	Speakers not paired via Bluetooth; volume too low; incorrect source selected; active and passive speakers not connected.	Ensure Bluetooth is paired correctly. Increase volume on both the source device and speakers. Verify the cable connecting the active and passive speakers is secure.

Problem	Possible Cause	Solution
Bluetooth device cannot find speakers	Speakers not in pairing mode; device too far; interference.	Ensure speakers are powered on and in pairing mode. Move the Bluetooth device closer to the active speaker. Avoid strong electromagnetic interference. Try turning Bluetooth off and on again on your device.
Sound distortion or poor quality	Volume too high; poor audio source quality; interference.	Reduce the volume. Try a different audio source or file. Move speakers away from other electronic devices.

9. Specifications

Technical specifications for the Audibax Delta 42 BT Black speakers:

- **Model Name:** Delta 42 BT Black
- **Item Model Number:** 10268245
- **Speaker Type:** Active Wall Speakers (Pair)
- **Connectivity:** Bluetooth
- **Speaker Configuration:** 2-way (Woofer + Tweeter)
- **Woofer Size:** 4 inches
- **Tweeter Size:** 0.5 inches
- **Frequency Response:** 90Hz - 20kHz
- **SPL (Sound Pressure Level):** 87dB
- **Maximum Output Power:** 100 Watts (Peak)
- **Rated Power Output:** 15W + 15W (RMS)
- **Audio Output Mode:** Surround Sound
- **Mounting Type:** Wall Mount
- **Product Dimensions:** 30.5 x 21.5 x 13.5 cm (per speaker, approx.)
- **Weight:** 2.5 kg (per pair, approx.)
- **Recommended Uses:** For smartphones, tablets, personal computers



Figure 9.1: Key Product Specifications

This image is a marketing graphic for the Audibax Delta 42 BT Black speakers, displaying key specifications such as "WALL ACTIVE SPEAKER PAIR", "POWER OUTPUT: 15W + 15W", "SPEAKER SIZE: 4 INCHES", "SPEAKER TYPE: ACTIVE (POWERED)", "CONNECTIVITY: BLUETOOTH (BT)", and "COLOR: BLACK", alongside an image of the speakers.

10. Warranty and Support

Audibax products are manufactured to high quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Audibax website.

Please have your model name (Delta 42 BT Black) and item model number (10268245) ready when contacting support.

© 2024 Audibax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CV7HRGKC

More documents and user manuals: **https://manuals.plus/**