

Cecotec EnergySilence 5000 Cool Wave

Cecotec EnergySilence 5000 Cool Wave Evaporative Air Conditioner User Manual

Model: EnergySilence 5000 Cool Wave (08199)

Brand: Cecotec

1. INTRODUCTION

Thank you for choosing the Cecotec EnergySilence 5000 Cool Wave Evaporative Air Conditioner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, level surface.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Unplug the appliance from the power outlet before cleaning, filling, or when not in use.
- Do not block the air inlet or outlet vents.
- Use only clean tap water in the water tank. Do not add any chemicals or fragrances.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped.
- This appliance is for indoor use only.

3. PRODUCT OVERVIEW

The Cecotec EnergySilence 5000 Cool Wave is an evaporative air conditioner designed to provide a refreshing airflow. It features a DC motor for efficient operation, a large water tank, multiple speed settings, and various modes to suit your comfort needs.

Key Features:

- **Power:** 28W for efficient cooling.
- **Water Tank Capacity:** 5 liters for extended operation.

- **Control:** Intuitive LED display with touch controls and a remote control for convenience.
- **Speed Settings:** 12 adjustable speeds to customize airflow intensity.
- **Modes:** 3 ventilation modes (Normal, Nature, Sleep) for varied comfort.
- **Timer:** Programmable timer up to 9 hours.
- **Oscillation:** 360° oscillation for wide air distribution.



Image 1: Front view of the Cecotec EnergySilence 5000 Cool Wave Evaporative Air Conditioner, illustrating the cool air output.

4. SETUP

4.1 Unpacking

1. Carefully remove the appliance from its packaging.

2. Check for any damage during transit. If damaged, do not operate and contact customer support.
3. Remove all packaging materials, including any protective films or stickers.

4.2 Wheel Installation

The appliance comes with wheels for easy mobility. These are typically located within the water tank compartment.

1. Gently tilt the unit to access the bottom.
2. Insert each wheel into its designated slot until it clicks securely into place.
3. Ensure all wheels are firmly attached before placing the unit upright.

4.3 Filling the Water Tank

For evaporative cooling, the water tank must be filled with water.

1. Locate the water tank, usually at the bottom or rear of the unit.
2. Pull out or open the water tank.
3. Fill the tank with clean tap water up to the maximum fill line indicated. Do not overfill.
4. If ice packs are included, place them in the water tank for enhanced cooling effect.
5. Securely close or reinsert the water tank.



Image 2: A person relaxing near the evaporative cooler, highlighting the 5-liter water tank capacity.

5. OPERATING INSTRUCTIONS

The EnergySilence 5000 Cool Wave can be operated using the touch control panel on the unit or the included remote control.

5.1 Power On/Off

- Plug the power cord into a suitable electrical outlet.
- Press the **Power** button on the control panel or remote control to turn the unit on or off.

5.2 Adjusting Fan Speed

The unit offers 12 fan speed settings.

- Press the **Speed** button repeatedly to cycle through the available speed levels. The current speed will be displayed on the LED screen.

12 ..



Image 3: Visual representation of the 12 fan speed settings available on the unit.

5.3 Selecting Operating Mode

Choose from three distinct modes: Normal, Nature, and Sleep.

- Press the **Mode** button repeatedly to select your desired mode.
- **Normal Mode:** Provides a constant, steady airflow.
- **Nature Mode:** Simulates natural breezes with varying fan speeds.
- **Sleep Mode:** Operates at a lower, quieter speed, gradually decreasing over time for undisturbed rest.



Image 4: Depiction of the three operating modes: Sleep, Normal, and a cooling/nature mode.

5.4 Timer Function

The programmable timer allows you to set the operating duration up to 9 hours.

- Press the **Timer** button to set the desired operating time. Each press typically increases the time by one hour.
- The unit will automatically turn off once the set time has elapsed.



Image 5: The evaporative cooler with an icon indicating the 9-hour timer function.

5.5 360° Oscillation

Activate the oscillation function for wider air distribution.

- Press the **Oscillation** button to start or stop the 360° rotating airflow.




Image 6: The evaporative cooler demonstrating its 360-degree oscillation feature.

5.6 Remote Control and Touch Panel

Both the remote control and the touch panel on the unit provide full access to all functions.



Image 7: The evaporative cooler's LED display and the included remote control.



Image 8: A hand interacting with the touch control panel on the top of the unit.

6. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your evaporative air conditioner.

6.1 Cleaning the Exterior

1. Always unplug the appliance before cleaning.
2. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. Ensure no water enters the control panel or other electrical components.

6.2 Cleaning the Water Tank

Clean the water tank regularly to prevent mold and mildew growth.

1. Unplug the unit and remove the water tank.
2. Empty any remaining water.
3. Wash the tank with mild soap and water. Rinse thoroughly.
4. Allow the tank to air dry completely before reinserting it into the unit.

6.3 Filter Cleaning

The evaporative filter (cooling pad) should be cleaned periodically.

1. Refer to your unit's specific design for accessing the filter. This usually involves opening a rear panel.
2. Carefully remove the filter.
3. Rinse the filter under running water to remove dust and mineral deposits. Do not use harsh chemicals.
4. Allow the filter to dry completely before reinstalling.

6.4 Storage

When storing the appliance for an extended period:

1. Ensure the water tank is empty and clean, and the filter is dry.
2. Clean the exterior of the unit.
3. Store the appliance in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Cecotec EnergySilence 5000 Cool Wave, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord not properly plugged in; Power button not pressed.	Check power outlet; Ensure power cord is securely plugged in; Press the Power button.
Weak or no airflow	Air inlet/outlet blocked; Fan speed too low; Filter dirty.	Clear any obstructions; Increase fan speed; Clean the air filter.
No cooling effect	Water tank empty; Evaporative filter dry or dirty; Room humidity too high.	Fill water tank; Clean or moisten evaporative filter; Evaporative coolers are less effective in high humidity.
Unusual noise	Unit not on a level surface; Obstruction in fan; Water pump issue.	Place unit on a level surface; Check for and remove obstructions; Contact customer support if pump noise persists.

8. SPECIFICATIONS

Feature	Detail
Brand	Cecotec
Model Name	EnergySilence 5000 Cool Wave
Model Number	08199

Feature	Detail
Color	White
Power Consumption	28 W (DC Motor)
Water Tank Capacity	5 Liters
Number of Speeds	12
Special Features	Digital Display, Oscillating Fan, Timer
Control Type	Touch, Remote Control
Product Dimensions	29 x 66.8 x 20 cm
Material	Plastic
Mounting Type	Freestanding

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Cecotec website. Keep your proof of purchase for warranty claims.

Related Documents - EnergySilence 5000 Cool Wave

	<p><u>Cecotec Energysilence Aero 360/365 Ceiling Fan - Instruction Manual</u> Comprehensive instruction manual for the Cecotec Energysilence Aero 360 and 365 series ceiling fans. Includes assembly, operation, maintenance, troubleshooting, and technical specifications.</p>
	<p><u>Cecotec EnergySilence 3500 Cool Compact Smart Air Cooler: User Manual and Guide</u> This comprehensive user manual provides detailed instructions for operating, maintaining, and troubleshooting the Cecotec EnergySilence 3500 Cool Compact Smart evaporative air cooler. Learn about its features, safety precautions, and technical specifications.</p>



[Cecotec EnergySilence 5500 Pure Tech: Manual de Instrucciones y Guía de Usuario](#)

Manual completo para el climatizador evaporativo Cecotec EnergySilence 5500 Pure Tech. Incluye instrucciones de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas para un uso óptimo.



[Cecotec EnergySilence 4800 Light: Manual de Instrucciones y Seguridad](#)

Manual de instrucciones y seguridad para el ventilador de techo Cecotec EnergySilence 4800 Light. Descubra cómo instalar, operar y mantener su ventilador de forma segura y eficiente.



[Manual de Instrucciones Cecotec ENERGYSILENCE AERO 5270 - Ventilador de Techo con Motor DC](#)

Manual de instrucciones completo para los ventiladores de techo Cecotec ENERGYSILENCE AERO 5270, incluyendo guías de seguridad, montaje, funcionamiento, limpieza, mantenimiento y especificaciones técnicas.



[Cecotec Energysilence Aero 5275: Manual de Instrucciones y Seguridad](#)

Descubra el ventilador de techo Cecotec Energysilence Aero 5275. Este manual proporciona instrucciones detalladas de seguridad, funcionamiento, limpieza y mantenimiento para los modelos DarkWood, Black&WhiteWood, White&BlackWood y WhiteWood.