

[Manuals.plus](#) /

› [Hurom](#) /

› Hurom H330P Slow Juicer Instruction Manual

Hurom H330P

Hurom H330P Slow Juicer Instruction Manual

Model: H330P

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your Hurom H330P Slow Juicer. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Information

- Always ensure the appliance is properly assembled before use.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils away from moving parts during operation.
- Unplug the juicer from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate the appliance with a damaged cord or plug.

2. PRODUCT OVERVIEW

The Hurom H330P is a premium slow juicer designed for extracting healthy, flavorful, and waste-free juices. It utilizes advanced slow pressing technology to preserve nutrients and maximize yield.



Image: Hurom H330P Slow Juicer with fresh produce.

Key Features

- **Slow Pressing Technology:** Features a 43 RPM motor and a 17 RPM inner basket to preserve essential vitamins and nutrients, resulting in exceptional juice flavor.
- **Reverse Function:** Helps prevent clogging when processing hard or fibrous ingredients, optimizing juice extraction.
- **Versatile Functionality:** Capable of preparing fresh juices, vegetable milks from nuts and almonds, and sorbets using the included wide mesh filter.
- **Large Capacity:** Equipped with a 2-liter pitcher, ideal for family use, and can operate continuously for up to 40 minutes thanks to its powerful motor.
- **High-Quality Materials:** Constructed with stainless steel filters, a BPA-free Tritan pitcher, and an Ultem screw, ensuring durability and safety.

HUROM
ESPAÑA

**MÁS CAPACIDAD
MÁS AUTONOMÍA**

¡MÁS ZUMO!

Tolva *maxi* de 2L

Permite preparar hasta
9 vasos de zumo sin
pausas



Tiempo continuo de
funcionamiento:
30 minutos

Image: Disassembled components of the Hurom H330P, highlighting high-quality materials like Tritan and Ultem.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your Hurom H330P Slow Juicer before first use.

1. Place the motor base on a stable, flat surface.
2. Insert the spinning brush and strainer into the juicing bowl.
3. Place the Ultem screw (auger) into the center of the strainer.
4. Attach the hopper assembly onto the juicing bowl, ensuring it locks securely into place.
5. Ensure the pulp and juice outlets are correctly positioned.



Image: The wide hopper of the Hurom H330P, designed for easy ingredient feeding.

4. OPERATING INSTRUCTIONS

Preparing Ingredients

- Wash all fruits and vegetables thoroughly.
- The H330P's all-in-one hopper allows for larger pieces or even whole fruits/vegetables. Remove any hard pits, large seeds, or tough skins that are not suitable for juicing.
- For fibrous ingredients, it is recommended to cut them into smaller pieces to prevent clogging.

TOLVA

ALL IN ONE

Entrada práctica: permite añadir nuevos ingredientes en cualquier momento, gracias al orificio en la tapa de la tolva.

Menos cortes introduce la fruta y verdura enteras.

Solo tienes que quitar lo que no se puede exprimir, como los huesos.



Parada automática integrada: Si abres la tapa durante el funcionamiento, la extracción se detiene automáticamente. Una vez cerrada, continúa.



Image: Demonstrating the wide feeding chute for whole ingredients.

Juicing Process

1. Plug the power cord into a suitable electrical outlet.
2. Place a juice container under the juice outlet and a pulp container under the pulp outlet.
3. Turn the power switch to the 'ON' position.
4. Slowly feed prepared ingredients into the hopper. The juicer will automatically process them.
5. The juicer features an integrated automatic stop function if the lid is opened during operation. Once closed, it will resume.
6. The H330P can operate continuously for up to 40 minutes.



ROTACIÓN INVERSA

PARA UNA EXTRACCIÓN CONTINUA

La **función reverse** permite desbloquear fácilmente los ingredientes más duros, evitando que el extractor se detenga durante su uso.

HUROM
ESPAÑA

Image: The 'ON' and 'REV' switch for operation and reverse function.

Using the Reverse Function

If ingredients become jammed or the juicer stops during operation, turn the switch to the 'REV' (Reverse) position for a few seconds. This will help dislodge the ingredients. Then, switch back to 'ON' to continue juicing. Do not hold the 'REV' switch for extended periods.


Versatile Applications

The Hurom H330P comes with three different filters, allowing you to prepare a variety of items:

- **Fine Filter:** For clear, smooth juices.
- **Coarse Filter:** For juices with more pulp, or for making nut milks.
- **Sorbet/Ice Cream Filter:** For frozen desserts.

UN EXTRACTOR, MIL POSIBILIDADES

zumos, leches vegetales e sorbetes



Con sus *3 filtros incluidos*, el H-330P es tu aliado en la cocina: zumos claros o con cuerpo, sorbetes, leches vegetales y mucho más.

Un solo extractor ¡Infinitas posibilidades!

HUROM
ESPAÑA

Image: The H330P's versatility in making juices, vegetable milks, and sorbets.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your Hurom H330P Slow Juicer. The design prioritizes easy and quick cleaning.

Disassembly for Cleaning

1. Unplug the juicer from the power outlet.
2. Remove the hopper assembly.
3. Lift out the Ultem screw, strainer, and spinning brush from the juicing bowl.

Cleaning Instructions

- Rinse all detachable parts under running water immediately after use.
- Use the included cleaning brush to remove any pulp residue from the strainer and other components.
- For thorough cleaning, wash parts with warm, soapy water.
- The motor base should be wiped clean with a damp cloth. Never immerse the motor base in water.
- Ensure all parts are completely dry before reassembling or storing.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Hurom H330P Slow Juicer.

Problem	Possible Cause	Solution
Juicer stops during operation or jams.	Overloading with ingredients, especially fibrous ones.	Switch to 'REV' (Reverse) for a few seconds to clear the jam, then switch back to 'ON'. Cut fibrous ingredients into smaller pieces.
Low juice yield or excessive pulp.	Incorrect filter used or ingredients not properly prepared.	Ensure the correct filter is installed for your desired juice consistency. Cut ingredients to appropriate sizes.
Appliance does not turn on.	Not properly plugged in, or parts not assembled correctly.	Check power connection. Ensure all parts are securely assembled and locked into place.

7. SPECIFICATIONS

Detailed technical specifications for the Hurom H330P Slow Juicer.

Specification	Detail
Brand	Hurom
Model Number	H-330P
Color	Ivory (RAL 1013)
Product Dimensions (L x W x H)	24.8 x 22.3 x 46.2 cm
Item Weight	10.68 Kilograms
Capacity	350 Milliliters (Juice Chamber)
Voltage	230 Volts
Material	Tritan (Pitcher), Ultem (Screw)

Specification	Detail
Number of Speeds	1
Maximum Power	200 Watt
Power Source	Corded Electric

8. WARRANTY AND SUPPORT

Hurom products are manufactured with high-quality standards. This product comes with a 15-year warranty, reflecting our commitment to durability and performance.



Image: Warranty information and customer support details.

Customer Support

For technical assistance, warranty claims, or any questions regarding your Hurom H330P Slow Juicer, please contact our customer support. Contact details can typically be found on the Hurom official website or your purchase documentation.

© 2024 Hurom. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question