



Manuals.plus /

› Members Only /

› Members Only Hair Clipper Instruction Manual

## Members Only MO515-NOC-STK-6

# Members Only Hair Clipper Instruction Manual

MODEL: MO515-NOC-STK-6 | BRAND: MEMBERS ONLY

## 1. Product Overview

---

The Members Only Hair Clipper is a versatile and powerful grooming tool designed for men. Featuring a cordless T-Blade design and a USB rechargeable lithium battery, it offers precision and convenience for all your hair cutting and grooming needs. The intelligent LED display provides real-time battery life and charging reminders, ensuring optimal performance.

This 7-piece kit includes the rechargeable T-Blade Hair Clipper, 5 comb guides for customizable lengths (1mm, 2mm, 3mm, 4mm, 5mm), a protective cap, and a cleaning brush, providing a complete solution for achieving your desired hairstyle with ease.

## 2. Product Components

---



**Figure 2.1:** Complete 7-piece kit including the hair clipper, comb guides, and cleaning brush.



**Figure 2.2:** Front view of the hair clipper highlighting the intelligent LED display.

**MEMBERS ONLY®**



Intelligent LED Display

USB Rechargeable Lithium Battery

High performance stainless steel blades

Cordless

Figure 2.3: Key features of the hair clipper: LED display, USB rechargeable, stainless steel blades, and cordless design.

**5**

**COMB GUIDES  
INCLUDED**

**Precise Trimming**

**Low Noise Operation**

**Easy to Hold**



Figure 2.4: The five included comb guides (1mm, 2mm, 3mm, 4mm, 5mm) for various hair lengths.

### Included in the Box:

- Rechargeable T-Blade Hair Clipper
- 5 Comb Guides (1mm, 2mm, 3mm, 4mm, 5mm)
- Protective Cap
- Cleaning Brush
- USB Charging Cable
- User Manual

### 3. Safety Information

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Avoid direct contact of blades with skin and eyes.
- Keep the device away from water and do not immerse it.
- Do not use on infants or young children.
- Always follow recommended cleaning and maintenance procedures as outlined in this manual.
- Unplug the clipper and allow it to cool before storing.
- Do not operate the clipper while it is charging.

- Ensure the protective cap is on the blades when not in use or during storage.

## 4. Setup & Charging

---

### Initial Charge:

1. Before first use, fully charge the hair clipper.
2. Connect the USB charging cable to the clipper's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, USB wall adapter).
4. The LED display will indicate charging progress. A full charge typically takes approximately 2 hours.
5. Once fully charged, the LED display will show "99" or a full battery indicator. Disconnect the clipper from the power source.

### Battery Indicator:

The intelligent LED display shows the remaining battery life in minutes, allowing you to monitor usage time. It also provides timely reminders for charging and cleaning.

## 5. Operating Instructions

---

### Attaching Comb Guides:

1. Ensure the clipper is turned off.
2. Select the desired comb guide (1mm, 2mm, 3mm, 4mm, or 5mm) based on your preferred hair length.
3. Align the comb guide with the clipper blade and gently push it until it clicks securely into place.
4. To remove, gently pull the comb guide away from the blade.




Figure 5.1: Using the hair clipper for precise grooming.

### Hair Cutting and Trimming:

1. Before cutting, ensure hair is clean and dry.
2. Turn on the clipper by pressing the power button.
3. For general hair cutting, start with a longer comb guide and gradually switch to shorter ones if a closer cut is desired.
4. Move the clipper against the direction of hair growth, using smooth, even strokes.
5. For precision trimming (e.g., beard lines, sideburns) or a very close cut, remove the comb guide and use the T-Blade directly. Exercise caution to avoid skin irritation.
6. Regularly tap or brush off accumulated hair from the blades during use to maintain optimal performance.
7. After use, turn off the clipper.

## 6. Maintenance

---

### Cleaning the Blades:

1. Ensure the clipper is turned off and unplugged (if charging).
2. Use the provided cleaning brush to remove any loose hair from the blades and the clipper body.

3. For a more thorough cleaning, the stainless steel blades can be carefully detached (refer to operating instructions for removal). Rinse the blades under running water. Ensure they are completely dry before reattaching.
4. Do not rinse the main body of the clipper under water.

### Oiling the Blades:

To maintain optimal cutting performance and blade longevity, it is recommended to oil the blades regularly (e.g., after every few uses). Apply a small drop of the included lubricating oil to the teeth of the blades. Turn the clipper on for a few seconds to distribute the oil evenly.

## 7. Troubleshooting

---

Problem	Possible Cause	Solution
Clipper not turning on.	Low battery; Power button not pressed correctly.	Charge the clipper fully. Press and hold the power button firmly.
Blades pulling hair or cutting poorly.	Blades are dull, dirty, or not oiled.	Clean the blades thoroughly. Apply lubricating oil. If issues persist, consider professional sharpening or blade replacement.
LED display not working.	Device malfunction; Extreme temperature.	Ensure the device is within operating temperature range. If malfunction persists, contact customer support.

## 8. Specifications

---

**Model Number:** MO515-NOC-STK-6

**Power Source:** Lithium Rechargeable Battery

**Blade Material:** Stainless Steel

**Comb Guides:** 1mm, 2mm, 3mm, 4mm, 5mm

**Color:** Black

**Manufacturer:** Sakar International

**UPC:** 021331069108

**Package Dimensions:** 9 x 4.9 x 2.1 inches

**Item Weight:** 4 ounces

**Country of Origin:** China

## 9. Warranty & Support

---

The Members Only Hair Clipper comes with a one-year warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please visit the official Members Only store on Amazon or contact their customer service directly. Refer to the product packaging for specific contact details.

**Online Store:** Members Only Amazon Store

