

[Manuals.plus](#) /

> [Miracle-Gro](#) /

> Miracle-Gro 4'8" x 29" x 6'5" All-Season Mini Walk-in Greenhouse Instruction Manual

## Miracle-Gro 70526

# Miracle-Gro 4'8" x 29" x 6'5" All-Season Mini Walk-in Greenhouse Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Miracle-Gro 4'8" x 29" x 6'5" All-Season Mini Walk-in Greenhouse. This portable greenhouse is designed to protect your plants, herbs, vegetables, or flowers from harsh weather and other elements, allowing for an extended growing season.

## SAFETY INFORMATION

---

- Always assemble the greenhouse on a flat, stable surface.
- Exercise caution with sharp edges and heavy components during assembly.
- Avoid exposing the PVC cover to high heat or direct sunlight for extended periods to prevent material degradation.
- When moving the greenhouse, ensure it is properly secured to prevent tipping.
- Always follow local regulations for anchoring and ventilation of greenhouses.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components are present and undamaged. The package should include:

- High-grade 5/8" tubular steel frame components with powder coat finish.
- Plastic connectors for frame assembly.
- Clear PVC cover with double-zipper door and tie-downs.
- Four (4) removable wire mesh shelves.

## SETUP AND ASSEMBLY

Assembly of the Miracle-Gro Mini Walk-in Greenhouse is designed to be quick and tool-free, typically taking about 15 minutes.

1. **Assemble the Base Frame:** Connect the tubular steel bars using the plastic connectors to form the base of the greenhouse. Ensure all connections are secure.
2. **Install Vertical Supports:** Attach the vertical steel bars to the base, followed by the horizontal bars for the shelf levels.
3. **Place Wire Shelves:** Insert the four wire mesh shelves onto the designated horizontal bars. These shelves are removable to accommodate taller plants or accessories.
4. **Attach the Cover:** Drape the clear PVC cover over the assembled frame. The fitted cover includes integrated tie-downs to fasten securely to the steel frame, preventing flapping.
5. **Secure the Greenhouse:** For outdoor use, it is recommended to anchor the greenhouse to prevent it from blowing away in strong winds. Use additional weights or secure it to a deck or ground stakes if necessary.




Figure 1: Assembly diagram with key features and dimensions.




Figure 2: Detailed dimensions of the greenhouse frame.

## OPERATING INSTRUCTIONS

The Miracle-Gro Mini Walk-in Greenhouse is designed for optimal plant growth and protection.

- **Plant Placement:** Utilize the four wire mesh shelves to organize your plants. Remove shelves as needed to accommodate taller plants or to create space for larger items.
- **Light Exposure:** The clear PVC cover allows maximum light penetration, crucial for plant growth, even during cooler months.
- **Ventilation and Access:** The double-zipper door provides easy access to your plants. It can be rolled up and secured with ties to allow for ventilation and temperature control, preventing overheating on warmer days.
- **Season Extension:** Use the greenhouse to start seedlings earlier in the spring or to extend your growing season into the cooler autumn months.
- **Pest Protection:** The enclosed structure helps protect plants from common garden pests, rabbits, deer, and other animals.



Figure 3: User interacting with plants inside the greenhouse.



Figure 4: Watering seedlings on a shelf within the greenhouse.

## MAINTENANCE

---

- **Frame Care:** The steel frame is powder-coated to resist chipping, peeling, rust, and corrosion. Clean with a damp cloth as needed.
- **Cover Care:** Periodically inspect the PVC cover for any damage or tears. Small tears can often be repaired with clear packing tape. Clean the cover gently with mild soap and water to maintain light transmission. Avoid harsh chemicals.
- **Storage:** The greenhouse can be disassembled for easy storage during off-seasons. Ensure all components are clean and dry before storing in a cool, dry place.



Figure 5: Detail of the durable double-zipper for easy access.

## TROUBLESHOOTING

---

- **Greenhouse Instability in Wind:** If the greenhouse is prone to tipping or blowing away in strong

winds, ensure it is properly anchored. Use heavy objects inside the base, secure it to a deck railing, or use ground stakes.

- **Flimsy Shelves:** If wire shelves feel unstable, consider using zip ties to secure them more firmly to the frame.
- **Cover Damage:** In case of minor rips or tears in the PVC cover, thick clear packing tape can be used for temporary or permanent repairs.

## SPECIFICATIONS

---

Feature	Detail
Model Number	70526
Dimensions (Assembled)	56"L x 28.4"W x 76"H (4'8" x 29" x 6'5")
Item Weight	13 Pounds
Frame Material	Alloy Steel with Powder Coat Finish
Cover Material	Polyvinyl Chloride (PVC)
Number of Doors	1 (Double-zipper)
Shelves	4 Wire Mesh, Removable
Color	Translucent
UPC	677599705267

## WARRANTY AND SUPPORT

---

### 90 Day Limited Warranty

This Miracle-Gro Mini Walk-in Greenhouse comes with a 90-day limited warranty. Please refer to the product packaging or contact customer service for full details regarding warranty coverage and terms.



Figure 6: 90 Day Limited Warranty information.

### Customer Service

Miracle-Gro offers USA-based customer service to assist with any questions, online manuals, warranty information, how-to videos, ordering parts, and product registration.

For support, please visit the [Miracle-Gro Store on Amazon](#) or refer to the contact information provided with your product.