**Bayer Design 17033AD**

# Bayer Design XEO Doll Stroller Set 17033AD

Instruction Manual

## Introduction

Thank you for choosing the Bayer Design XEO Doll Stroller Set 17033AD. This comprehensive set is designed to provide an engaging play experience, allowing children to care for their dolls with a realistic and versatile stroller, doll bed, and accessories. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and enjoyable use.

### Important Safety Information

**WARNING: Not suitable for children under 3 years due to small parts. Choking hazard!**
Please retain this instruction manual for future reference.

## Key Features

- Complete doll stroller set including a doll bed, shoulder bag, sleeping bag, and doll accessories.
- XEO doll stroller with an adjustable handle, approximately 58-71 cm.
- Features a reversible handle and convertible seat, allowing transformation into a pushchair.
- Doll bed with a sleeping bag for comfortable doll rest.
- Includes accessories such as plates, cutlery, cups, and a pacifier for role-playing.

## Setup and Assembly

Follow these steps to assemble your Bayer Design XEO Doll Stroller Set. Refer to the assembly video for visual guidance.

### 1. Unpacking and Component Identification

Carefully unpack all components and verify against the parts list. Ensure all pieces are present before beginning assembly.



*Image: Overview of all components included in the XEO Doll Stroller Set.*

## 2. Doll Bed Assembly

Assemble the doll bed by inserting the metal rods into the fabric sleeves and connecting them with the plastic corner pieces. Ensure all connections are secure.



*Image: The assembled doll bed, ready for use.*

## 3. Stroller Frame Assembly

Unfold the stroller frame. Attach the main support bars and secure them with the provided screws using a screwdriver. Ensure the frame is stable.

## 4. Wheel Attachment

Attach the larger rear wheels to the rear axle of the stroller frame. Secure them with the provided caps. Then, attach the smaller swivel front wheels to the front of the frame, ensuring they click into place securely.



*Image: The assembled XEO doll stroller.*

### 5. Bassinet/Seat Attachment

Attach the bassinet or seat unit to the stroller frame. Ensure the attachment points are securely fastened. The bassinet can be converted into a seat by adjusting the straps and buckles.

### Assembly Video Guide

*Video: Detailed assembly instructions for the Bayer Design XEO Doll Stroller Set. This video demonstrates step-by-step how to put together the doll bed, stroller frame, attach the wheels, and secure the bassinet/seat unit.*

## Operating Instructions

### Adjusting the Handlebar

The handlebar height can be adjusted to suit the child's height. Locate the adjustment buttons on either side of the handle, press them, and move the handle up or down to the desired position. Release the buttons to lock it in place.

### Reversible Handle Feature

The stroller features a reversible handle. To change the direction, locate the release mechanisms near the handle's pivot points, activate them, and swing the handle over to the opposite side. This allows the doll to face the child or face forward.

### Converting Bassinet to Seat

The bassinet can be converted into a seat. Unfasten any securing straps or buckles holding the bassinet in its flat position. Adjust the backrest and footrest to form a seated position. Secure any new straps or buckles to maintain the seat

configuration.

### Using Accessories

The set includes a sleeping bag, shoulder bag, and plastic accessories (bottle, pacifier, dishes). Use the sleeping bag to keep the doll cozy in the bed or stroller. The shoulder bag can be attached to the stroller handle for carrying doll essentials. The plastic accessories are for imaginative role-play.



*Image: Child interacting with the doll stroller set, demonstrating its play features.*

## Maintenance

### Cleaning Instructions

To clean the fabric parts of the stroller and doll bed, wipe with a damp cloth and mild soap. Do not machine wash or tumble dry. Allow to air dry completely before storage or next use. The plastic accessories can be washed with warm soapy water.

### Storage

When not in use, store the doll stroller set in a clean, dry place away from direct sunlight to prevent fading and damage.

## Troubleshooting

### Stroller Not Folding/Unfolding Smoothly

Ensure all locking mechanisms are disengaged before attempting to fold or unfold the stroller. Check for any obstructions in the folding joints. Apply gentle, even pressure.

### Wheels Not Turning Freely

Check for any hair, string, or debris caught in the wheel axles. Clean the wheels and axles as needed. Ensure the wheels are correctly attached and secured.

### Loose Connections

Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary to maintain stability and safety.

## Specifications

- **Brand:** Bayer Design
- **Model Number:** 17033AD
- **Recommended Age:** 36 months - 7 years
- **Product Dimensions (L x W x H):**8 x 37.01 x 23.5 cm (packaged); 37L x 73W x 68H cm (assembled stroller)
- **Item Weight:** 4.47 Kilograms
- **Main Material:** Fabric, Metal
- **Color:** Rose, Grey
- **Educational Value:** Fosters imaginative play and social learning in children
- **Battery/Batteries Required:** No
- **Wheel Type:** Swivel

## Warranty and Support

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your proof of purchase for any warranty claims.

© 2025 Bayer Design. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question