

[manuals.plus](#) /› [Nilox](#) /› [Nilox MOUSB3013 USB Ergonomic Mouse User Manual](#)

Nilox MOUSB3013

Nilox MOUSB3013 USB Ergonomic Mouse User Manual

1. INTRODUCTION

This manual provides detailed instructions for the Nilox MOUSB3013 USB Ergonomic Mouse. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user comfort. The Nilox MOUSB3013 is a black, wired USB mouse designed with an ergonomic shape for comfortable use.



Image 1.1: The Nilox MOUSB3013 ergonomic mouse, showcasing its design and primary controls.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- Nilox MOUSB3013 USB Ergonomic Mouse
- User Manual (this document)



Image 2.1: The Nilox MOUSB3013 mouse packaging, highlighting its features.

3. SETUP INSTRUCTIONS

The Nilox MOUSB3013 mouse is designed for plug-and-play functionality, requiring no additional software installation for basic operation.

1. **Connect the USB Cable:** Locate an available USB port on your computer. Insert the USB connector of the Nilox MOUSB3013 mouse firmly into the USB port.
2. **System Recognition:** Your operating system (Windows, macOS, Linux) will automatically detect and

install the necessary drivers. This process usually takes a few seconds.

3. **Begin Use:** Once the system indicates that the device is ready, you can begin using your mouse.



Image 3.1: The underside of the Nilox MOUSB3013 mouse, illustrating the optical sensor.

4. OPERATING THE MOUSE

The Nilox MOUSB3013 features an ergonomic design for comfortable hand positioning and includes 6 buttons for enhanced functionality.

4.1 Button Functions

- **Left Click Button:** Primary button for selecting items, opening files, and executing commands.
- **Right Click Button:** Secondary button for accessing context menus and special functions.
- **Scroll Wheel:** Used for scrolling through documents and web pages. It can also function as a middle click button.
- **DPI Adjustment Button:** Located near the scroll wheel, this button allows you to cycle through different DPI (Dots Per Inch) sensitivity settings to adjust cursor speed.
- **Side Buttons (2):** Typically configured as "Forward" and "Back" buttons for web browsing and file navigation. These functions may be customizable via operating system settings or third-party software.



Image 4.1: Top view of the mouse, highlighting the main buttons and scroll wheel.

4.2 Ergonomic Design

The vertical orientation of the Nilox MOUSB3013 is designed to promote a more natural hand and wrist posture, reducing strain during prolonged use. This ergonomic feature aims to enhance comfort and prevent repetitive strain injuries.



Image 4.2: Side profile of the Nilox MOUSB3013, illustrating its ergonomic vertical design.

5. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Nilox MOUSB3013 mouse.

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to ensure accurate tracking.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures and direct sunlight.

6. TROUBLESHOOTING

If you encounter issues with your Nilox MOUSB3013 mouse, please refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
Mouse is not responding.	<p>Ensure the USB cable is securely connected to a working USB port.</p> <p>Try connecting the mouse to a different USB port on your computer.</p> <p>Restart your computer.</p> <p>Test the mouse on another computer to determine if the issue is with the mouse or the computer.</p>
Cursor movement is erratic or jumpy.	<p>Clean the optical sensor on the underside of the mouse.</p> <p>Ensure you are using the mouse on a clean, non-reflective, and uniform surface. Avoid glass or highly reflective surfaces.</p> <p>Adjust the DPI setting using the DPI button on the mouse.</p>
Buttons are not functioning correctly.	<p>Check your operating system's mouse settings to ensure buttons are configured correctly.</p> <p>Restart your computer.</p>

7. TECHNICAL SPECIFICATIONS




Brand	Nilox
Model Number	MOUSB3013 (S77103754)
Connectivity Technology	USB (Wired)
Movement Detection Technology	Optical
Special Feature	Ergonomic Design
Number of Buttons	6
Color	Black
Operating System Compatibility	Windows, macOS, Linux
Product Dimensions (LxWxH)	6.75 x 4.94 x 3.51 inches (approx. 17.1 x 12.5 x 8.9 cm)
Item Weight	14.1 ounces (approx. 400 grams)

8. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Nilox website. For technical support or further assistance, please contact Nilox customer service through their official channels.

Official Nilox Website: www.nilox.com

Related Documents - MOUSB3013

	<p>Nilox Onair Smartwatch User Manual</p> <p>User manual for the Nilox Onair Smartwatch (Model: NXSWONAIR), detailing its features, specifications, operation, safety information, and warranty provided by Esprinet S.p.A.</p>
	<p>Nilox Electric Scooter V1 User Manual: Safety, Operation, and Maintenance Guide</p> <p>Comprehensive user manual for the Nilox Electric Scooter V1, covering safety instructions, operation, assembly, maintenance, troubleshooting, and technical specifications. Learn how to safely operate and care for your Nilox electric scooter.</p>
	<p>Nilox UPS Premium SineWave 2000/3000 VA User Manual</p> <p>Comprehensive user manual for Nilox UPS Premium SineWave models (2000 VA and 3000 VA), detailing installation, operation, maintenance, and troubleshooting for reliable power protection.</p>
	<p>Nilox PS300 Portable Power Station User Guide</p> <p>User guide for the Nilox PS300 Portable Power Station, detailing its features, specifications, usage instructions, charging methods, troubleshooting tips, security advice, and environmental information.</p>
	<p>Nilox NXAIRPUMP Portable Electric Air Compressor Instruction Manual</p> <p>This manual provides comprehensive instructions for the Nilox NXAIRPUMP Portable Electric Air Compressor, covering setup, operation, features, troubleshooting, and safety guidelines for efficient and reliable use.</p>
	<p>Nilox NXBK033 Professional Laptop Backpack (15.6") - Black</p> <p>Discover the Nilox NXBK033 professional backpack, designed for safe transport of laptops up to 15.6 inches. Features waterproof material, ample storage, and comfortable design for daily use by professionals, students, and travelers.</p>