

KAIDI KD-829

KAIDI KD-829 Waterproof Portable Bluetooth Speaker User Manual

This manual provides essential instructions for the safe and efficient use of your KAIDI KD-829 Waterproof Portable Bluetooth Speaker. Please read it thoroughly before use and retain it for future reference.

Safety Information	Product Overview	Setup	Operating Instructions	Maintenance
	Troubleshooting	Specifications	Warranty & Support	

1. IMPORTANT SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to your device or injury to yourself.

- **Water Resistance:** The KAIDI KD-829 speaker is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. Ensure the charging port cover is securely closed before exposing the speaker to water. Do not expose to salt water or other liquids.
- **Temperature:** Avoid exposing the speaker to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Charging:** Use only the provided charging cable and a compatible power adapter. Do not charge the speaker in wet conditions.
- **Cleaning:** Do not use abrasive cleaners or solvents. Refer to the Maintenance section for proper cleaning instructions.
- **Disassembly:** Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- **Hearing Protection:** Avoid listening at high volume levels for prolonged periods to prevent hearing damage.

2. PRODUCT OVERVIEW

The KAIDI KD-829 is a portable, waterproof Bluetooth speaker designed for high-quality audio playback in various environments, including outdoor and humid settings like beaches and pools. It features powerful sound output and a durable design.

Key Features:

- **ANATEL Approved:** Certified for quality and safety.
- **IPX7 Waterproof:** Fully submersible for worry-free use near water.
- **Powerful Audio:** 31W output with 2+1 speakers for rich, dynamic sound.
- **Long Battery Life:** Up to 12 hours of playback on a single charge (2200mAh battery).
- **True Wireless Stereo (TWS):** Connect two KD-829 speakers for an immersive stereo experience.

Package Contents:

- KAIDI KD-829 Portable Bluetooth Speaker
- Charging Cable
- User Manual

Product Images:



Figure 2.1: Front view of the KAIDI KD-829 speaker, showcasing its cylindrical design and speaker grille.

KD-829



Figure 2.2: Packaging box of the KAIDI KD-829 speaker, displaying key features and specifications.



Figure 2.3: The KAIIDI KD-829 speaker partially submerged in water, highlighting its IPX7 waterproof feature.

3. SETUP

3.1 Charging the Speaker

1. Locate the charging port on the speaker, usually protected by a rubber flap.
2. Open the rubber flap and connect the provided charging cable to the speaker's charging port.
3. Connect the other end of the charging cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate, typically red, to show that the speaker is charging.
5. Once fully charged (approximately 3-4 hours), the indicator light will change color (e.g., turn off or turn blue/green).
6. Disconnect the charging cable and securely close the rubber flap to maintain the speaker's waterproof rating.

A full charge provides up to 12 hours of playback, depending on volume level and audio content.

3.2 Bluetooth Pairing

1. **Power On:** Press and hold the Power button on the speaker until you hear an audible prompt or see the LED indicator flash, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Select Speaker:** In the list of available devices, look for "KAIDI KD-829" (or a similar name) and select it to connect.
4. **Confirmation:** Once successfully paired, you will hear a confirmation sound from the speaker, and the LED indicator will typically turn solid blue or flash slowly.
5. **Reconnect:** The speaker will automatically attempt to reconnect to the last paired device when powered on.

3.3 Auxiliary (AUX) Connection

1. Open the rubber flap covering the ports.
2. Connect one end of a 3.5mm audio cable (not included) to the AUX-in port on the speaker.
3. Connect the other end of the audio cable to the headphone jack of your audio source (e.g., MP3 player, computer).
4. The speaker will automatically switch to AUX mode.
5. Adjust volume on both the speaker and your audio source.

3.4 True Wireless Stereo (TWS) Pairing (Optional)

To achieve a stereo sound experience, you can pair two KAIDI KD-829 speakers together.

1. Ensure both KD-829 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a specific button indicated in the speaker's quick start guide, often the Play/Pause button for 3-5 seconds) until you hear a pairing prompt.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation sound once connected.
4. Now, connect your Bluetooth device to the primary speaker as described in section 3.2. Audio will play in stereo across both speakers.

4. OPERATING INSTRUCTIONS

4.1 Button Functions (Typical Layout)

- **Power Button:** Press and hold to Power ON/OFF. Short press to change modes (Bluetooth/AUX).
- **Play/Pause Button:** Short press to Play/Pause music. Short press to Answer/End calls. Press and hold to reject calls.
- **Volume Up (+):** Short press to increase volume. Press and hold for Next Track.
- **Volume Down (-):** Short press to decrease volume. Press and hold for Previous Track.
- **TWS Button (if separate):** Short press to activate/deactivate TWS pairing mode.

4.2 Audio Playback

- Once connected via Bluetooth or AUX, start playing music from your connected device.

- Use the Volume Up/Down buttons on the speaker or your device to adjust the sound level.
- Use the Play/Pause button for basic playback control.

4.3 Hands-Free Calling

When connected via Bluetooth to a smartphone, the speaker can be used for hands-free calls.

- **Answer Call:** Short press the Play/Pause button.
- **End Call:** Short press the Play/Pause button during a call.
- **Reject Call:** Press and hold the Play/Pause button when an incoming call rings.

5. MAINTENANCE

5.1 Cleaning

- Ensure the speaker is powered off and disconnected from any power source before cleaning.
- Use a soft, damp cloth to wipe the exterior of the speaker.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Allow the speaker to air dry completely before use or charging.

5.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to about 50% every few months to prolong its lifespan.

5.3 Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the speaker connected to a charger for excessively long periods after it is fully charged.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker for at least 30 minutes.
Cannot pair via Bluetooth.	Speaker is not in pairing mode. Bluetooth is off on device. Speaker is connected to another device.	Ensure speaker is in pairing mode. Turn on Bluetooth on your device. Disconnect from other devices. Try restarting both speaker and device.
No sound.	Volume too low. Incorrect input mode. Device not playing audio.	Increase volume on both speaker and device. Ensure correct mode (Bluetooth/AUX) is selected. Check audio playback on your device.
Poor sound quality / Distortion.	Bluetooth range exceeded. Low battery. Audio source quality.	Move device closer to speaker. Charge the speaker. Try a different audio source or file.

Problem	Possible Cause	Solution
Battery does not hold charge.	Battery degradation. Faulty charging cable/adapter.	Ensure you are using the correct charging cable and a functional adapter. If the issue persists, contact customer support as the battery may be degraded.

7. SPECIFICATIONS

Feature	Detail
Model Name	KD-829
Manufacturer	KAIDI
Brand	Yuce (as listed by seller)
Maximum Speaker Output Power	31 Watts
Connectivity Technology	Bluetooth, Auxiliary (Wired)
Audio Output Mode	Surround Sound (2.1 Channel Configuration)
Special Features	IPX7 Waterproof
Recommended Product Uses	For Smartphones or Tablets, Outdoor and Humid Environments
Color	Black
Control Method	Touch
Speaker Size	8 Inches (Audio Controller Size)
Battery Duration	Up to 12 Hours
Battery Capacity	2200 mAh
Item Dimensions (L x W x H)	22 x 10 x 10 cm (approx. 8.66 x 3.94 x 3.94 inches)
Compatible Devices	Notebook, Smartphone, Tablet
Power Source	Battery Powered
Components Included	Speaker, Cable

8. WARRANTY AND SUPPORT

8.1 Product Warranty

The KAIDI KD-829 speaker comes with a **3-month limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to conditions beyond the product's specified ratings (e.g., submersion beyond 1 meter or for longer than 30 minutes, exposure to salt water).

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

If you encounter any issues with your KAIDI KD-829 speaker that cannot be resolved using the troubleshooting guide, or if you have questions regarding its operation or warranty, please contact the retailer where you purchased the product or the manufacturer's customer service.

For the most up-to-date support information, please refer to the official KAIDI website or the contact details provided with your purchase.