

Manuals.plus /

› VIZIO /

› VIZIO 2.1 Soundbar with Wireless Subwoofer User Manual (Model SV210M-0808)

VIZIO SV210M-0808

VIZIO 2.1 Soundbar with Wireless Subwoofer User Manual

MODEL: SV210M-0808

Introduction

This manual provides instructions for the VIZIO 2.1 Soundbar with Wireless Subwoofer, Model SV210M-0808. This audio system is designed to enhance your home entertainment experience with immersive sound technologies like Dolby Atmos and DTS:X. It features a low-profile soundbar and a compact wireless subwoofer, offering a two-piece design suitable for various room sizes. Connectivity options include HDMI eARC and Bluetooth, with control available via the VIZIO mobile app or your TV remote.

Package Contents

Verify that all items listed below are included in your package:

- Soundbar
- Wireless Subwoofer
- HDMI Cable
- Power Cord (for Soundbar)
- Power Cord (for Subwoofer)
- QuickFit mounting screws (for compatible VIZIO TVs)

Note: A soundbar remote control is sold separately.

Fill your space with bass

Bring the cinema home




Figure 1: Included components of the VIZIO 2.1 Soundbar system.

Setup Guide

1. Placement

Position the soundbar centrally below your television. The wireless subwoofer can be placed anywhere in the room, ideally within 30 feet of the soundbar, for optimal bass distribution.




Figure 2: Recommended placement for the soundbar and wireless subwoofer.

2. Connections

1. **HDMI eARC Connection:** Connect one end of the included HDMI cable to the HDMI OUT (eARC) port on the back of your soundbar. Connect the other end to the HDMI eARC port on your television. This connection allows for high-quality audio transmission and control of the soundbar volume using your TV remote.
2. **Power Connection:** Connect the power cord to the soundbar and then to a wall outlet. Connect the subwoofer's power cord to the subwoofer and then to a wall outlet.
3. **Bluetooth Connection:** For wireless audio streaming from mobile devices, refer to the 'Bluetooth Pairing' section under Operation.
4. **USB Connection:** The USB port on the soundbar is for firmware updates only.



Figure 3: Soundbar rear panel connections.



Figure 4: Wireless Subwoofer rear panel connections.

3. QuickFit Installation (for compatible VIZIO TVs)

The QuickFit feature allows for seamless attachment of the soundbar directly to select VIZIO TVs without tools. This creates an integrated look and eliminates gaps.

1. **Twist in:** Locate the mounting points on the bottom of your compatible VIZIO TV. Twist the QuickFit mounting screws into these points.
2. **Plug in:** Connect the HDMI eARC cable from the soundbar to the TV's eARC port.
3. **Snap on:** Align the soundbar with the mounting screws and gently push until it snaps securely into place.

The art of audio

Premium fabrics and modern design



Figure 5: QuickFit installation steps for compatible VIZIO TVs.

For a list of compatible VIZIO TVs, visit www.vizio.com/quickfit.

Operation

1. Power On/Off


Press the Power button on the soundbar or use the VIZIO mobile app to turn the soundbar on or off. If connected via HDMI eARC, the soundbar may power on/off automatically with your TV.

2. Controlling with VIZIO Mobile App

Download the VIZIO Mobile app from your device's app store (Android or iOS). A VIZIO Account is required. The app allows you to control soundbar settings, adjust audio levels (bass, treble, dialogue), and receive product updates.

Hear every word

Say goodbye to missed words and muffled conversations with the ClearDialog setting.



Screen image simulated. VIZIO TV required to enable ClearDialog.

Figure 6: VIZIO Mobile App interface for soundbar control.

3. Controlling with TV Remote (HDMI eARC)

When connected via your TV's HDMI eARC port, you can use your existing TV remote to control the soundbar's volume. This provides a simplified user experience.

4. Bluetooth Pairing

To stream audio wirelessly from a Bluetooth-enabled device:

1. Ensure the soundbar is powered on.
2. Activate Bluetooth on your mobile device.
3. Select the VIZIO soundbar from the list of available devices. The soundbar will indicate a successful connection.

Your sound. Your way.

Access audio controls with the VIZIO app

VIZIO app and VIZIO Account required for soundbar control, settings, and system updates.
Soundbar remote control not included.




Figure 7: Bluetooth streaming from a mobile device.

5. Audio Modes and Settings

Adjust various audio settings for a personalized listening experience. These settings can typically be accessed through the VIZIO Mobile app or your VIZIO TV's integrated audio menu (if compatible).

- **Bass:** Adjusts low-frequency audio output.
- **Treble:** Adjusts high-frequency audio output.
- **ClearDialog:** Enhances dialogue clarity, making conversations easier to understand.
- **Night Mode:** Reduces subwoofer output for quieter listening environments.
- **Virtual:X:** Enables or disables DTS Virtual:X for virtual surround sound.
- **Height:** Adjusts the audio height effect for immersive content.




Figure 8: VIZIO TV integrated audio menu for soundbar settings.

Features Overview

- **Dolby Atmos & DTS:X:** Experience multi-dimensional audio that moves around you, creating an immersive soundstage for movies, music, and games.
- **Bluetooth Streaming:** Wirelessly stream audio from your smartphone, tablet, or other Bluetooth-enabled devices.
- **QuickFit Compatibility:** Seamlessly attach the soundbar to select VIZIO TVs for a clean, integrated setup.
- **VIZIO Mobile App Control:** Access advanced soundbar settings and product updates directly from your smartphone.
- **ClearDialog:** Enhance vocal clarity to ensure every word is heard.
- **Powerful Bass:** The compact wireless subwoofer delivers room-filling bass down to 45Hz.



Figure 9: Immersive audio experience with Dolby Atmos and DTS:X.

Care and Maintenance

To ensure the longevity and optimal performance of your VIZIO Soundbar system, follow these care guidelines:

- **Cleaning:** Gently wipe the surfaces of the soundbar and subwoofer with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.
- **Ventilation:** Ensure adequate airflow around the soundbar and subwoofer. Do not block any ventilation openings.
- **Environment:** Keep the system away from direct sunlight, heat sources, and moisture. Avoid placing it in areas with excessive dust or vibrations.
- **Power:** Disconnect the power cords from the wall outlet if the system will be unused for an extended period.

Troubleshooting

If you encounter issues with your VIZIO Soundbar system, refer to the following common solutions:

- **No Sound:**
 - Ensure all cables are securely connected.
 - Verify the soundbar is powered on and the correct input source is selected.
 - Check your TV's audio output settings to ensure it's set to external speakers or HDMI eARC.
 - Increase the volume on both the soundbar and your TV.
- **Subwoofer Not Producing Sound:**
 - Ensure the subwoofer is powered on and its power indicator light is active.
 - Check the wireless connection between the soundbar and subwoofer. Refer to the VIZIO app or soundbar manual for re-pairing instructions if needed.
- **Bluetooth Connection Issues:**
 - Ensure the soundbar is in Bluetooth pairing mode.
 - Delete the soundbar from your device's Bluetooth list and attempt to re-pair.
 - Move your device closer to the soundbar to reduce interference.
- **Sound Distortion:**

- Reduce the volume level.
- Check audio settings (e.g., bass, treble) in the VIZIO app or TV menu and adjust as necessary.

For further assistance, please contact VIZIO customer support or visit their support website.

Specifications

Feature	Detail
Model Number	SV210M-0808
Surround Sound Channel Configuration	2.1
Speaker Type	Soundbar with Wireless Subwoofer
Audio Technologies	Dolby Atmos, DTS:X
Connectivity Technology	Bluetooth, HDMI (eARC), USB
Wireless Communication Technology	Bluetooth
Subwoofer Connectivity	Wireless
Control Method	App (VIZIO Mobile), TV Remote (via HDMI eARC)
Mounting Type	Wall Mount, QuickFit (Compatible with select VIZIO TVs)
Product Dimensions (Soundbar)	3.23"D x 30"W x 2.32"H
Item Weight	11.97 pounds (total system)
Color	Black
UPC	845226022708

Warranty and Support

This VIZIO product comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official VIZIO website.

For technical support, product registration, or to access frequently asked questions, please visit the VIZIO support website or contact customer service:

- **Website:** support.vizio.com
- **Phone:** 844-254-8087