



Manuals.plus /

- › **Brilliant** /
- › Brilliant Slimline Black Fan with Wooden Edge - G60060/09 User Manual

Brilliant G60060/09

Brilliant Slimline Black Fan with Wooden Edge - G60060/09 User Manual

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Brilliant Slimline Black Fan with Wooden Edge, model G60060/09. This modern ceiling fan combines efficient air circulation with versatile lighting options, including dimmable white light and vibrant RGB colors. Designed for ease of use, it comes with a remote control for convenient operation. This manual provides essential information for safe installation, operation, and maintenance of your new fan.



Energie-efficiënte LED voor langdurige helderheid



Ventilator voor een aangename luchtcirculatie



Afstandsbediening voor gemakkelijke bediening vanuit de bank

Image 1: Key features of the Brilliant Slimline Fan, highlighting its energy-efficient LED for lasting brightness, effective fan for pleasant air circulation, and remote control for convenient operation.

Elegant & modern design




Image 2: Illustrates the elegant and modern design, featuring whisper-quiet fan blades, vibrant digital RGB lighting, and high-quality materials including a wooden edge and internal metal/plastic components.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before installation and use. Retain this manual for future reference.

- Ensure the main power supply is disconnected before installation, maintenance, or cleaning.
- Installation must be performed by a qualified electrician in accordance with local wiring regulations.
- The fan must be securely mounted to a ceiling structure capable of supporting its weight (2.02 kg).
- Do not insert fingers or any objects into the fan blades while the fan is operating.
- Keep children and pets away from the fan during operation.
- Do not use the fan in damp or wet environments.
- Only use the provided remote control for operation.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged:

- Brilliant Slimline Black Fan with Wooden Edge (G60060/09)
- Remote Control
- Mounting Hardware (screws, anchors, etc.)
- User Manual

4. SETUP AND INSTALLATION

Follow these steps for proper installation. Professional installation is recommended.

1. **Prepare the Installation Area:** Ensure the power is off at the circuit breaker. Choose a suitable location on the ceiling that can support the fan's weight and allows for adequate clearance around the blades.
2. **Mount the Bracket:** Securely attach the mounting bracket to the ceiling joist or a suitable electrical junction box using the provided hardware.
3. **Electrical Connection:** Connect the fan's wiring to your household electrical wiring according to the wiring diagram in the installation guide (usually included with mounting hardware). Ensure all connections are secure and insulated.
4. **Attach the Fan Unit:** Carefully lift the fan unit and attach it to the mounting bracket. Secure it with the screws provided.
5. **Test Functionality:** Restore power at the circuit breaker. Use the remote control to test the fan and light functions.

5. OPERATING INSTRUCTIONS

The fan is operated using the included remote control. Ensure batteries are correctly inserted into the remote.



Pas de lichtintensiteit, lichtkleur en ventilatorsnelheid eenvoudig aan vanaf uw bank

Image 5: Demonstrates the convenience of adjusting light intensity, light color, and fan speed directly from your couch using the remote control.

5.1 Fan Control

- **Power On/Off:** Press the fan power button to turn the fan on or off.
- **Speed Adjustment:** Use the speed buttons (usually indicated by fan icons or numbers) to cycle through different fan speeds.
- **Direction Change:** The fan offers a direction change function for seasonal use. Activate the appropriate button on the remote (often indicated by sun/snowflake icons or arrows) to switch between cooling (downward airflow) and warmth distribution (upward airflow).



Image 4: Explains the direction change feature. Activate the right button for cool freshness and the left button to spread warmth, illustrating airflow patterns for different seasons.

5.2 Light Control

- **Light On/Off:** Press the light power button to turn the LED light on or off.
- **Dimmable White Light:** Use the dimming buttons (often +/- or sun icons) to adjust the brightness of the white light. The fan supports adjustable color temperature (CCT) from 3000K (warm white) to 6500K (white light).
- **RGB Color Selection:** Press the RGB button or color cycle button to activate the vibrant digital RGB lighting. Use specific color buttons or a color wheel on the remote (if available) to select desired colors.




Image 3: Showcases the dimmable lighting feature for a flexible ambiance, demonstrating white light, natural light, and warm white light settings.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning:** Ensure the power is off before cleaning. Use a soft, damp cloth to wipe down the fan blades and the light cover. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Periodically dust the fan unit to prevent accumulation, which can affect performance and appearance.
- **Blade Inspection:** Check fan blades for any damage or imbalance. If damage is found, contact customer support.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Fan Not Operating:**

- Check if the main power supply is on.
- Ensure the remote control batteries are not depleted and are inserted correctly.
- Verify that the fan is properly connected to the electrical supply.

- **Light Not Working:**

- Check the light power button on the remote.
- Ensure the fan's electrical connections are secure.

- **Remote Control Not Responding:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fan.
- Re-pair the remote control if necessary (refer to specific pairing instructions in the full installation guide).

- **Unusual Noise:**

- Ensure all mounting screws are tightened.
- Check if any fan blades are bent or damaged.
- Verify that the fan is not touching any part of the ceiling or other objects.

If problems persist, contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Brilliant Slimline Black Fan with Wooden Edge - G60060/09.

TECHNISCHE SPECIFICATIES

Digitaal RGB

Dimbaar LED-licht

Kleurtemperatuur: 6500 Kelvin

Vermogensverbruik: 36 watt

Helderheid: 4700 lumen

Spanning: 230 volt

Instelbare CCT
(3000K-6500K)




Image 6: Presents the technical specifications including Digital RGB, Dimmable LED, Color Temperature, Power Consumption, Brightness, Voltage, and Adjustable CCT, alongside visual examples of various RGB light settings.

Feature	Specification
Model Number	G60060/09
Product Dimensions	49 cm (Diameter) x 14 cm (Height)
Item Weight	2.02 kg
Base Material	Wood
Lampshade Material	Wood
Color	Black (with Wooden Edge)
Lamp Type	Fan Lamp (Integrated LED)
LED Features	Dimmable LED, Digital RGB
Color Temperature (CCT)	Adjustable 3000K (Warm White) - 6500K (White Light)
Brightness	4700 Lumen
Power Consumption	36 Watt
Voltage	230 Volt
Number of Units	1



Image 7: Visual representation of the fan's dimensions (49 cm diameter, 14 cm height) and its weight (2.02 Kilograms).



Image 8: Showcases the fan's versatile application and stylish design, making it suitable for various environments such as living rooms, bedrooms, kitchens, and dining areas.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Brilliant website. Keep your proof of purchase for any warranty claims.