

[manuals.plus](#) /› [BELLEZE](#) /› [BELLEZE London 36-inch Electric Fireplace TV Stand User Manual](#)

BELLEZE 014-HG-41897-DWA+336

BELLEZE London 36-inch Electric Fireplace TV Stand User Manual

Model: 014-HG-41897-DWA+336

1. SAFETY INFORMATION

Read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the power outlet voltage matches the appliance's requirements.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This electric fireplace is equipped with overheating protection and is CSA & UL certified for safety.
- Always unplug the fireplace when not in use.

2. SETUP AND ASSEMBLY

This BELLEZE Fireplace TV Stand is designed for straightforward assembly. It is shipped in two separate packages, which may arrive at different times. Please ensure all components are present before beginning assembly.

2.1 Unpacking and Inspection

- Carefully remove all parts from the packaging. Due to the weight of some components (total item weight: 99.6 lbs), assistance may be required for lifting and moving.
- Inspect all parts for any damage. Do not proceed with assembly if any parts are damaged. Contact customer support for replacements.
- Ensure all hardware and components listed in the included assembly instructions are present.

2.2 Assembly Steps

Follow the detailed assembly instructions provided with the product. General steps include:

1. Assemble the main frame of the TV stand using the engineered wood panels and hardware.
2. Attach the sturdy metal base to the bottom of the stand.
3. Install the side cabinets and their adjustable shelves. The shelves can be adjusted to three different levels to accommodate various items.
4. Insert the 36-inch electric fireplace unit into the central opening.
5. Attach the elegant golden handles to the cabinet doors.

2.3 Placement Considerations

- Place the TV stand on a flat, stable surface.
- Ensure adequate clearance around the fireplace unit for proper ventilation.
- This TV stand is designed to accommodate televisions up to 75 inches, with a maximum weight capacity of 70 lbs for the top surface. Each shelf can hold up to 30 lbs.



This diagram provides key dimensions of the TV stand and the electric fireplace insert. It also indicates that the product ships in two separate packages.



This image visually confirms the TV stand's compatibility with various television sizes, specifically highlighting its capacity for TVs up to 75 inches.

3. OPERATING THE ELECTRIC FIREPLACE

The integrated 36-inch electric fireplace provides realistic flame effects, heat, and optional sound. It can be controlled via the built-in display panel or the included remote control.

3.1 Control Panel and Remote Functions

- **Power Button:** Turns the fireplace unit on or off.
- **Heater Control:** Activates or deactivates the heating function. The heater operates at 1400 Watts and can heat areas up to 400 sq. ft.
- **Temperature Adjustment:** Set the desired room temperature between 64°F and 82°F.
- **Flame Control:** Adjusts the brightness of the flame effects. Multiple levels of brightness are available.
- **Timer Control:** Sets an automatic shut-off timer for 1 to 8 hours.
- **Sound Function:** Toggles the realistic fire crackling sounds on or off.



Built Display Control Panel



Fireplace Remote Control



Sound Function



Temperature
64°F - 82°F



Remote Control & Mechanism Control



Heat 5000BTUS/400 square feet



4 Level of Brightness




Timer 1-8H

This diagram explains the functionality of the electric fireplace, including its built-in control panel and remote. It shows options for adjusting flame brightness, temperature (64°F-82°F), heat output (5000 BTUs/400 sq ft), sound effects, and setting a timer (1-8 hours).

This video showcases the realistic flame effects and optional crackling sound feature of the 36-inch electric fireplace, demonstrating its ambiance settings.



Sturdy Metal Base



Adjustable Partition



Elegant Handles



Premium MDF Board

Detailed views showcasing the quality construction and design elements: the robust metal base for stability, the adjustable shelving for flexible storage, the stylish golden handles, and the durable engineered wood material.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TV stand and electric fireplace.

4.1 TV Stand Care

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Dust regularly to prevent buildup.
- Avoid placing hot items directly on the surface without protection.
- Check and tighten any loose hardware periodically.

4.2 Electric Fireplace Care

- Ensure the unit is unplugged and cool before cleaning.
- Clean the exterior surfaces with a soft, damp cloth.
- Periodically check the air intake and exhaust vents for dust or obstructions and clean as necessary.

- Do not attempt to service the internal components of the fireplace. Refer to qualified service personnel if repairs are needed.

5. TROUBLESHOOTING

If you encounter issues with your BELLEZE Fireplace TV Stand, refer to the following common troubleshooting steps.

5.1 Fireplace Not Turning On

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check the circuit breaker or fuse box for tripped breakers or blown fuses.
- Verify the power button on the unit or remote control is pressed.

5.2 No Heat Output

- Confirm the heater function is activated on the control panel or remote.
- Check the temperature setting; ensure it is set higher than the current room temperature.
- Ensure the air intake and exhaust vents are not blocked.

5.3 Flame Effect Not Working

- Verify the flame control button is pressed.
- Check if the brightness level is set too low.

5.4 Remote Control Not Responding

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fireplace unit's receiver.

6. SPECIFICATIONS

Feature	Specification
Brand	BELLEZE
Model Name	014-HG-41897-DWA+336
Product Dimensions	15.6"D x 68"W x 30.6"H
Item Weight	99.6 Pounds
Material	Engineered Wood
Color	Dark Walnut
Power Source	Corded Electric
Fireplace Size	36 inches
Heating Coverage	400 sq. ft
Temperature Range	64°F-82°F

Special Features	Flame Effect, Timer, Sound Function
Max TV Size Supported	Up to 75 inches
Top Table Weight Capacity	70 lbs
Shelf Weight Capacity	30 lbs (each)
Certifications	CSA & UL Certified
UPC	192928053838



This image highlights the storage features of the TV stand, including the wide top surface for media accessories, adjustable shelves within the side cabinets, and the overall design for organization.



Television



DVD Player



Remote Control



Books



An interior view of the TV stand with a cabinet door open, illustrating the adjustable shelving for customized storage and the integrated electric fireplace.



A complete view of the TV stand with a television, demonstrating its aesthetic appeal and how it functions as an entertainment center with the electric fireplace.

7. WARRANTY INFORMATION

This BELLEZE Fireplace TV Stand comes with a**Limited Lifetime Warranty**. Please refer to the warranty documentation included with your product for specific terms, conditions, and coverage details. Keep your proof of purchase for warranty claims.

8. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact BELLEZE customer support. Refer to the contact information provided in your product packaging or visit the official BELLEZE website for support resources.

© 2024 BELLEZE. All rights reserved.